


AIR HANDLER

INSTALLATION INSTRUCTIONS

B64EM & B64VM SERIES



IMPORTANT

ATTENTION INSTALLERS:

It is your responsibility to know this product better than your customer. This includes being able to install the product according to strict safety guidelines and instructing the customer on how to operate and maintain the equipment for the life of the product. Safety should always be the deciding factor when installing this product and using common sense plays an important role as well. Pay attention to all safety warnings and any other special notes highlighted in the manual. Improper installation of the furnace or failure to follow safety warnings could result in serious injury, death, or property damage.

These instructions are primarily intended to assist qualified individuals experienced in the proper installation of this appliance. Some local codes require licensed installation/service personnel for this type of equipment. Please read all instructions carefully before starting the installation. Return these instructions to the customer's package for future reference.

DO NOT DESTROY. PLEASE READ CAREFULLY & KEEP IN A SAFE PLACE FOR FUTURE REFERENCE.

TABLE OF CONTENTS

| | | | |
|--|----------|--|-----------|
| IMPORTANT SAFETY INFORMATION..... | 3 | STARTUP & ADJUSTMENTS..... | 10 |
| REQUIREMENTS & CODES | 3 | Before You Start the Unit..... | 10 |
| GENERAL INFORMATION..... | 4 | Air Circulation..... | 11 |
| Before You Install this Unit | 4 | Running the Blower Continuously | 11 |
| Locating the Air Handler | 4 | Selecting Continuous Low Speed Fan Operation ... | 11 |
| Minimum Clearances | 4 | Turning the Blower Off | 11 |
| Installation in a Garage | 4 | System Cooling | 11 |
| Plenums & Air Ducts | 4 | System Heating | 11 |
| Unconditioned Spaces | 5 | Selecting Minimum Electric Heat Airflow | 11 |
| Air Filters..... | 5 | Blower Configurations | 11 |
| Acoustical Duct Work..... | 5 | Determining Nominal System Capacity..... | 11 |
| AIR HANDLER INSTALLATION | 5 | High Efficiency Units (Variable & Fixed Speed) | 11 |
| Packaging Removal | 5 | Basic Heating Airflow for Variable & Fixed Speed... 11 | |
| Mounting Applications | 5 | Basic Cooling / Heat Pump Airflow for Variable & | |
| Upflow Installations..... | 5 | Fixed Speed | 12 |
| Downflow Installations..... | 5 | TROUBLESHOOTING | 12 |
| Horizontal Installations..... | 5 | UNIT MAINTENANCE..... | 12 |
| Horizontal Left Installations: | 6 | REFRIGERANT CHARGING | 13 |
| Horizontal Right Installations:..... | 6 | FIGURES & TABLES..... | 14 |
| Circuit Breaker Cover Installation | 7 | Figure 8. B64 Series Physical Dimensions..... | 14 |
| Refrigerant Line Connections | 7 | Figure 9. Air Handler Components | 15 |
| Connecting the Linesets..... | 7 | Airflow Data..... | 16 |
| Condensate Drainage | 8 | Table 6. B64EM (FSHE) Airflow Data..... | 16 |
| ELECTRICAL CONNECTIONS | 9 | Table 7. Recommended Cooling Airflow Settings... 17 | |
| Pre-Electrical Checklist..... | 9 | Table 8. B64VM (VSHE) Airflow Data | 18 |
| Line Voltage | 9 | Electrical Data & Diagrams | 19 |
| Thermostat Connections | 9 | Table 9. Control Board Operation | 19 |
| Grounding | 10 | Table 9. Control Board Operation continued | 20 |
| Control Board | 10 | Figure 10. Typical Thermostat Connections..... | 21 |
| Twinning..... | 10 | Figure 11. Low Voltage Wiring For Twinning..... | 21 |
| Line & Low Voltage Connections | 10 | Figure 12. Single Stage Control Board..... | 22 |
| Heater Kits | 10 | Figure 13. Two - Stage Control Board | 22 |
| Humidifier | 10 | Figure 14. Fixed Speed Motor Control Board | 23 |
| Dehumidification Options | 10 | Figure 15. Variable Speed Motor Control Board | 23 |
| Electronic Air Cleaner (EAC) | 10 | Figure 16. B64EM Wiring Diagram | 24 |
| | | Figure 17. B64VM Wiring Diagram | 25 |
| | | INSTALLATION CHECKLIST..... | 28 |

IMPORTANT SAFETY INFORMATION

INSTALLER: Please read all instructions before servicing this equipment. Pay attention to all safety warnings and any other special notes highlighted in the manual. Safety markings are used frequently throughout this manual to designate a degree or level of seriousness and should not be ignored. **WARNING** indicates a potentially hazardous situation that if not avoided, could result in personal injury or death. **CAUTION** indicates a potentially hazardous situation that if not avoided, may result in minor or moderate injury or property damage.

WARNING:

ELECTRICAL SHOCK, FIRE OR EXPLOSION HAZARD


Failure to follow safety warnings exactly could result in serious injury or property damage.

Improper servicing could result in dangerous operation, serious injury, death or property damage.

Before servicing, disconnect all electrical power to furnace.

- **Before servicing, disconnect all electrical power to the air handler.**
- **When servicing controls, label all wires prior to disconnecting. Reconnect wires correctly.**
- **Verify proper operation after servicing.**

WARNING:



| NITROGEN | |
|----------------------------------|---|
| HEALTH | 1 |
| FLAMMABILITY | 0 |
| REACTIVITY | 0 |
| 0 Minimal Hazard 1 Slight Hazard | |

B64EM & B64VM air handlers leave the factory with a nitrogen holding charge. Use caution when preparing coils for field connections. If repairs make it necessary for evacuation and charging, it should only be attempted by qualified, trained personnel thoroughly familiar with this equipment. Some local codes require licensed installation service personnel to service this type of equipment. Under no circumstances should the equipment owner attempt to install and/or service this equipment. Failure to comply with this warning could result in equipment damage, personal injury, or death.

REQUIREMENTS & CODES

WARNING:

This unit must be installed in accordance with instructions outlined in this manual during the installation, service, and operation of this unit. Unqualified individuals should not attempt to interpret these instructions or install this equipment. Failure to follow safety recommendations could result in possible damage to the equipment, serious personal injury or death.

- The installer must comply with all local codes and regulations which govern the installation of this type of equipment. Local codes and regulations take precedence over any recommendations contained in these instructions. Consult local building codes for special installation requirements.
- This equipment contains nitrogen gas. Installation or servicing should only be performed by qualified trained personnel thoroughly familiar with this type equipment.
- All electrical wiring must be completed in accordance with local, state and national codes and regulations and with the National Electric Code (ANSI/NFPA 70) or in Canada the Canadian Electric Code Part 1 CSA C.22.1.
- Installation of equipment may require brazing operations. Installer must comply with safety codes and wear appropriate safety equipment (safety glasses, work gloves, fire extinguisher, etc.) when performing brazing operations.
- Install this unit only in a location and position as specified on [page 4](#) & [page 5](#). This unit is designed only for Indoor installations and should be located with consideration of minimizing the length of the supply and return ducts. See [Table 6, \(page 16\)](#), [Table 7, \(page 17\)](#), [Table 8, \(page 18\)](#), & [Table 9, \(pages 19 and 20\)](#) and the rating plate for proper circulating airflow data.
- Follow all precautions in the literature, on tags, and on labels provided with the equipment. Read and thoroughly understand the instructions provided with the equipment prior to performing the installation and operational checkout of the equipment.
- Air handler installations in a residential garage must be installed as specified on [page 4](#).
- This air handler may not be used for temporary heating or cooling of buildings or structures under construction. Operating the air handler during construction is not permitted and will void the manufacturer's warranty.

GENERAL INFORMATION

This appliance has been tested for capacity and efficiency in accordance with AHRI Standards and will provide many years of safe and dependable comfort, providing it is properly installed and maintained. Abuse, improper use, and/or improper maintenance can shorten the life of the appliance and create unsafe hazards. Please read all instructions before installing the unit.

Before You Install this Unit

- ✓ This equipment is securely packaged at the time of shipment and upon arrival should be carefully inspected for damage prior to installing the equipment at the job site. Claims for damage (apparent or concealed) should be filed immediately with the carrier.
- ✓ it is recommended that the cooling load of the area to be conditioned should be calculated and a system of the proper capacity selected.
- ✓ Check the electrical supply and verify the power supply is adequate for unit operation. The system must be wired and provided with circuit protection in accordance with local building codes. If there is any question concerning the power supply, contact the local power company.
- ✓ Verify the duct system is appropriate for the air handler being installed. Please note that when replacing an existing system with lower air-flow, the duct system may require modification.

Locating the Air Handler

- Survey the job site to determine the best location for mounting the unit. Consideration should be given to availability of electric power, service access, and noise.
- The dimensions of the room or alcove must be able to accommodate the overall size of the unit and the installation clearances listed in [Table 1](#). Physical dimensions for this air handler are also shown in [Figure 8 \(page 14\)](#).
- The air handler should be set into position before routing the refrigerant tubing.

Minimum Clearances

- This appliance must be installed in accordance with clearances listed in [Table 1](#). The air handler must be installed with ample clearance for easy access to the air filter, blower assembly, heater assembly, controls, and vent connections. Applicable building codes may require additional clearance to equipment. Refer to applicable building codes for details.
- Static pressure drop through louvered openings and through return air plenums should be considered in the overall duct design in the determination of the total external static pressure.

Installation in a Garage

WARNING:

Do not place combustible materials on or against the cabinet. Do not place flammable materials, (gasoline, paint thinners, etc.) or any other flammable vapors and liquids, in the vicinity of the air handler.

The B64 Series air handler may be installed in a residential garage with the provision that the unit must be located or protected to prevent physical damage by vehicles.

Plenums & Air Ducts

- Plenums and air ducts should be installed in accordance with the standards of the National Fire Protection Association Standard for Installation of Air Conditioning Systems (NFPA 90A), Standard for Installation of Residence Type Warm Air Heating and Air Conditioning Systems (NFPA 90B), and all applicable local codes. NFPA publications are available by writing to: National Fire Protection Association, Batterymarch Park, Quincy, ME 02269 or visit www.NFPA.org online.


WARNING:

All return ducts must be secured to the air handler using appropriate methods. All return ducts must be adequately sealed. When return air is provided through the bottom of the unit, the joint between the air handler and the return air plenum must be air tight.

Return air and circulating air ducts must not be connected to any other heat producing device such as a fireplace insert, stove, etc. This may result in fire, explosion, carbon monoxide poisoning, personal injury, or property damage.

- Design the duct work according to methods described by the Air Conditioning Contractors of America (ACCA).
- This unit is designed only for use with a return and supply duct. The return air duct must have the same free area as the opening provided on the air handler. The ducts should be appropriately sized to the capacity of the air handler to ensure its proper airflow rating.

| INSTALLATION CLEARANCES | |
|--------------------------|---------------------------|
| Left Side 0 Inches | Right Side 0 Inches |
| Back 0 Inches | Front †See Notes |



†NOTE:
Alcove Installations - Allow 24 in. minimum clearance from front of unit to nearest wall or partition for servicing. Recommended clearance is 36 in.

Table 1. Minimum Unit Clearances

- Use transition fittings if the supply and/or return air openings of the unit do not match the duct openings. These transitions should be dimensioned in accordance with standard practice as specified in the ASHRAE recommendations for duct transitions.
- Flexible connectors may be used between the unit and the ductwork to prevent transmission of vibration from the unit to the structure. If electric heater kits are installed, heat resistant material must be used for the flexible connector at the supply air end of the unit.
- It is good practice to seal all connections and joints with industrial grade sealing tape or liquid sealant. Requirements for sealing ducts vary from region to region. Consult with local codes for requirements specific to your area.

Unconditioned Spaces

All duct work passing through unconditioned space must be properly insulated to minimize duct losses and prevent condensation. Use insulation with an outer vapor barrier. Refer to local codes for insulation material requirements.

Air Filters

B64 Series Air Handlers are not supplied with an air filter when shipped from the factory. The installer must provide a high velocity filter that is appropriately sized to the return air duct opening or filter rack located in the bottom of the unit. Accessing the filter does not require tools and can be removed from the front of the unit by removing the filter door. See Unit Maintenance (page 12) for filter sizes and installation information.

WARNING:

Never operate the air handler without a filter or with doors removed. Dust and lint can build up on internal components, resulting in loss of efficiency, equipment damage, and possible fire.

Acoustical Duct Work

- Certain installations may require the use of acoustical lining inside the supply duct work. Acoustical insulation must be in accordance with the current revision of the Sheet Metal and Air Conditioning Contractors National Association (SMACNA) application standard for duct liners. Duct lining must be UL classified batts or blankets with a fire hazard classification of FHC-25/50 or less.
- Fiber duct work may be used in place of internal duct liners if the fiber duct work is in accordance with the current revision of the SMACNA construction standard on fibrous glass ducts. Fibrous duct work and internal acoustical lining must be NFPA Class 1 air ducts when tested per UL Standard 181 for Class 1 ducts.
- Damping ducts, flexible vibration isolators, or pleated media-style filters on the return air inlet of the air handler may be used to reduce the transmission of equipment noise emanating from the air handler. These treatments can produce a quieter installation, particularly in the heated space. However, they can increase the pressure drop in the duct system. Care must be taken to maintain the proper maximum pressure rise across the air handler, temperature rise and flow rate. This may mean increasing the duct size and/or reducing the blower speed. These treatments must be constructed and installed in accordance with NFPA and SMACNA construction standards. Consult with local codes for special requirements. For best sound performance, be sure to install all the needed gaskets and grommets around penetrations into the air handler, such as for electrical wiring.

AIR HANDLER INSTALLATION

B64 series air handlers are shipped ready for vertical upflow installation and are approved for attic, basement, alcove/closet or crawlspace installation with zero clearance to combustibles. See Table 1, (page 4) for required installation clearances. **This appliance is approved only for indoor use. If installing an electric heater kit, please refer to the installation instructions supplied with the kit for recommended duct clearances to combustibles.**

- The unit must be leveled at installation and attached to a properly installed duct system.
- The surface that the air handler is mounted on must provide sound physical support of the unit.
- The air handler must be installed so that all electrical components are protected from water.
- If a louvered door is installed across the front of this unit, the appliance must be mounted flush or behind front edge of finished wall.
- Always reinstall the doors on the air handler after servicing or cleaning/changing the filters. **Do not operate the air handler without all doors and covers in place.**

Packaging Removal

Remove the shipping carton and User's Manual from the equipment. When removing the crate, use extra care so tubing connections are not damaged. Do not pull on the coils upper tubes.

Mounting Applications

Vertical only air handlers are factory ready for upflow applications. These units may be applied in downflow applications when applied with the appropriate field kit.

Factory ready horizontal air handlers may be applied in upflow or horizontal-left and -right discharge applications. These units may also be applied in downflow discharge when applied with the appropriate field kit as specified in the units Technical Specifications.

Through-the-floor installations require a 1/4" thick noncombustible resilient gasket to be used whenever the supply or return air ducts pass through the floor. The gasket should be positioned between the duct, unit, and floor.

Upflow Installations

All air handlers are factory shipped, ready for upflow installation. The horizontal drain pan may be removed from the air handler when installing the unit in an upflow configuration. All return air must enter from the bottom of the unit. A typical upflow unit is shown in Figure 1 (page 6).

Downflow Installations

The downflow accessory kit (See Technical Specifications) is required for downflow applications. Instructions for installing the downflow accessory kit are included with the kit. It is recommended that the accessory be installed prior to installing the unit. All return air in downflow applications must enter through the top of the unit. A typical installation of the unit in a downflow application is shown in Figure 2 (page 6).

Horizontal Installations

The B64 Series air handler can be installed horizontally in an attic, basement, crawl space or alcove. It can also be suspended from a ceiling in a basement or utility room in either a right to left airflow or left to right airflow as shown in Figure 3 (page 6). Air handlers may or may not be shipped from the factory with all the parts required for horizontal left applications and horizontal right applications. If your unit does not have parts for a horizontal application, a kit may be available.




Figure 1. Upflow Installation




Figure 2. Downflow Installation




Figure 3. Horizontal Configurations




Figure 4. Unit Horizontally Suspended

NOTE 1: In all horizontal applications in which the unit is installed above a finished ceiling and/or living space, a secondary drain pan must be installed under the entire unit to avoid damage to the ceiling in the event of condensate overflow. Additionally, it is recommended that an approved water level indicator or float switch device be used to shut down the unit in the event water is detected in the auxiliary drain pan.

NOTE 2: In horizontal right applications where the air handler is in a humid location in an unconditioned space, it is recommended to install a condensate shield kit over the control board.

If suspending the air handler from the ceiling, assemble a support frame (Figure 4) using slotted iron channel and full threaded rod. Fasten the frame together with nuts, washers, and lockwashers. Secure the support frame to the rafters with lag bolts. The air handler can also be suspended using steel straps around each end of the unit. The straps should be attached to the air handler with sheet metal screws and to the rafters with bolts.

Horizontal Left Installations:

1. Remove the coil access door.
2. Remove the plug from one of the threaded holes in the horizontal drain pan. Completely remove the webbing located in the threaded holes of the horizontal drain pan.

IMPORTANT: If the webbing is not removed, the condensate will not drain properly and ceiling damage may occur.

3. Insert the plug (from horizontal drain pan) into the open and unused drain hole in the drain pan at the bottom of the unit to block bypass air.
4. Remove the corresponding drain line knockout from the coil access door to allow access to the horizontal drain.
5. Replace the door and attach the drain line.

Horizontal Right Installations:

1. Remove the coil access door. Unscrew the line-set tube close-off plate from the front left cabinet rail.
2. Slide the coil and drain pan assembly out of the unit.
3. Remove the sheet metal hairpin covers (if supplied) from the back of the coil and discard.
4. Place the horizontal drain pan on the opposite side of the coil. On units with 2 sets of knockouts, remove the other set of knockouts in the coil spacing plates and insert support rod.
5. Slide the coil and the horizontal drain pan assembly back into the unit. Re-attach the tube close off plate.

NOTE: For A-size cabinet applications, it may be preferable to remove the blower assembly prior to installing the coil & drainpan. In this case follow instructions 1-4 as listed above but also remove the blower access door and blower assembly. The blower assembly is secured with two screws on either side near the front. With these removed the blower assembly can slide out of the front of the unit. Install the coil and drain pan as described in step 5 and then replace the blower assembly. Make sure the flanges on the sides of the blower assembly are captured by the pockets in the blower deck. It may be necessary to lift the blower assembly during insertion to allow the lower blower leg to clear the side of the drain pan. The blower will stop against the back of the blower deck. Replace the two screws and the blower access door and proceed with steps 6-9.

6. Remove the plug from one of the threaded holes in the horizontal drain pan. Completely remove the webbing located in the threaded holes of the drain pan.

IMPORTANT: If the webbing is not removed, the condensate will not drain properly and ceiling damage may occur.

NOTE: It is recommended that the suction line be insulated up to the coil inside of the cabinet.

7. Insert the plug (from horizontal drain pan) into the open and unused drain hole in the drain pan at the bottom of the unit to block bypass air.
8. Remove the corresponding drain line knockout from the coil access door to allow access to the horizontal drain.
9. Replace the door and attach the drain line.

Circuit Breaker Cover Installation

The air handler circuit breaker cover is designed to protect the breakers of an installed heater kit from debris and condensation. The cover attaches to the breaker recess of the air handler upper access door using a double-sided adhesive gasket. See Figure 5. The heater kit circuit breaker toggles are still accessible and can be switched with the cover in place.

There are 2 different circuit breaker cover sizes:


- 2-breaker cover for 2, 2.5, 3, 3.5, & 4 ton air handlers.
- 3-breaker cover for 5 ton air handlers.

After the heater kit is properly installed, remove the appropriate knockouts in the upper air handler access door and follow these instructions to install the breaker cover:

1. Clean any oil, dirt, or insulation fibers from the recess area of the air handler access door. This step is important for ensuring the gasket adheres properly to the sheet metal door.
2. Remove release paper from one side of the gasket and attach to back side of the breaker cover. **NOTE:** For proper alignment, It is recommended to leave the center section of the gasket in place when attaching the gasket to the breaker cover. Remove the center section after the gasket is applied to the breaker cover.
3. Remove the release paper from the other side of the gasket and attach to the circuit breaker recess area.
4. Press firmly along all four sides of the cover to ensure gasket and cover are securely attached to the access door.

Refrigerant Line Connections


WARNING:



| NITROGEN | |
|-------------------------------------|---|
| HEALTH | 1 |
| FLAMMABILITY | 0 |
| REACTIVITY | 0 |
| 0 Minimal Hazard 1 Slight Hazard | |

The coil in the air handler is factory shipped with a nitrogen charge. Avoid direct face exposure or contact with valve when gas is escaping. Always ensure adequate ventilation is present during the depressurization process. Address any uncertainties before proceeding. Failure to comply with this warning could result in equipment damage, personal injury, or death.




Figure 5. Circuit Breaker Cover

- The installer should make every effort to ensure the field installed refrigerant containing components of the system have been installed in accordance with these instructions and sound installation practices for reliable system operation and longevity.
- The air handler coil does not contain a refrigerant charge. Refer to the installation instructions supplied with the outdoor unit for refrigerant charge information.
- The refrigerant piping to each air handler (or coil) should be of equal length and size. Run the copper pipes from condensing unit to a point equidistant between the air handlers (or coils). Place a tee in the lines at this point. After the tee (as close to the air handler as practical), reduce the pipe size to match the piping of the air handler or coil.
- Always refer to the installation instructions supplied with the outdoor unit for piping requirements. The suction and liquid lines must be sized in accordance with the condensing unit specifications. See Figure 8 (page 14) for liquid and suction line locations.
- When connecting refrigerant linesets together, it is recommended that dry nitrogen be flowing through the joints during brazing. This will prevent internal oxidation and scaling from occurring.
- Refrigerant tubing should be routed in a manner that minimizes the length of tubing and the number of bends in the tubing. It should be supported in a manner that prevents it from vibrating or abrading during system operation. Tubing should be kept clean of foreign debris during installation.
- If precise forming of refrigerant lines is required, a copper tubing bender is recommended. Avoid sharp bends and contact of the refrigerant lines with metal surfaces.
- Refrigerant lines should be wrapped with pressure sensitive neoprene or other suitable material where they pass against sharp sheet metal edges.
- B64 Series air handlers are charged (with nitrogen) through service valves on the end of the liquid tube for each circuit. These must be removed before brazing the line sets.

Connecting the Linesets

IMPORTANT NOTES FOR HORIZONTAL OR DOWNFLOW INSTALLATIONS WITH TXV VALVE:

- The sensing bulb must be located flush against the suction line for optimum heat transfer.
- Avoid attaching the sensing bulb to the lowest part of the suction line where condensate may accumulate.
- Do not locate the sensing bulb on vertical sections of the lineset.
- For horizontal lines, the bulb should not be located at 12 or 6 o'clock position of the suction line. The best location is at 4 or 8 o'clock.
- For additional information on proper sensing bulb locations, please refer to the valve manufacturer's instructions.

1. Remove grommets from line set holes.

⚠ CAUTION:

It is recommended that a wet rag be wrapped around the suction line in front of the close off plate or the sensing bulb (if TXV is installed) before applying heat. Failure to keep components cool during brazing may result in structural damage, premature equipment failure, or possible personal injury.

2. Cut off the heat shrink and remove the plug from the suction line.
3. Route and cut both lineset tubes to proper length in accordance with the outdoor unit specifications. Verify the ends are round, clean, and free of any burrs.
4. Position grommet on line set with sufficient distance away from brazing area. Brazing processes can permanently damage grommets.
5. Connect the suction and liquid lineset tubes.

⚠ CAUTION:

It is recommended that a wet rag be wrapped around the suction line in front of the close off plate or the sensing bulb (if TXV is installed) before applying heat. Failure to keep components cool during brazing may result in structural damage, premature equipment failure, or possible personal injury.

6. Braze the individual connections with dry nitrogen flowing through the joints. **NOTE:** This will prevent internal oxidation and scaling from occurring.
7. Wrap the refrigerant lines with pressure sensitive neoprene or other suitable material especially where the lines enter the opening in the sheet metal.
8. Evacuate the system of moisture and non-condensables to prevent low efficiency operation or damage to the unit. The suggested range of evacuation is 350 - 500 microns.
9. Charge the system with refrigerant. Refer to the outdoor unit installation manual for additional charging instructions.
10. Check the system for leaks, including the lineset and the brazed joints.
11. Replace all grommets and properly dispose of all removed parts.

Condensate Drainage

⚠ CAUTION:

The air handler must be level to ensure proper condensate drainage. An unlevel installation may result in structural damage, premature equipment failure, or possible personal injury.

- Methods for disposing of condensate vary according to local codes. Refer to local codes or authority having jurisdiction for restrictions and proper condensate disposal requirements.
- The drain pan that is supplied with this air handler contains a primary and secondary drain fitting. The condensate is drained from the unit through two 3/4" female pipe fittings located on the front side of the unit as shown in Figure 6.
- The drain pan must be drained with field supplied tubing or pvc pipe and adequately trapped. Both drain tubes must have a minimum diameter of 3/4" and be trapped separately.

IMPORTANT: Failure to install a trap may result in condensation overflowing the drain pan, resulting in substantial water damage to surrounding area.

- Route both lines to a suitable drain, avoiding sharp bends and pinching of the lines. The drain should maintain a minimum horizontal slope in the direction of discharge of not less than 1" vertical for every 10 ft of horizontal run.
- If the air handler is located in or above a living space where damage may result from condensate overflow, an auxiliary drain pan shall be installed under the unit. A separate drain line should extend from the pan to a conspicuous point and serve as an alarm indicating that the primary drain is restricted. As an alternative to a separate drain line,




Figure 6. Condensate Drainage Example

- an approved water level indicator or float switch device may be used to shut down the unit in the event water is detected in the auxiliary pan.
- Install a single 5 inch trap in the condensate drain line as close to the coil as possible. Make sure that the top of the trap is below the bottom of the drain pan to prevent the condensate from overflowing the drain pan. NOTE: There must be only one trap in the drain line. Using more than one trap may prevent drainage.
 - Prime the trap with water. Insulate the drain if it is located in an unconditioned space, and test the condensate line for leaks. Consult local codes for additional restrictions or precautions.
 - During system checkout, inspect the drain line and connections to verify proper condensate drainage.

ELECTRICAL CONNECTIONS

WARNING:

ELECTRICAL SHOCK, FIRE OR EXPLOSION HAZARD

Failure to follow safety warnings exactly could result in serious injury or property damage.

Improper servicing could result in dangerous operation, serious injury, death or property damage.

Before servicing, disconnect all electrical power to furnace.

- **Before servicing, disconnect all electrical power to the air handler.**
- **When servicing controls, label all wires prior to disconnecting. Reconnect wires correctly.**
- **Verify proper operation after servicing.**

- Electrical connections must be in compliance with all applicable local codes and ordinances, and with the current revision of the National Electric Code (ANSI/NFPA 70).
- For Canadian installations, the electrical connections and grounding shall comply with the current Canadian Electrical Code (CSA C22.1 and/or local codes).

Pre-Electrical Checklist

- √ Verify the voltage, frequency, and phase of the supply source match the specifications on the unit rating plate.
- √ Verify that the service provided by the utility is sufficient to handle the additional load imposed by this equipment.
- √ Verify factory wiring is in accordance with the unit wiring diagram (Figure 16 (page 24) or Figure 17 (page 25)). Make sure the connections didn't loosen during shipping or installation.

Line Voltage

- **An electrical disconnect must be located within sight of and readily accessible to the unit.** This switch shall be capable of electrically de-energizing the outdoor unit. See unit data label for proper incoming field wiring. Any other wiring methods must be acceptable to authority having jurisdiction.
- It is recommended that the line voltage to the unit be supplied from a dedicated branch circuit containing the correct fuse or circuit breaker for the unit.

- Overcurrent protection must be provided at the branch circuit distribution panel and sized as shown on the unit rating label and according to applicable local codes. See the unit rating plate.
- The installer should become familiar with the wiring diagram/schematic before making any electrical connections to the unit. See the unit wiring label or Figure 16 (page 24) or Figure 17 (page 25).
- Use only copper wire for the line voltage power supply to this unit. Use proper code agency listed conduit and a conduit connector for connecting the supply wires to the unit. Aluminum supply wire may be used if a heater kit is installed.
- If replacing any of the original wires supplied with the unit, the replacement wire must be copper wire consisting of the same gauge and temperature rating.
- Provide power supply for the unit in accordance with the unit wiring diagram, and the unit rating plate. Use UL listed conduit and conduit connectors for connecting the supply wires to the unit and for proper grounding. Field supplied bushings for the power supply cables must be added to support and protect the power supply cables.
- All 208/230 Volt units are shipped from the factory wired for 240 volt operation. For 208V operation, remove the lead from the transformer terminal marked 240V and connect it to the terminal marked 208V.

Thermostat Connections

- Thermostat connections shall be in accordance with the instructions supplied with the thermostat. The thermostat used with this equipment must operate in conjunction with any installed accessories. Typical AC and air handler hookups are shown in Figure 10 (page 21).

CAUTION:

Isolation must be maintained from the external Class 2 output of any transformer in a cooling circuit. Use a thermostat with isolating contacts to prevent inter-connection of Class 2 outputs.

- Where local codes require that the thermostat wiring must be routed through a conduit or raceway, splices can be made inside the unit; however, all wiring must be NEC Class 1 and separated from incoming power leads.
- The thermostat should be mounted about 5 feet above the floor on an inside wall. DO NOT install the thermostat on an outside wall or any other location where its operation may be adversely affected by radiant heat from fireplaces, sunlight, or lighting fixtures, and convective heat from warm air registers or electrical appliances. Refer to the thermostat manufacturer's instruction sheet for detailed mounting and installation information.
- Install the grommet, which is packed with the unit, in the hole for low-voltage wires. Properly connect the low-voltage wiring between the thermostat, outdoor unit, and control board. **NOTE:** When the low voltage wires are positioned in this grommet, the grommet will prevent chafing and/or shorting of the low voltage leads.

Grounding

WARNING:

The unit cabinet must have an uninterrupted or unbroken electrical ground to minimize personal injury if an electrical fault should occur. Do not use gas piping as an electrical ground!

This unit must be electrically grounded in accordance with local codes or, in the absence of local codes, with the National Electrical Code (ANSI/NFPA 70) or the CSA C22.1 Electrical Code. Use the grounding lug provided in the control box for grounding the unit.

Control Board

The control board in the air handler controls the timing sequence of the elements. The board is equipped with a 3 second blower on delay and a 15 second blower off delay in heating and a 40 second blower off delay in cooling. See [Figure 12](#) or [Figure 13 \(page 22\)](#) and [Table 9, \(page 19 and 20\)](#) for control board modes and actions.

Twinning

These instructions are to be used when connecting two B64 air handlers (2-4 ton models) to a common single stage A/C condensing unit or heat pump. Twinning is possible for B64 units with PSC or fixed speed (FSHE) motors. Twinning is not possible for units with variable (VSHE) speed motors. All low voltage wiring instructions, cautions, and warnings accompanying the air handler remain applicable, except for:

Line & Low Voltage Connections

- The line voltage connections for both air handlers must be the same phase and on the same leg of power.
- Low voltage wiring should be connected as shown in [Figure 11 \(page 21\)](#).
- Wire all other low voltage thermostat terminals to both air handlers as shown in [Figure 10 \(page 21\)](#).

NOTE: If there is any other air moving device in the duct work, consult the factory for a resolution.

Heater Kits

When electric heat packages with circuit breakers are field-installed, the circuit breaker may be used as a disconnecting means in most applications. Reference the NEC and local codes for disconnect requirements.

If a heater kit is installed:

B64EM and B64VM air handlers are shipped from the factory without an electric heater kit installed. If electric heat is desired, a heater kit may be purchased separately and field installed. Determine the correct size heater kit for your unit by referring to the heater kit installation instructions.

- Connect the 2 wire plug of the air handler to the mating 2 wire plug of the heater kit.
- Connect the line voltage leads to the circuit breaker or terminal block provided.
- Connect the heater kit plug with the mating receptacle on the air handler control board.
- Refer to Heater Kit Installation Instructions to determine if you need to replace a limit or add an air baffle.
- Connect blue blower limit wires according to Heater Kit Installation Instructions and the corresponding Wiring Diagram.

If a heater kit is not installed:

- Remove the 2 wire plug of the air handler by cutting the wires and discarding the plug.
- Strip the ends of the 2 air handler wires and connect to the line-voltage leads with the 2 wire nuts provided.
- Certain air handler models are equipped with blower limits as shown in [Figure 15 \(page 23\)](#). These are left unconnected if a heater kit is not installed.

Humidifier

The unit has an output to power a humidifier when the blower is running. This output is rated to 1.0 amp at 208/240V.

Dehumidification Options

The motor control board has a **DHUM** or **D** connection that allows the system to increase the amount of humidity that is removed from the circulating air. See [Figure 14](#) & [Figure 15 \(page 23\)](#) This is accomplished by reducing the CFM and allowing the cooling coil to become colder. This will only occur when there is a call for cooling. There are many ways that this can be electrically wired.

- If the room thermostat incorporates a humidity sensor and **DHUM** output, connect the **DHUM** on the thermostat to the **D** terminal on the motor control board. See [Figure 7](#).
- If using a separate humidistat, connect the **DHUM** & **R** terminals on the humidistat to the **D** & **R** terminals on the motor control board of the air handler. In this option, the **DHUM** output of the humidistat must be set so it is only closed when there is a call for dehumidification.
- If a humidistat is not available, it is an acceptable option to connect the **R** & **D** terminals on the motor control board together with a field supplied wire. This option causes the blower to run at a reduced CFM for 10 minutes after a call for cooling. **NOTE:** If outdoor unit is a heat pump, connect the **O** terminal to the **D** terminal.




Figure 7. DHUM Wiring Configuration

Electronic Air Cleaner (EAC)

The unit has an output to power an electronic air cleaner when the blower is running. This output is rated to 1.0 amp at 208/240V. See [Figure 12 and 13 \(page 22\)](#) and [Figure 14 \(page 23\)](#).

STARTUP & ADJUSTMENTS

Before You Start the Unit

Prior to start-up, complete the following inspections:

- ✓ Verify the unit is level and properly located with adequate clearances for servicing the unit as shown in [Table 1, \(page 4\)](#).
- ✓ Check condensate drain line(s) for proper drainage.
- ✓ Verify the surrounding area and top of the unit is free from obstructions and debris.
- ✓ Check all duct connections. Make sure the duct work is adequately sealed to prevent air leakage.
- ✓ Check all coil connections for leaks.
- ✓ Verify that the line voltage power leads are securely connected and the unit is properly grounded. Make sure all doors are installed before restoring power to the unit

- √ Verify the thermostat is wired correctly. Make sure all low voltage wires are securely connected.
- √ Verify the power supply branch circuit overcurrent protection is sized properly.
- √ Verify filter is properly and securely installed.

IMPORTANT: Before starting the unit, install the initial charge on units that are factory shipped with a nitrogen holding charge:

1. Read all installation instructions first.
2. Purge the nitrogen holding charge.
3. Evacuate the unit to 350 - 500 microns.
4. Allow the unit to remain under vacuum for at least 30 minutes.
5. Weigh in the proper amount of new (or reclaimed) refrigerant. Refer to the air conditioner or heat pump installation manual for the proper type and quantity of refrigerant.

Air Circulation

Running the Blower Continuously

Set the thermostat's system mode to **OFF** and the thermostat's fan mode to **ON**. The blower motor should run continuously. Check for air delivery at the register(s). Ensure that there are no obstructions at the registers or in the ducts.

Selecting Continuous Low Speed Fan Operation (Standard Blower)

The air handler is equipped with an option of continuous low speed fan operation. When **G** is energized without **YY2**, the air handler will operate using the cooling speed. With **G & YY2** or **YY2** energized, the air handler will operate in the selected cooling speed (including 40 sec blower-off delay).

Turning the Blower Off

Set thermostat's fan mode to **AUTO**, the blower will shut down immediately.

System Cooling

1. Set the thermostat's system mode to **COOL** and fan mode to **AUTO**. Lower the thermostat's temperature mode below room temperature and observe that the blower energizes. Check the air being discharged at the register is cooler than room temperature. Verify unit refrigerant pressures are in order. Blower should be turning in direction indicated by arrow.

NOTE: DO NOT alter unit wiring. Listen for any unusual noises. Locate the source and correct as needed.

2. Allow the unit to run for several minutes and then set the thermostat's temperature above room temperature. Verify the blower cycles off with the thermostat.

System Heating

1. Set the thermostat's system mode to **HEAT** and the fan mode to **AUTO**. Increase the thermostat's temperature above room temperature and observe that the blower energizes. Check the air being discharged at the register is warmer than room temperature.
2. Allow the unit to run for several minutes and then set the thermostat's temperature below room temperature. Verify the blower cycles off with the thermostat.

Selecting Minimum Electric Heat Airflow

The minimum electric heat airflow setting controls the minimum air flow that will be produced whenever electric heater kits are used. When the electric heater kit is energized along with a heat pump, the airflow may be higher depending on the basic cooling/heat-pump airflow setting. The minimum electric heat airflow is selected by setting switches 1, 2, 3, &

4 on B64EM models. B64VM models automatically set the heating speed based on the amount of installed heat. The A/B switch must be set appropriately for the unit cabinet size. For C-sized cabinets, the A/B switch can be set in either position. The remaining 3 HEAT switches have no function. Switch settings are listed in [Table 6, \(page 16\)](#) or [Table 9, \(pages 19 and 20\)](#).

NOTES:

- For B64EM Models, the minimum electric heat airflow setting may be set higher, but must never be set lower than the setting shown in [Table 7, \(page 17\)](#).
- Variable speed motor control boards do not support non-electric heat because the heating air flow cannot be set independently.

Blower Configurations

Determining Nominal System Capacity

To select the appropriate airflows for the air handler, the nominal system capacity must be known. The nominal system capacity is always the nominal capacity of the outdoor unit. However, in some situations the nominal system capacity may not be the same as the nominal capacity of the air handler. Always refer to the nominal capacity of the outdoor unit to determine the nominal system capacity. Use [Tables 6 and 8, \(page 18\)](#) as a guide for acceptable airflow CFM (dependent on air handler cabinet size and nominal capacity of the outdoor unit).

NOTE: The CFM values listed in [Table 8, \(page 18\)](#) are not dependent on duct static pressure. The VSHE motor automatically compensates for changes in duct static pressure (within the limits of the motor).

High Efficiency Units (Variable & Fixed Speed)

IMPORTANT! This air handler has been designed to give the installer maximum flexibility to optimize system performance, efficiency, and comfort. Because there are so many different ways to set up the air handler it is important to read and follow these directions carefully.

B64EM & B64VM air handlers use high efficiency circulating air motors that come in two variations and both are controlled differently. The variable speed motor control board ([Figure 15](#)) controls the airflow at a constant CFM when paired with a separate control board. The fixed speed unit has a single integrated control board ([Figure 14 \(page 23\)](#)) that controls the torque of the motor.

Before operation, the air handler must be configured to match the unit with the system, system options, and climatic conditions. During normal operation, the motor will gradually change speeds during start-up, shut down, when thermostat inputs change, and when the duct static pressure changes (vents closed or opened, filter clogging, etc.). The air handler is configured by setting the selector switches and removing jumper connectors.

Basic Heating Airflow for Variable & Fixed Speed

Fixed & variable speed motor control boards ([Figure 14 & Figure 15 \(page 23\)](#)) contain a set of dip switches for setting the blower speed. For B64EM models, pins 1-4 set the speed for heating. For B64VM models, the A/B switch must be set for the appropriate cabinet size (either setting can be used for C-size cabinets). The airflow is set automatically based on the amount of installed heat. To determine the appropriate switch settings for your installation, see [Table 6, \(page 16\)](#), or [Table 8, \(page 18\)](#).

Basic Cooling / Heat Pump Airflow for Variable & Fixed Speed

The basic cooling/heat-pump airflow is controlled by setting switches 5 - 8 on the motor control board (mounted on the blower). All airflows for other modes of operation (except electric heat) are determined by this basic setting. FAN ONLY would deliver 50% of the selected cooling airflow. [Table 7, \(page 17\)](#) lists the CFM airflow values recommended for each nominal system capacity. To determine dip switch settings, refer to [Table 6, \(page 16\)](#) for FSHE applications and [Table 8, \(page 18\)](#) for VSHE applications.

- When operating in the heat pump mode, a higher basic airflow setting will increase the energy efficiency and capacity but will also decrease the supply air temperature.
- For maximum capacity and energy efficiency, select an airflow at or near the top of the range for that nominal capacity. See [Table 8, \(page 18\)](#).
- For maximum dehumidification, select an airflow near the middle or bottom of the range for that nominal capacity. Additional information on humidity control can be found in the Dehumidification Options section on [page 10](#).
- For thermostats with a dehumidifier output, use a field supplied wire to connect the thermostat's dehumidifier output to the terminal marked **DHUM**. The thermostat should be set so that the **DHUM** output should be high (energized) when dehumidification is needed. See also Dehumidification Options section.

IMPORTANT! If coil icing is observed, the basic cooling/heat-pump airflow selected may be too low. Verify the setting selected is within the range shown in [Table 8 \(page 18\)](#) and that the system is properly charged. Please refer to the instructions supplied with the outdoor unit. If icing continues to occur, raise the selected airflow one or two steps.

NOTE: Variable speed air handlers with SEER ratings higher than 15 are matched with a 2-stage cooling outdoor unit. They are programmed to operate at 75% of the selected airflow while the system is in the lo-cool mode and 100% of the selected airflow while in hi-cool mode.

Units with an FSHE control scheme (B64EM) have a control board that includes a 7 segment display to help the installer identify what mode the air handler is running in as well as troubleshooting if the unit is not functioning properly. [Table 2](#), contains a list of the codes that may appear on the 7 segment display. The display code will only show what mode the air handler is currently in. There is not a history of fault codes that have occurred in previous operation.

TROUBLESHOOTING

If the air handler fails to operate, check the following:

- Is the electric turned on?
- Is the thermostat operating properly?
- Are the blower compartment door(s) in place?
- Is the air handler disconnect closed?
- Has the circuit breaker tripped or the control board fuse burned open?
- Are any manual reset switches open?
- Is the filter dirty or plugged?
- Is the LED on both control boards constantly ON? If not, refer to [Table 3](#) or [Table 4](#) to determine fault condition.

| DISPLAY CODE | CURRENT MODE |
|--------------|---|
| - | Standby is a Rotating Segment |
| ⌋ | Cooling Mode (Y input active) |
| H | Heating Mode (W input active) |
| F | Circulate Fan Mode (G input active) |
| d | Dehum Cooling Mode (DEHUM input active along with Y) |
| i | (one) A Motor Fault has Occurred (BMF active for more than 30 seconds) |
| t | (lower case t) Over Temperatures (The value of the TS input has exceeded 80C all outputs are stopped.) |
| L | Lockout (Ten (10) or more Motor Faults or Over Temperature events have occurred. All outputs are set to off for one hour. |

Table 2. FSHE Motor Control Board Display Codes

| RED LED (AN2) | DIAGNOSTIC |
|---------------|--------------------------|
| OFF | Control Fault (No Power) |
| Flash | Blower Fault |
| ON | Normal Operation |

Table 3. Air Handler Control Board Fault Conditions

| DIAGNOSTIC FAULT CONDITIONS FOR VARIABLE SPEED FURNACES | GREEN LED | RED LED |
|---|-----------|---------|
| Control Fault (No Power) | Off | Off |
| Normal Operation | On | On |
| Motor Fault | On | Flash |
| Communications Fault | Flash | Flash |

Table 4. VSHE Motor Control Board Display Codes

UNIT MAINTENANCE

Proper maintenance is most important to achieve the best performance from a air handler. Some of the components and their locations are shown in [Figure 9 \(page 15\)](#). If any component of the air handler must be replaced, use only factory authorized replacement parts specified in the Replacement Parts List provided online.

WARNING:

ELECTRICAL SHOCK, FIRE OR EXPLOSION HAZARD

Failure to follow safety warnings exactly could result in serious injury or property damage.

Improper servicing could result in dangerous operation, serious injury, death or property damage.

- **Before servicing, disconnect all electrical power to the indoor blower.**
- **When servicing controls, label all wires prior to disconnecting. Reconnect wires correctly.**
- **Verify proper operation after servicing.**

- These maintenance instructions are primarily intended to assist qualified technicians experienced in the proper maintenance and operation of this appliance.
- Always reinstall the doors on the air handler after servicing or cleaning/changing the filters. **Do not operate the air handler without all doors and covers in place.**

- Verify that the thermostat is properly installed and is not being affected by drafts or heat from lamps or other appliances.
- To achieve the best performance and minimize equipment failure, it is recommended that a yearly maintenance checkup be performed. At a minimum, this check should include the following items:

Air Filter(s) - B64 Series Air Handlers are not supplied with an air filter when shipped from the factory. It is recommended that the filter be cleaned or replaced every 4 to 6 months at a minimum. Newly built or recently renovated homes may require more frequent changing until the construction dust has minimized. Filter sizes shown in [Table 5](#) are available at most local retailers.

! WARNING:

Never operate the air handler without a filter in place. Dust and lint in the return air can build up on internal components, resulting in loss of efficiency, equipment damage, and possible fire.

Filters designed to remove smaller particles such as pollen, may require additional maintenance.

Blower Compartment - Dirt and lint can create excessive loads on the motor resulting in higher than normal operating temperatures and shortened service life. It is recommended that the blower compartment be cleaned of dirt or lint that may have accumulated in the compartment or on the blower and motor as part of the annual inspection.

| CABINET SIZE | FILTER SIZE |
|--------------|-------------|
| A | 12 x 20 x 1 |
| B | 18 x 20 x 1 |
| C | 20 x 20 x 1 |


Table 5. Filter Sizes

Blower Fan Wheel - Inspect the blower wheel blades for accumulations of dirt and clean if necessary. Inspect mounting nut for tightness when done.

Blower Motor & Assembly - Inspect the blower assembly and motor mounting brackets for tightness and corrosion. Correct deficiencies if necessary. The blower motor contains sealed bearings and under normal operating conditions, no maintenance is necessary for the life of the equipment.

REFRIGERANT CHARGING

! WARNING:



| NITROGEN | |
|-------------------------------------|---|
| HEALTH | 1 |
| FLAMMABILITY | 0 |
| REACTIVITY | 0 |
| 0 Minimal Hazard 1 Slight Hazard | |

The evaporator coil is shipped from the factory with a nitrogen charge. Use caution when preparing coils for field connections. If repairs make it necessary for evacuation and charging, it should only be attempted by qualified, trained personnel thoroughly familiar with this equipment. Some local codes require licensed installation service personnel to service this type of equipment. Under no circumstances should the equipment owner attempt to install and/or service this equipment. Failure to comply with this warning could result in equipment damage, personal injury, or death.

The system refrigerant charge can be checked and adjusted through the service ports provided at the front panel of the outdoor unit. Use only gauge lines which have a Schrader depression device present to actuate the valve.

FIGURES & TABLES




Figure 8. B64 Series Physical Dimensions




Figure 9. Air Handler Components

Airflow Data

| | SWITCH SETTINGS 0 = OFF, 1 = ON | | | | COOLING OR HEATING AIRFLOW (CFM) | | | | | | | |
|----------------------------|------------------------------------|-----|-----|------|----------------------------------|------|------|------|------|------|------|------|
| | | | | | DRY COIL ESP | | | | | | | |
| | 1/5 | 2/6 | 3/7 | 4/8 | 0.1 | 0.2 | 0.3 | 0.4 | 0.5 | 0.6 | 0.7 | 0.8 |
| B64EM A-CABINET | 0 | 0 | 0 | 0 | 585 | 550 | 520 | 460 | 420 | 405 | — | — |
| | 1 | 0 | 0 | 0 | 710 | 670 | 650 | 610 | 560 | 530 | 475 | 440 |
| | 0 | 1 | 0 | 0 | 845 | 790 | 765 | 715 | 680 | 655 | 625 | 580 |
| | 1 | 1 | 0 | 0 | 890 | 865 | 840 | 785 | 760 | 710 | 680 | 655 |
| | 0 | 0 | 1 | 0 | 955 | 925 | 900 | 850 | 825 | 790 | 770 | 720 |
| | 1 | 0 | 1 | 0 | 1030 | 995 | 975 | 940 | 910 | 870 | 840 | 815 |
| | 0 | 1 | 1 | 0 | 1115 | 1085 | 1060 | 1020 | 995 | 965 | 925 | 905 |
| | 1 | 1 | 1 | 0 | 1155 | 1130 | 1095 | 1070 | 1040 | 1010 | 985 | 950 |
| | 0 | 0 | 0 | 1 | 1200 | 1175 | 1145 | 1110 | 1085 | 1060 | 1025 | 1000 |
| | 1 | 0 | 0 | 1 | 1240 | 1215 | 1195 | 1170 | 1140 | 1110 | 1080 | 1060 |
| | 0 | 1 | 0 | 1 | 1320 | 1290 | 1265 | 1240 | 1215 | 1185 | 1160 | 1130 |
| | 1 | 1 | 0 | 1 | 1355 | 1330 | 1305 | 1280 | 1255 | 1220 | 1200 | 1175 |
| | 0 | 0 | 1 | 1 | 1405 | 1375 | 1345 | 1325 | 1295 | 1275 | 1250 | 1210 |
| | 1 | 0 | 1 | 1 | 1440 | 1415 | 1385 | 1355 | 1325 | 1290 | 1255 | 1215 |
| | 0 | 1 | 1 | 1 | 1465 | 1425 | 1390 | 1355 | 1320 | 1290 | 1260 | 1215 |
| 1 | 1 | 1 | 1 | 1465 | 1425 | 1390 | 1355 | 1320 | 1290 | 1260 | 1215 | |
| B64EM B-CABINET | 0 | 0 | 0 | 0 | 600 | 550 | 430 | 390 | — | — | — | — |
| | 1 | 0 | 0 | 0 | 660 | 610 | 540 | 460 | 425 | — | — | — |
| | 0 | 1 | 0 | 0 | 830 | 750 | 695 | 640 | 580 | 520 | — | — |
| | 1 | 1 | 0 | 0 | 860 | 825 | 765 | 690 | 630 | 600 | 525 | 485 |
| | 0 | 0 | 1 | 0 | 935 | 895 | 835 | 790 | 710 | 655 | 620 | 585 |
| | 1 | 0 | 1 | 0 | 1045 | 975 | 920 | 875 | 830 | 795 | 720 | 685 |
| | 0 | 1 | 1 | 0 | 1095 | 1040 | 995 | 950 | 900 | 850 | 805 | 750 |
| | 1 | 1 | 1 | 0 | 1155 | 1105 | 1060 | 1010 | 965 | 920 | 870 | 825 |
| | 0 | 0 | 0 | 1 | 1230 | 1185 | 1140 | 1090 | 1045 | 1010 | 965 | 920 |
| | 1 | 0 | 0 | 1 | 1285 | 1260 | 1210 | 1165 | 1125 | 1080 | 1040 | 1010 |
| | 0 | 1 | 0 | 1 | 1330 | 1290 | 1245 | 1205 | 1170 | 1125 | 1085 | 1045 |
| | 1 | 1 | 0 | 1 | 1395 | 1365 | 1315 | 1275 | 1235 | 1205 | 1160 | 1130 |
| | 0 | 0 | 1 | 1 | 1450 | 1405 | 1375 | 1335 | 1295 | 1260 | 1220 | 1180 |
| | 1 | 0 | 1 | 1 | 1490 | 1450 | 1410 | 1385 | 1340 | 1300 | 1270 | 1230 |
| | 0 | 1 | 1 | 1 | 1530 | 1485 | 1460 | 1425 | 1380 | 1350 | 1310 | 1280 |
| 1 | 1 | 1 | 1 | 1530 | 1490 | 1465 | 1425 | 1390 | 1350 | 1310 | 1285 | |
| B64EM C-CABINET | 0 | 0 | 0 | 0 | 720 | 610 | 510 | 420 | 335 | -- | -- | -- |
| | 1 | 0 | 0 | 0 | 880 | 780 | 685 | 595 | 505 | 425 | -- | -- |
| | 0 | 1 | 0 | 0 | 1035 | 940 | 850 | 765 | 690 | 620 | 560 | -- |
| | 1 | 1 | 0 | 0 | 1130 | 1050 | 975 | 900 | 830 | 760 | 695 | 630 |
| | 0 | 0 | 1 | 0 | 1275 | 1195 | 1120 | 1050 | 985 | 920 | 865 | 815 |
| | 1 | 0 | 1 | 0 | 1365 | 1295 | 1230 | 1165 | 1100 | 1035 | 975 | 915 |
| | 0 | 1 | 1 | 0 | 1490 | 1425 | 1360 | 1300 | 1240 | 1185 | 1130 | 1075 |
| | 1 | 1 | 1 | 0 | 1580 | 1525 | 1465 | 1410 | 1355 | 1300 | 1245 | 1190 |
| | 0 | 0 | 0 | 1 | 1685 | 1630 | 1575 | 1520 | 1465 | 1410 | 1355 | 1300 |
| | 1 | 0 | 0 | 1 | 1750 | 1695 | 1640 | 1585 | 1535 | 1480 | 1430 | 1375 |
| | 0 | 1 | 0 | 1 | 1840 | 1785 | 1730 | 1680 | 1625 | 1575 | 1530 | 1480 |
| | 1 | 1 | 0 | 1 | 1895 | 1850 | 1800 | 1750 | 1700 | 1650 | 1595 | 1540 |
| | 0 | 0 | 1 | 1 | 1980 | 1930 | 1880 | 1830 | 1780 | 1735 | 1685 | 1640 |
| | 1 | 0 | 1 | 1 | 2045 | 1995 | 1945 | 1895 | 1845 | 1795 | 1750 | 1700 |
| | 0 | 1 | 1 | 1 | 2095 | 2045 | 1995 | 1945 | 1895 | 1845 | 1800 | 1755 |
| 1 | 1 | 1 | 1 | 2170 | 2120 | 2070 | 2020 | 1970 | 1925 | 1875 | 1830 | |

Table 6. B64EM (FSHE) Airflow Data

| A-CABINET | | B-CABINET | | C-CABINET | | |
|-----------|------------------|-----------|------------------|-----------|------------------|-------|
| CFM | NOMINAL CAPACITY | CFM | NOMINAL CAPACITY | CFM | NOMICAL CAPACITY | |
| 525 | 1.5 TON | 525 | 1.5 TON | 1100 | 3 TON | |
| 560 | | 560 | | 1200 | | |
| 600 | | 600 | | 1250 | 3.5 TON | |
| 625 | | 650 | | 1300 | | |
| 700 | | 700 | | 1350 | | 4 TON |
| 750 | 750 | 1400 | | | | |
| 800 | 2 TON | 800 | 2 TON | 1450 | 5 TON | |
| 850 | 2.5 TON | 850 | 2.5 TON | 1500 | | |
| 875 | | 875 | | 875 | | 1550 |
| 890 | | 950 | | 950 | | 1600 |
| 930 | | 1050 | | 1050 | | 1650 |
| 950 | | 1150 | | 1150 | 1700 | |
| 1000 | 3 TON | 1250 | 3 TON | 1750 | | |
| 1050 | | 1350 | | 1350 | 1800 | |
| 1125 | | 1400 | | 1400 | 1900 | |
| 1200 | | 1600 | | 1600 | 2000 | |
| | | | | | 4 TON | |

Table 7. Recommended Cooling Airflow Settings

| B64VM A-CABINET | COOLING AIRFLOW | | | | | |
|--------------------|---------------------------------------|--|---|---|------|------------------|
| | A/B SWITCH SETTING 0 = OFF, 1 = ON | COOL SWITCH SETTING 0 = OFF, 1 = ON | | | | AIRFLOW (CFM) |
| | | 5 | 6 | 7 | 8 | |
| 0 | 0 | 0 | 0 | 0 | 525 | |
| 0 | 0 | 0 | 0 | 1 | 560 | |
| 0 | 0 | 0 | 1 | 0 | 600 | |
| 0 | 0 | 0 | 1 | 1 | 625 | |
| 0 | 0 | 1 | 0 | 0 | 700 | |
| 0 | 0 | 1 | 0 | 1 | 750 | |
| 0 | 0 | 1 | 1 | 0 | 800 | |
| 0 | 0 | 1 | 1 | 1 | 850 | |
| 0 | 1 | 0 | 0 | 0 | 875 | |
| 0 | 1 | 0 | 0 | 1 | 890 | |
| 0 | 1 | 0 | 1 | 0 | 930 | |
| 0 | 1 | 0 | 1 | 1 | 950 | |
| 0 | 1 | 1 | 0 | 0 | 1000 | |
| 0 | 1 | 1 | 0 | 1 | 1050 | |
| 0 | 1 | 1 | 1 | 0 | 1125 | |
| 0 | 1 | 1 | 1 | 1 | 1200 | |

| HEATING AIRFLOW | | |
|---------------------------------------|---------------------------------|------------------|
| A/B SWITCH SETTING 0 = OFF, 1 = ON | HEATER KIT INSTALLED (KW) | AIRFLOW (CFM) |
| 0 | 0 | 600 |
| 0 | 5 | 800 |
| 0 | 8 | 1000 |
| 0 | 10 | 1000 |
| 0 | 15 | 1300 |
| 0 | 20 | n/a |
| 0 | 25 | n/a |

| B64VM B-CABINET | COOLING AIRFLOW | | | | | |
|--------------------|---------------------------------------|--|---|---|------|------------------|
| | A/B SWITCH SETTING 0 = OFF, 1 = ON | COOL SWITCH SETTING 0 = OFF, 1 = ON | | | | AIRFLOW (CFM) |
| | | 5 | 6 | 7 | 8 | |
| 1 | 0 | 0 | 0 | 0 | 525 | |
| 1 | 0 | 0 | 0 | 1 | 560 | |
| 1 | 0 | 0 | 1 | 0 | 600 | |
| 1 | 0 | 0 | 1 | 1 | 650 | |
| 1 | 0 | 1 | 0 | 0 | 700 | |
| 1 | 0 | 1 | 0 | 1 | 750 | |
| 1 | 0 | 1 | 1 | 0 | 800 | |
| 1 | 0 | 1 | 1 | 1 | 850 | |
| 1 | 1 | 0 | 0 | 0 | 875 | |
| 1 | 1 | 0 | 0 | 1 | 950 | |
| 1 | 1 | 0 | 1 | 0 | 1050 | |
| 1 | 1 | 0 | 1 | 1 | 1150 | |
| 1 | 1 | 1 | 0 | 0 | 1250 | |
| 1 | 1 | 1 | 0 | 1 | 1350 | |
| 1 | 1 | 1 | 1 | 0 | 1400 | |
| 1 | 1 | 1 | 1 | 1 | 1600 | |

| HEATING AIRFLOW | | |
|---------------------------------------|---------------------------------|------------------|
| A/B SWITCH SETTING 0 = OFF, 1 = ON | HEATER KIT INSTALLED (KW) | AIRFLOW (CFM) |
| 1 | 0 | 700 |
| 1 | 5 | 900 |
| 1 | 8 | 1100 |
| 1 | 10 | 1100 |
| 1 | 15 | 1300 |
| 1 | 20 | 1500 |
| 1 | 25 | n/a |

| B64VM C-CABINET | COOLING AIRFLOW | | | | | |
|--------------------|---|--|---|---|------|------------------|
| | A/B SWITCH SETTING (* = EITHER 0 OR 1) | COOL SWITCH SETTING 0 = OFF, 1 = ON | | | | AIRFLOW (CFM) |
| | | 5 | 6 | 7 | 8 | |
| * | 0 | 0 | 0 | 0 | 1100 | |
| * | 0 | 0 | 0 | 1 | 1200 | |
| * | 0 | 0 | 1 | 0 | 1250 | |
| * | 0 | 0 | 1 | 1 | 1300 | |
| * | 0 | 1 | 0 | 0 | 1350 | |
| * | 0 | 1 | 0 | 1 | 1400 | |
| * | 0 | 1 | 1 | 0 | 1450 | |
| * | 0 | 1 | 1 | 1 | 1500 | |
| * | 1 | 0 | 0 | 0 | 1550 | |
| * | 1 | 0 | 0 | 1 | 1600 | |
| * | 1 | 0 | 1 | 0 | 1650 | |
| * | 1 | 0 | 1 | 1 | 1700 | |
| * | 1 | 1 | 0 | 0 | 1750 | |
| * | 1 | 1 | 0 | 1 | 1800 | |
| * | 1 | 1 | 1 | 0 | 1900 | |
| * | 1 | 1 | 1 | 1 | 2000 | |

| HEATING AIRFLOW | | |
|---|---------------------------------|------------------|
| A/B SWITCH SETTING (* = EITHER 0 OR 1) | HEATER KIT INSTALLED (KW) | AIRFLOW (CFM) |
| * | 0 | 800 |
| * | 5 | 1000 |
| * | 8 | 1200 |
| * | 10 | 1200 |
| * | 15 | 1400 |
| * | 20 | 1600 |
| * | 25 | 1800 |

NOTES:

- Airflow values listed are for 240V operation. For 208V operation, multiply A & B cabinet values by .95; for C-cabinet values multiply by .90
- When matched with two-stage outdoor units the airflow on low (Y1 or W1) input only will be 70% of the values shown in this table.

Table 8. B64VM (VSHE) Airflow Data

Electrical Data & Diagrams

| CONTROL SIGNAL & MODE | OPERATION | TOTAL KW | BOARD ACTION | |
|-----------------------|------------------|-------------|---|---|
| W1 ONLY EHEAT | ON | 5 KW | Stage 1 Heat on instantly Heat blower on after 3 second delay | |
| | | 8 KW, 10 KW | Stage 1 Heat on instantly Heat blower on after 3 second delay | |
| | | 15 KW | Stage 1 Heat on instantly Heat blower on after 3 second delay Stage 2 Heat on after 5 second delay | |
| | | 20 KW | Stage 1 Heat on instantly Heat blower on after 3 second delay Stage 2 Heat on after 5 second delay Stage 3 Heat on after 10 second delay | |
| | | 25 KW | Stage 1 Heat on instantly Heat blower on after 3 second delay Stage 2 Heat on after 5 second delay Stage 3 Heat on after 10 second delay | |
| | OFF | — | Heat stages off instantly Blower off after 15 second delay | |
| | W1 & W2 EHEAT | ON | 5 KW | Stage 1 Heat on instantly Heat blower on after 3 second delay |
| | | | 8 KW, 10 KW | Stage 1 Heat on instantly Heat blower on after 3 second delay Stage 2 Heat on after 5 seconds delay |
| | | | 15 KW | Stage 1 Heat on instantly Heat blower on after 3 second delay Stage 2 Heat on after 5 seconds delay Stage 3 Heat on after 10 seconds delay |
| | | | 20 KW | Stage 1 Heat on instantly Heat blower on after 3 second delay Stage 2 Heat on after 5 seconds delay Stage 3 Heat on after 10 seconds delay Stage 4 Heat on after 15 seconds delay |
| | | | 25 KW | Stage 1 Heat on instantly Heat blower on after 3 second delay Stage 2 Heat on after 5 seconds delay Stage 3 Heat on after 10 seconds delay Stage 4 Heat on after 15 seconds delay Stage 5 Heat on after 20 seconds delay |
| OFF | | — | Heat stages off instantly Blower off after 15 second delay | |

Table 9. Control Board Operation

| CONTROL SIGNAL & MODE | OPERATION | TOTAL KW | BOARD ACTION |
|---------------------------------------|---------------------------------------|--|--|
| W1 & Y/Y2 AUX HEAT | ON | 5 KW | Stage 1 Heat on instantly |
| | | | Cool blower on after 3 second delay |
| | | 8 KW, 10 KW | Stage 1 Heat on instantly |
| | | | Cool blower on after 3 second delay |
| | | 15 KW | Stage 1 Heat on instantly |
| | | | Cool blower on after 3 second delay |
| | | | Stage 2 Heat on after 5 seconds delay |
| | | 20 KW | Stage 1 Heat on instantly |
| | Cool blower on after 3 second delay | | |
| | Stage 2 Heat on after 5 seconds delay | | |
| 25 KW | Stage 1 Heat on instantly | | |
| | Cool blower on after 3 second delay | | |
| | Stage 2 Heat on after 5 seconds delay | | |
| OFF | — | Stage 3 Heat on after 10 seconds delay | |
| | | Heat stages off instantly Heat blower turns off after 40 second delay | |
| W1, W2 & Y/Y2 AUX HEAT | ON | 5 KW | Stage 1 Heat on instantly |
| | | | Cool blower on after 3 second delay |
| | | 8 KW, 10 KW | Stage 1 Heat on instantly |
| | | | Cool blower on after 3 second delay |
| | | | Stage 2 Heat on after 5 seconds delay |
| | | 15 KW | Stage 1 Heat on instantly |
| | | | Cool blower on after 3 second delay |
| | | | Stage 2 Heat on after 5 seconds delay |
| | | 20 KW | Stage 3 Heat on after 30 seconds delay |
| | | | Stage 1 Heat on instantly |
| | | | Cool blower on after 3 second delay |
| | | | Stage 2 Heat on after 5 seconds delay |
| | | 25 KW | Stage 3 Heat on after 10 seconds delay |
| | | | Stage 4 Heat on after 15 seconds delay |
| | Stage 1 Heat on instantly | | |
| | Cool blower on after 3 second delay | | |
| Stage 2 Heat on after 5 seconds delay | | | |
| OFF | — | Stage 3 Heat on after 10 seconds delay | |
| | | Stage 4 Heat on after 15 seconds delay Stage 5 Heat on after 20 seconds delay Heat stages off instantly Heat blower turns off after 40 second delay | |
| G FAN | ON | — | Fan blower on after 3 second delay |
| | OFF | — | Fan blower off instantly |
| Y/Y2 HEAT PUMP & COOL | ON | — | Cool blower on after 3 second delay |
| | OFF | — | Cool blower off after 40 second delay |
| Y1 HEAT PUMP & COOL | ON | — | Cool blower on after 3 second delay |
| | OFF | — | Cool blower off after 40 second delay |
| Y1 & Y/Y2 HEAT PUMP & COOL | ON | — | Cool blower on after 3 second delay |
| | OFF | — | Cool blower off after 40 second delay |

Table 9. Control Board Operation - Continued





Figure 10. Typical Thermostat Connections




Figure 11. Low Voltage Wiring For Twinning




Figure 12. Single Stage Control Board




Figure 13. Two - Stage Control Board




Figure 14. Fixed Speed Motor Control Board




Figure 15. Variable Speed Motor Control Board

WIRING DIAGRAM


Air Handler with Fixed Speed High Efficiency Motor

NOTES:

1. The blower motor speed tap connection may not be as shown. See the Installation Instructions.
2. Disconnect all power before servicing.
3. Transformer may have a dual voltage primary tap. Match the tap position with the supply voltage used.
4. If the internal wiring is replaced, use only 105°C copper wire of the same gauge.

Remarques

1. Le connecteur de vitesse du moteur du ventilateur peut différer de l'illustration. Consultez les instructions d'installation.
2. Débranchez toutes les sources d'alimentation avant l'entretien.
3. Le transformateur peut avoir un robinet principal à double tension. Agencez la position du robinet au type de tension de l'installation.
4. Si le câblage interne est remplacé, utilisez seulement un fil de cuivre 105° C du même gabarit.



10436940

07/22

Figure 16. B64EM Wiring Diagram

WIRING DIAGRAM

Air Handler with Variable Speed High Efficiency Motor

NOTES:

1. The blower motor speed tap connection may not be as shown. See the Installation Instructions.
2. Disconnect all power before servicing.
3. Transformer may have a dual voltage primary tap. Match the tap position with the supply voltage used.
4. If the internal wiring is replaced, use only 105°C copper wire of the same gauge.

Remarques

1. Le connecteur de vitesse du moteur du ventilateur peut différer de l'illustration. Consultez les Instructions d'installation.
2. Débranchez toutes les sources d'alimentation avant l'entretien.
3. Le transformateur peut avoir un robinet principal à double tension. Agencez la position du robinet au type de tension de l'installation.
4. Si le câblage interne est remplacé, utilisez seulement un fil de cuivre 105° C du même gabarit.




Figure 17. B64VM Wiring Diagram

INSTALLATION CHECKLIST

ATTENTION INSTALLERS:

It is your responsibility to know this product better than your customer. This includes being able to install the product according to strict safety guidelines and instructing the customer on how to operate and maintain the equipment for the life of the product. Safety should always be the deciding factor when installing this product and using common sense plays an important role as well. Pay attention to all safety warnings and any other special notes highlighted in the manual. Improper installation of the furnace or failure to follow safety warnings could result in serious injury, death, or property damage.

These instructions are primarily intended to assist qualified individuals experienced in the proper installation of this appliance. Some local codes require licensed installation/service personnel for this type of equipment. Please read all instructions carefully before starting the installation. Return these instructions to the customer's package for future reference.

ELECTRICAL SYSTEM

| | | |
|--|-----|----|
| Electrical connections tight? | YES | NO |
| Line voltage polarity correct? | YES | NO |
| Supply Voltage: _____ (V) | | |
| Has the thermostat been calibrated? | YES | NO |
| Is the thermostat level? | YES | NO |
| Is the heat anticipator setting correct? | YES | NO |

INSTALLER NAME:

| | |
|-------|--------|
| CITY: | STATE: |
|-------|--------|

INSTALLATION ADDRESS:

| | |
|-------|--------|
| CITY: | STATE: |
|-------|--------|

UNIT MODEL #

UNIT SERIAL #

| | | |
|--|-----|----|
| Minimum clearances per Table 1, (page 4) ? | YES | NO |
| Is the unit properly installed and leveled? | YES | NO |
| Does condensate drain properly in both drain tubes? | YES | NO |
| Has the owner's information been reviewed with the home-owner? | YES | NO |
| Has the literature package been left near the appliance? | YES | NO |

