

B6BV Series

INSTALLATION INSTRUCTIONS

AIR HANDLER



For HUD approved installations in manufactured homes and modular homes

IMPORTANT

ATTENTION INSTALLERS:

It is your responsibility to know this product better than your customer. This includes being able to install the product according to strict safety guidelines and instructing the customer on how to operate and maintain the equipment for the life of the product. Safety should always be the deciding factor when installing this product and using common sense plays an important role as well. Pay attention to all safety warnings and any other special notes highlighted in the manual. Improper installation of the furnace or failure to follow safety warnings could result in serious injury, death, or property damage.

Please read all instructions carefully before starting the installation. These instructions are primarily intended to assist qualified individuals experienced in the proper installation of this appliance. Some local codes require licensed installation / service personnel for this type of equipment. If a problem occurs, check the instructions and follow recommendations given. If these suggestions don't eliminate your problem, call your servicing contractor. Return this manual to the customer's package for future reference.

DO NOT DESTROY. PLEASE READ CAREFULLY & KEEP IN A SAFE PLACE FOR FUTURE REFERENCE.

TABLE OF CONTENTS

IMPORTANT SAFETY INFORMATION	3	STARTUP & ADJUSTMENTS	9
GENERAL INFORMATION	3	Before You Start the Unit	9
Requirements & Codes	3	Air Circulation Check	9
About the Air Handler	3	Running the Blower Continuously	9
Mounting Applications	3	System Cooling	9
Before You Install this Appliance	4	System Heating	9
Locating the Air Handler	4	Turning the Blower Off	10
Minimum Clearances	4	Blower Configurations	10
CIRCULATING AIR SUPPLY	4	Determining Nominal System Capacity	10
Return Air Connections	5	Selecting Continuous Low Spd Fan Operation	10
Supply Air Connections	5	Proper Blower Speed for Multi Speed Units	10
Unconditioned Spaces	5	High Efficiency Units (Var. & Fixed Speed)	10
Acoustical Duct Work	5	Selecting Basic Heating Airflow	10
Air Filters	5	Selecting Basic Cooling/Heat Pump Airflow	10
Ventilaire III or IV Air Quality Package	6	Dehumidification Options	11
AIR HANDLER INSTALLATION	6	UNIT MAINTENANCE	11
Upflow Installations	6	TROUBLESHOOTING	12
Downflow Installations	6	FIGURES & TABLES	13
Plenum Connector Installation	6	Figure 9. B6BV Physical Dimensions	13
A/C or H/P Coil Installation	7	Airflow Data	14
ELECTRICAL CONNECTIONS	8	Table 6. B6BV Airflow Settings	14
Pre-Electrical Checklist	8	Table 7a. B6BV Airflow Data (B-Cabinet)	14
Line Voltage	8	Table 7b. B6BV Airflow Data (C-Cabinet)	14
Single Circuit Adaptor Kit	8	Electrical Diagrams & Data	15
Dual Supply Circuits	8	Table 8. B6BV MCA & MOP Data	15
Control Board	8	Figure 10. Typical T-Stat Connections	15
Twinning	8	Figure 11. Single Stage Control Board	16
Thermostat Connections	9	Figure 12. Two-Stage Control Board	16
Grounding	9	Figure 13. Two-Stage Fix. Sp. Control Board	17
		Table 9. B6BV Heat Element Logic	17
		Figure 14. W.D., PSC Mtr, 10Kw, B-Cabinet	20
		Figure 15. W.D., PSC Mtr, 15Kw, B-Cabinet	21
		Figure 16. W.D., FSHE Mtr, 10Kw, C-Cabinet	22
		Figure 17. W.D., FSHE Mtr, 20Kw, C-Cabinet	23
		INSTALLATION / PERFORMANCE CHECKLIST	24

IMPORTANT SAFETY INFORMATION

NOTE TO INSTALLER: Please read all instructions before servicing this equipment. Pay attention to all safety warnings and any other special notes highlighted in the manual.

Safety markings are used frequently throughout this manual to designate a degree or level of seriousness and should not be ignored. **WARNING** indicates a potentially hazardous situation that if not avoided, could result in personal injury or death. **CAUTION** indicates a potentially hazardous situation that if not avoided, may result in minor or moderate injury or property damage.

WARNING:

ELECTRICAL SHOCK, FIRE OR EXPLOSION HAZARD

Failure to follow safety warnings exactly could result in serious injury or property damage.

Improper servicing could result in dangerous operation, serious injury, death or property damage.

- **Before servicing, disconnect all electrical power to air handler.**
- **When servicing controls, label all wires prior to disconnecting. Reconnect wires correctly.**
- **Verify proper operation after servicing.**

GENERAL INFORMATION

Requirements & Codes

WARNING:

This unit must be installed in accordance with instructions outlined in this manual during the installation, service, and operation of this unit. Unqualified individuals should not attempt to interpret these instructions or install this equipment. Failure to follow safety recommendations could result in possible damage to the equipment, serious personal injury or death.

- The installer must comply with all local codes and regulations which govern the installation of this type of equipment. Local codes and regulations take precedence over any recommendations contained in these instructions. Consult local building codes for special installation requirements.
- This equipment contains nitrogen gas. Installation or servicing should only be performed by qualified trained personnel thoroughly familiar with this type equipment.

- All electrical wiring must be completed in accordance with local, state and national codes and regulations and with the National Electric Code (ANSI/NFPA 70) or and HUD Manufactured Home Construction and Safety Standard, Title 24 CFR, Part 3280. If this standard is not applicable, the installation must be comply to the Standard for Manufactured Home Installation Manufactured Home Sites, Communities and Setups (ANSI 225.1). In Canada all electrical wiring must be completed in accordance with the Canadian Electric Code Part 1 CSA C.22.1
- Installation of equipment may require brazing operations. Installer must comply with safety codes and wear appropriate safety equipment (safety glasses, work gloves, fire extinguisher, etc.) when performing brazing operations.
- Install this unit only in a location and position as specified on page 4. This unit is designed only for Indoor installations and should be located with consideration of minimizing the length of the supply and return ducts. Refer to the rating plate or Tables 6a & 6b (page 17) for proper circulating airflow data.
- Follow all precautions in the literature, on tags, and on labels provided with the equipment. Read and thoroughly understand the instructions provided with the equipment prior to performing the installation and operational checkout of the equipment.

About the Air Handler

This appliance has been tested and certified by AHRI for capacity and efficiency and will provide many years of safe and dependable comfort, providing it is properly installed and maintained. Abuse, improper use, and/or improper maintenance can shorten the life of the appliance and create unsafe hazards. Please read all instructions before installing the unit.

The B6BV Series electric furnace is approved for use in HUD code manufactured homes (HUD Manufactured Home Construction and Safety Standard (Title 24, Part 3280) and other modular home applications

B6BV Series electric furnaces are supplied with factory installed electric heat. Approved NORDYNE heat-pump/air conditioning coils may be installed in the field. Unless otherwise noted in the instructions, only factory authorized kits or accessories may be used when modifying this product.

Mounting Applications

Vertical only air handlers are factory ready for upflow applications. These units may also be applied in downflow discharge applications when applied with the appropriate field kit.

Through-the-floor installations require a 1/4" thick noncombustible resilient gasket to be used whenever the supply or return air ducts pass through the floor. The gasket should be positioned between the duct, unit, and floor.

Before You Install this Appliance

- ✓ This equipment is securely packaged at the time of shipment and upon arrival should be carefully inspected for damage prior to installing the equipment at the job site. Claims for damage (apparent or concealed) should be filed immediately with the carrier.
- ✓ It is recommended that the heating area should be calculated and a system of the proper capacity selected.
- ✓ Check the electrical supply and verify the power supply is adequate for unit operation. The system must be wired and provided with circuit protection in accordance with local building codes. If there is any question concerning the power supply, contact the local power company.
- ✓ Verify the duct system is appropriate for the air handler being installed. Please note that when replacing an existing system with lower air-flow, the duct system may require modification.

Locating the Air Handler

- Survey the job site to determine the best location for mounting the unit. Consideration should be given to availability of electric power, service access, and noise.
- The dimensions of the room or alcove must be able to accommodate the overall size of the unit and the installation clearances listed in Table 1. Physical dimensions for this air handler are also shown in Figure 9 (page 13).
- This unit should be located with consideration of minimizing the length of the supply and return ducts. Refer to the rating plate or Tables 6, 7a & 7b (page 14) for proper circulating airflow data.

Minimum Clearances

- This appliance must be installed in accordance with clearances listed in Table 1. The air handler must be installed with ample clearance for easy access to the air filter, blower assembly, heater assembly, controls, and vent connections.
- Static pressure drop through louvered openings and through return air plenums should be considered in the overall duct design in the determination of the total external static pressure.
- All electric heater kits less than 20 kw are approved for use in air handler installations with zero-clearance to combustibles at any blower speed. For upflow configuration, B6 electric furnace equipped with 20 kw electric heater kits are approved for installation with zero clearance to combustibles at any blower speed.

Plenums & Air Ducts

⚠ WARNING:

All return ducts must be secured to the air handler using appropriate methods. All return ducts must be adequately sealed. When return air is provided through the bottom of the unit, the joint between the air handler and the return air plenum must be air tight.

Return air and circulating air ducts must not be connected to any other heat producing device such as a fireplace insert, stove, etc. This may result in fire, explosion, carbon monoxide poisoning, personal injury, or property damage.

- Plenums and air ducts should be installed in accordance with the standards of the National Fire Protection Association Standard for Installation of Air Conditioning Systems (NFPA 90A), Standard for Installation of Residence Type Warm Air Heating and Air Conditioning Systems (NFPA 90B), and all applicable local codes. NFPA publications are available by writing to: National Fire Protection Association, Batterymarch Park, Quincy, ME 02269 or visit www.NFPA.org online.
- Design the duct work according to methods described by the Air Conditioning Contractors of America (ACCA). Air ducts must be aluminum, tin plate, galvanized sheet steel, or other approved materials for outlet or return air ducts. Snap-Lock or Pittsburgh-Lock seams are preferred. All other types of seams must be made tight to prevent leakage.
- **GAS PIPING MUST NOT RUN IN OR THROUGH ANY OF THE AIR DUCT SYSTEM.**
- This unit is designed only for use with a return and supply duct. The ducts should be appropriately sized to the capacity of the air handler to ensure its proper

INSTALLATION CLEARANCES	
Left Side..... 0 Inches	Right Side 0 Inches
Back..... 0 Inches	Front..... †See Notes

†NOTES:
Closest or Alcove Installations:

- Allow 24 in. minimum clearance from front of unit to nearest wall or partition for servicing. Recommended clearance is 36 in.
- A return air grill should be installed in the door or a partially louvered door across the opening for proper air circulation. Provide at least 235 in² free opening for return air for B-cabinet models and 300 in² for C-cabinet models. A fully louvered closet door is strongly recommended for both installation types.

Table 1. Minimum Unit Clearances

airflow rating. Refer to the rating plate or Tables 6, 7a & 7b (page 14) for proper circulating airflow data.

- Use transition fittings if the supply and/or return air openings of the unit do not match the duct openings. These transitions should be dimensioned in accordance with standard practice as specified in the ASHRAE recommendations for duct transitions.
- Flexible connectors may be used between the unit and the ductwork to prevent transmission of vibration from the unit to the structure. Heat resistant material must be used for the flexible connector at the supply air end of the unit.
- It is good practice to seal all connections and joints with industrial grade sealing tape or liquid sealant. Requirements for sealing ducts vary from region to region. Consult with local codes for requirements specific to your area.

Return Air Connections

For each application in the USA, the home manufacturer shall comply with all of the following conditions to have acceptable return air systems for closet installed forced air heating appliances:

- Regardless of the location, the return air opening into the closet shall not be less than specified in the appliance's listing.
- Means shall be provided to prevent inadvertent closure by a flat object placed over the return air opening when it is located in the floor of the closet (versus the vertical front or side wall).
- The cross-sectional area of the return duct system leading into the closet shall not be less than 390 in².
- The total free area of openings in the floor or ceiling registers serving the return air duct system must be at least 352 in². At least one register should be located where it is not likely to be covered by carpeting, boxes and other objects.
- Materials located in the return duct system must have a flame spread classification of 200 or less. This includes a closet door if the air handler is in a closet.
- Test the negative pressure in the closet with the air-circulating fan operating at high speed and the closet closed. The negative pressure is to be no more negative than minus 0.05 inch water column.
- For floor return systems, the manufactured home manufacturer shall affix a prominent marking on or near the appliance where it can be easily read when the closet door is open. The marking shall read:

CAUTION:

HAZARD OF ASPHYXIATION: Do not cover or restrict return air opening.

- The return air opening can be located in a closet door or a sidewall. If the return air opening is directly adjacent to the side (or front) of the air handler, 6" minimum clearance must be provided between the side of the

air handler and the return air opening. If no part of the return air opening is directly adjacent to the unit no clearance is required.

- In applications where the supply ducts carry heated air to areas outside the space where the furnace is installed, the return air must be delivered to the furnace by duct(s) secured to the furnace casing, running full size and without interruption.

Supply Air Connections

- The supply duct system must be designed so that the static pressure measured external to the furnace does not exceed the listed static pressure shown on the furnace rating plate. The supply air must be delivered to the heated space by duct(s) secured to the furnace casing, running full length and without interruption.

Unconditioned Spaces

All duct work passing through unconditioned space must be properly insulated to minimize duct losses and prevent condensation. Use insulation with an outer vapor barrier. Refer to local codes for insulation material requirements.

Acoustical Duct Work

- Certain installations may require the use of acoustical lining inside the supply duct work. Acoustical insulation must be in accordance with the current revision of the Sheet Metal and Air Conditioning Contractors National Association (SMACNA) application standard for duct liners. Duct lining must be UL classified batts or blankets with a fire hazard classification of FHC-25/50 or less.
- Fiber duct work may be used in place of internal duct liners if the fiber duct work is in accordance with the current revision of the SMACNA construction standard on fibrous glass ducts. Fibrous duct work and internal acoustical lining must be NFPA Class 1 air ducts when tested per UL Standard 181 for Class 1 ducts.
- Damping ducts, flexible vibration isolators, or pleated media-style filters on the return air inlet of the air handler may be used to reduce the transmission of equipment noise emanating from the air handler. These treatments can produce a quieter installation, particularly in the heated space. However, they can increase the pressure drop in the duct system. Care must be taken to maintain the proper maximum pressure rise across the air handler, temperature rise and flow rate. This may mean increasing the duct size and/or reducing the blower speed. These treatments must be constructed and installed in accordance with NFPA and SMACNA construction standards. Consult with local codes for special requirements. For best sound performance, be sure to install all the needed gaskets and grommets around penetrations into the air handler, such as for electrical wiring.

Air Filters

B6BV series air handlers are not supplied with an air filter when shipped from the factory. The installer must provide a high velocity filter that is appropriately sized to the return

air duct opening or filter rack located in the bottom of the unit. Accessing the filter does not require tools and can be removed from the front of the unit by removing the filter door. See Unit Maintenance (page 13) for filter sizes and installation information.

⚠ WARNING:

Never operate the air handler without a filter or with doors removed. Dust and lint can build up on internal components, resulting in loss of efficiency, equipment damage, and possible fire.

AIR HANDLER INSTALLATION

These Installation procedures are suggested for typical air handler installations. Since all installations are different from each other, the sequence of these steps may differ from the actual installation. **Only qualified HVAC technicians should install this furnace.**

The B6BV series air handler is shipped ready for vertical upflow installation and is approved for attic, basement, alcove/closet or crawlspace installation with zero clearance to combustibles. See Table 1 (page 4) for required installation clearances. **This appliance is approved only for indoor use.**

- Remove the shipping crate and User's Manual from the equipment.
- The unit must be leveled at installation and attached to a properly installed duct system.
- The surface that the air handler is mounted on must provide sound physical support of the unit.
- The air handler must be installed so that all electrical components are protected from water.
- If a louvered door is installed across the front of this unit, the appliance must be mounted flush or behind front edge of finished wall.

Upflow Installations

All air handlers are factory shipped, ready for upflow installation. All return air must enter from the bottom of the unit when installed in the upflow configuration. A typical upflow unit is shown in Figure 1.

Position the air handler on top of the return air duct and secure together with sheet metal screws. The screws must penetrate the sheet metal cabinet and duct. Tape or seal all seams if required by local code.

To attach the supply air duct to the air handler, bend the perforated flanges (Figure 3, page 7) upward 90° with a pair of wide duct pliers. Position the duct on top of the air handler and secure together with sheet metal screws. Make sure the screws penetrate the sheet metal casing and flanges. Tape or seal all seams if required by local code.

NOTE: If an upflow pedestal mounting stand is fabricated in the field, the stand must be constructed strong enough to support the unit with all accessories installed




Figure 1. Installation Configurations

(approximately 130 lbs. for B-cabinet models and 200 lbs. for C-cabinet models). The construction of the pedestal stand must also allow for at least 235 in² free opening (300 in² for C-cabinet models) in the application. Field fabricated upflow pedestal mounting stands must be constructed of noncombustible materials. Position the air handler on top of the mounting stand and secure together with sheet metal screws. The screws must penetrate the sheet metal cabinet and duct. Tape or seal all seams if required by local code.

Downflow Installations

B6BV air handlers can be converted to downflow operation by flipping an upflow unit 180°. A typical installation of the unit in a downflow application is shown in Figure 1.

NOTE: Downflow installations require the use of a plenum connector (or its equivalent) if the supply air ducts pass through the floor of the structure. This factory supplied accessory must be installed in the floor cavity and attached to the supply air duct before the downflow unit is installed. Available plenum connectors for all B6BV air Handlers are listed in Table 2 (page 7). All return air in downflow applications must enter through the top of the unit.

Position the air handler on top of the plenum connector and secure together with sheet metal screws. The screws must penetrate the sheet metal cabinet and plenum connector. Tape or seal all seams if required by local code.

Plenum Connector Installation

The plenum connector is designed for use with trunk ducts having a minimum width of 12". If sufficient space is not available to adequately bend and secure duct tabs it may be necessary to attach the connector to the duct using

sheet-metal fasteners and seal with an approved foil tape. The connector may be field constructed but must meet requirements as listed in the unit installation instructions.

1. Measure and mark the outline of the cut-out on the floor. See Figure 2 for cutout dimensions.

IMPORTANT!: Cut-outs in the floor and ductwork must be carefully located to avoid misalignment of the furnace and supply / return air ducts.

2. Cut out the floor opening.

NOTE: To allow some clearance for installing the plenum connector, cut the opening 1/16" larger than the actual cutout drawn.

3. Center the plenum connector in the floor opening with bottom tabs resting on top of the supply air duct.
4. Mark the cut-out area on the supply air duct by tracing around the connector tabs of the plenum connector.
5. Remove the plenum connector and cut out the marked area of the supply air duct.

NOTE: To allow some clearance for installing the plenum connector, cut the opening 1/4" larger the actual cutout drawn.

6. Install the duct connector back in the floor opening with the bottom tabs extending into the supply air duct. See Figure 4.
7. Secure the plenum connector to the wood floor with appropriate size screws.
8. Bend the connector tabs on the bottom of the plenum connector upwards and as tight as possible against the supply air duct. See Figure 4.
9. Seal all connections with industrial grade sealing tape or liquid sealant. **Requirements for sealing ductwork vary from region to region. Consult with local codes for requirements specific to your area.**

A/C or H/P Coil Installation

Approved air conditioning and heat pump system components are listed on the unit nameplate. To install the indoor coil:

1. Remove door cover plate, door and coil close-off plate (with insulation). Discard door cover plate.
2. Upflow Applications: Slide the coil into the track located in the bottom of the unit.

Downflow Applications: The downflow adaptor must be used (see Table 2). Install the downflow adaptor and coil as directed in the instructions supplied with the kit.

3. Reinstall the door and coil close-off plate (with insulation). **NOTE:** In downflow applications the door is rotated 180° so that the refrigerant and condensate lines remain on the left side.

4. Install the refrigerant and condensate lines as directed in the instructions supplied with the outdoor unit.

Description	Cabinet Size	
	B	C
Downflow Plenum Connector, 6.25"	913840	914969
Downflow Plenum Connector, 8.25"	913841	914970
Downflow Plenum Connector, 10.25"	913842	914971
Upflow Pedestal Mounting Stand	913872	913873
Downflow Coil Adaptor	919321	919322 *919323

* Use when installing B width coil in C width cabinet

Table 2. Optional Accessory Kits




Figure 2. Plenum Adapter




Figure 3. Perforated Flanges




Figure 4. Duct Connector Installed

ELECTRICAL CONNECTIONS

WARNING:

ELECTRICAL SHOCK, FIRE OR EXPLOSION HAZARD

Failure to follow safety warnings exactly could result in serious injury or property damage.

Improper servicing could result in dangerous operation, serious injury, death or property damage.

- **Before servicing, disconnect all electrical power to the air handler.**
- **When servicing controls, label all wires prior to disconnecting. Reconnect wires correctly.**
- **Verify proper operation after servicing.**

Electrical connections must be in compliance with all applicable local codes and ordinances, and with the current revision of the National Electric Code (ANSI/NFPA 70). For Canadian installations, the electrical connections and grounding shall comply with the current Canadian Electrical Code (CSA C22.1 and/or local codes).

Pre-Electrical Checklist

- ✓ Verify the voltage, frequency, and phase of the supply source match the specifications on the unit rating plate.
- ✓ Verify that the service provided by the utility is sufficient to handle the additional load imposed by this equipment. See the unit wiring label or Table 7 (page 17) for proper high and low voltage wiring.
- ✓ Verify factory wiring is in accordance with the unit wiring diagrams (Figures 15-18, pages 20-23). Verify no connections came loose during shipping or installation.

Line Voltage

- **An electrical disconnect must be located within sight of and readily accessible to the unit.** This switch shall be capable of electrically de-energizing the outdoor unit. See unit data label for proper incoming field wiring. Any other wiring methods must be acceptable to authority having jurisdiction.
- It is recommended that the line voltage to the unit be supplied from a dedicated branch circuit containing the correct fuse or circuit breaker for the unit.
- The installer should become familiar with the wiring diagram/schematic before making any electrical connections to the unit. See the unit wiring label or (Figures 15-18, pages 20-23).
- Use only copper wire for the line voltage power supply to this unit. Use proper code agency listed conduit and a conduit connector for connecting the supply wires to the unit. Aluminum supply wire may be used if a heater kit is installed.
- Provide power supply for the unit in accordance with the unit wiring diagram, and the unit rating plate. Use UL

- listed conduit and conduit connectors for connecting the supply wires to the unit and for proper grounding. Field supplied bushings for the power supply cables must be added to support and protect the power supply cables.
- If replacing any of the original wires supplied with the unit, the replacement wire must be copper wire consisting of the same gauge and temperature rating.
- Circuit breakers installed in the B6BV series air handler are for short-circuit protection of the internal wiring and to serve as a unit disconnect. They do not provide over-current protection of the supply wiring. Overcurrent protection must be provided at the branch circuit distribution panel and sized as shown on the unit rating label and according to applicable local codes. See the unit rating plate and Table 8 (page 15) for maximum circuit ampacity and maximum overcurrent protection limits.
- All 208/230 Volt units are shipped from the factory wired for 240 volt operation. For 208V operation, remove the lead from the transformer terminal marked 240V and connect it to the terminal marked 208V.

Single Circuit Adaptor Kit

If a single circuit adaptor kit is used, it may need to be re-configured for some applications. Remove the single circuit adaptor kit cover and verify that the lugs are configured correctly for the application. If the lugs are not configured for the application, refer to the instructions included with the kit and modify the configuration.

Install the single circuit adaptor kit (if used) in the line side ("on" end) of the circuit breakers. Tighten the lugs securely (45 in-lbs recommended). Connect the supply wiring to the circuit breakers, single circuit adaptor kit, or terminal block. Tighten the lugs securely.

Dual Supply Circuits

When using dual supply circuits verify that the supply sized for circuit "A" is connected to the circuit breaker that is connected to the top element assembly. Replace metal circuit breaker line cover. Refer to Figure 10 (page 15) for thermostat wiring examples.

Control Board

The control board in the air handler controls the timing sequence of the elements. The board is equipped with a 3 second blower ON delay and a 15 second blower OFF delay in heating and a 40 second blower OFF delay in cooling. See Figures 11 or 12 (page 16).

Twinning

B6BM air handlers are not supplied with a built in twinning capability. To connect two air handlers to a common single stage AC condensing unit or heat pump, a twinning kit is available for field installation. **Please follow the instructions supplied with the kit.**

NOTE: Variable speed air handlers cannot be twinned.

Thermostat Connections

- Thermostat connections shall be in accordance with the instructions supplied with the thermostat. The thermostat used with this equipment must operate in conjunction with any installed accessories. Typical AC and air handler hookups are shown in Figure 10 (page 15).

CAUTION:

Isolation must be maintained from the external Class 2 output of any transformer in a cooling circuit. Use a thermostat with isolating contacts to prevent inter-connection of Class 2 outputs.

- Where local codes require that the thermostat wiring must be routed through a conduit or raceway, splices can be made inside the unit; however, all wiring must be NEC Class 1 and must be separated from incoming power leads.
- The thermostat should be mounted about 5 feet above the floor on an inside wall. **DO NOT** install the thermostat on an outside wall or any other location where its operation may be adversely affected by radiant heat from fireplaces, sunlight, or lighting fixtures, and convective heat from warm air registers or electrical appliances. Refer to the thermostat manufacturer's instruction sheet for detailed mounting and installation information.
- Install the grommet, which is packed with the unit, in the hole for low-voltage wires. Properly connect the low-voltage wiring between the thermostat, outdoor unit, and control board. **NOTE:** When the low voltage wires are positioned in this grommet, the grommet will prevent chafing and/or shorting of the low voltage leads.

Grounding

WARNING:

The unit cabinet must have an uninterrupted or unbroken electrical ground to minimize personal injury if an electrical fault should occur. Do not use gas piping as an electrical ground!

This unit must be electrically grounded in accordance with local codes or, in the absence of local codes, with the National Electrical Code (ANSI/NFPA 70) or the CSA C22.1 Electrical Code. Use the grounding lug provided in the control box for grounding the unit.

STARTUP & ADJUSTMENTS

Before You Start the Unit

Prior to start-up, complete the following inspections:

- ✓ Verify the unit is level and properly located with adequate clearances for servicing the unit. See Table 1 (page 4).
- ✓ Check condensate drain line(s) for proper drainage (if applicable).
- ✓ Verify the surrounding area and top of the unit is free from obstructions and debris.
- ✓ Check all duct connections. Make sure the duct work is adequately sealed to prevent air leakage.
- ✓ Check all coil connections for leaks (if applicable).
- ✓ Verify that the line voltage power leads are securely connected and the unit is properly grounded. Make sure all doors are installed before restoring power to the unit
- ✓ Verify the thermostat is wired correctly. Make sure all low voltage wires are securely connected.
- ✓ Verify the power supply branch circuit overcurrent protection is sized properly.
- ✓ Verify filter is properly and securely installed.

Air Circulation Check

Running the Blower Continuously

Set the thermostat's system mode to **OFF** and the thermostat's fan mode to **ON**. The blower motor should run continuously. Check for air delivery at the register(s). Make sure that there are no obstructions at the registers or in the ducts.

NOTE: If blower is turning opposite of arrow direction, shut off main power to the unit and switch any two field wires at the disconnect. **DO NOT** alter unit wiring.

System Cooling

1. Set the thermostat's system mode to **COOL** and fan mode to **AUTO**. Lower the thermostat's temperature mode below room temperature and observe that the blower energizes. Check the air being discharged at the register is cooler than room temperature. Verify unit refrigerant pressures are in order. Blower should be turning in direction indicated by arrow.

NOTE: DO NOT alter unit wiring. Listen for any unusual noises. Locate the source and correct as needed.

2. Allow the unit to run for several minutes and then set the thermostat's temperature above room temperature. Verify the blower cycles off with the thermostat.

System Heating

1. Set the thermostat's system mode to **HEAT** and the fan mode to **AUTO**. Increase the thermostat's temperature above room temperature and observe that the blower energizes. Check the air being discharged at the register is warmer than room temperature.
2. Allow the unit to run for several minutes and then set the thermostat's temperature below room temperature. Verify the blower cycles off with the thermostat.

Turning the Blower Off

Set thermostat's fan mode to **AUTO**, the blower will shut down immediately.

Blower Configurations

Determining Nominal System Capacity

To select the appropriate airflows for the air handler, the nominal system capacity must be known. The nominal system capacity is always the nominal capacity of the outdoor unit. However, in some situations the nominal system capacity may not be the same as the capacity rating of the air handler. Always refer to the capacity rating of the outdoor unit to determine the nominal system capacity.

Selecting Continuous Low Speed Fan Operation

The B6BV series air handler is equipped with the option of continuous low speed fan operation. When **G** is energized without **Y/Y2**, the air handler will operate using the heating speed. With **G & Y/Y2** or **Y/Y2** energized, the B6 electric furnace will operate in the selected cooling speed (including 40 sec blower-off delay). **NOTE:** To achieve continuous low speed fan operation **G** must be connected at the B6 electric furnace.

Proper Blower Speed for Multi-Speed Units

The blower speed is preset at the factory for operation at the same speed for heating and cooling, by using the jumping terminal on the blower motor and connecting it to the desired speed with both the red and black wires connected to the jumping terminal.

NOTES:

- The control board is programmed with a 40 second off delay in the cooling mode for optimum system performance and efficiency.
- When using a 20 kw electric heat kit in a downflow installation, the blower must be set for high speed for both heating and cooling.

CAUTION:

To avoid personal injury or property damage, make sure the motor leads do not come into contact with any uninsulated metal components of the unit.

For optimum system performance and comfort, it may be necessary to change the factory set speed. Refer to Tables 6, 7a, or 7b (page 14) for airflow data. To change the blower speed:

1. Disconnect all electrical power to the unit and remove the upper door.
2. Remove the black and red wires from the blower motor jumping terminal. Discard the blower motor jumping terminal.
3. Connect the heating speed wire (red) and the cooling speed wire (black) to the desired blower speed marked on the terminal block of the blower motor.

Standard 4-speed motors:

- Terminal 2 = High speed
- Terminal 3 = Medium High speed
- Terminal 4 = Medium Low speed
- Terminal 5 = Low speed

4. Replace the upper door and secure it to the unit.

5. Restore power to the unit.

High Efficiency - Fixed Speed Units

IMPORTANT! This air handler has been designed to give the installer maximum flexibility to optimize system performance, efficiency, and comfort. Because there are so many different ways to set up the air handler it is important to read and follow these directions carefully.

B6BV air handlers use high efficiency circulating air motors. The fixed speed motor control board (Figure 13, page 17) controls the torque output of the motor.

Before operation, the air handler must be configured to match the unit with the system, system options, and climatic conditions. When configured, the air handler responds directly to the thermostat inputs, as well as the optional humidistat (see page 11). During normal operation, the motor will gradually change speeds during start-up, shut down, when thermostat inputs change, and when the duct static pressure changes (vents closed or opened, filter clogging, etc.). The air handler is configured by setting the selector switches on the control board.

Selecting Basic Heating Airflow

The fixed speed motor control board (Figure 13) contains a set of dip switches for setting the blower speed. Use pins 1 to 4 to set the blower speed for heating and pins 5 to 8 to set the speed for cooling. To determine the appropriate switch settings for your installation, see Table 7b (page 14)

NOTE: The minimum electric heat airflow setting may be set higher, but must never be set lower than the setting shown in Table 6 (page 14).

Selecting Basic Cooling / Heat Pump Airflow

The basic cooling/heat-pump airflow is controlled by setting switches 5 - 8 on the thermostat input board (mounted on the blower). All airflows for other modes of operation (except electric heat) are determined by this basic setting. FAN ONLY would deliver 50% of the selected cooling airflow. Table 7b (page 14) lists the basic airflow values versus the airflow selector switch settings and ranges of basic air flow settings.

- When operating in the heat pump mode, a higher basic airflow setting will increase the energy efficiency and capacity but will also decrease the supply air temperature.
- For maximum capacity and energy efficiency, select an airflow at or near the top of the range for that nominal capacity.
- For maximum dehumidification, select an airflow near the middle or bottom of the range for that nominal capacity.

Additional information on humidity control can be found in the Humidistat and Delay Setting sections.

- For thermostats with a dehumidifier output, use a field supplied wire to connect the thermostat's dehumidifier output to the terminal marked **DHUM**. The thermostat should be set so that the **DHUM** output should be high (positive) when dehumidification is needed. See also Dehumidification Options section.

IMPORTANT! If coil icing is observed, the basic cooling/heat-pump airflow selected may be too low. Verify the setting selected is within the range shown in Tables 7a or 7b (page 14) and that the the system is properly charged. Please refer to the instructions supplied with the outdoor unit. If icing continues to occur, raise the selected airflow one or two steps.

Dehumidification Options

The motor control board (Figure 13, page 17) has a **DHUM** connection that allows the system to increase the amount of humidity that is removed from the circulating air. This is accomplished by reducing the CFM and allowing the cooling coil to become colder. This will only occur when there is a call for cooling. There are many ways that this can be electrically wired.

1. If the room thermostat incorporates a humidity sensor and **DHUM** output, connect the **DHUM** on the thermostat to the **DHUM** terminal on the motor control board. See Figure 5.
2. If using a separate humidistat, connect the **DHUM & R** terminals on the humidistat to the **DHUM & R** terminals on the motor control board of the air handler. In this option, the **DHUM** output of the humidistat must be set to be normally open and closed when there is a call for humidification.
3. If a humidistat is not available, it is an acceptable option to connect the **R & DHUM** terminals on the motor control board together with a field supplied wire. This option causes the blower to run at a reduced CFM for 10 minutes after a call for cooling. **NOTE:** If outdoor unit is a heat pump, connect the **O** terminal to **DHUM**.




Figure 5. DHUM Wiring Configuration

CABINET SIZE	FILTER SIZE
A	12 x 20 x 1
B	18 x 20 x 1
C	20 x 20 x 1

Table 3. Filter Sizes

UNIT MAINTENANCE

Proper maintenance is most important to achieve the best performance from a air handler. Some of the components and their locations are shown in Figure 8 (page 12). If any component of the air handler must be replaced, use only factory authorized replacement parts specified in the Replacement Parts List provided online.

WARNING:

ELECTRICAL SHOCK, FIRE OR EXPLOSION HAZARD

Failure to follow safety warnings exactly could result in serious injury or property damage.

Improper servicing could result in dangerous operation, serious injury, death or property damage.

- Before servicing, disconnect all electrical power to air handler.
- When servicing controls, label all wires prior to disconnecting. Reconnect wires correctly.
- Verify proper operation after servicing.

- These maintenance instructions are primarily intended to assist qualified technicians experienced in the proper maintenance and operation of this appliance.
- Always reinstall the doors on the air handler after servicing or cleaning/changing the filters. Do not operate the air handler without all doors and covers in place.
- Verify that the thermostat is properly installed and is not being affected by drafts or heat from lamps or other appliances.
- To achieve the best performance and minimize equipment failure, it is recommended that a yearly maintenance checkup be performed. At a minimum, this check should include the following items:

Air Filter(s)

WARNING:

Never operate the air handler without a filter in place. Dust and lint in the return air can build up on internal components, resulting in loss of efficiency, equipment damage, and possible fire.

B6BV series air handlers are not supplied with a single air filter when shipped from the factory. It is recommended that the filter be cleaned or replaced monthly. Newly built or recently renovated homes may require more frequent changing until the construction dust has minimized. Filter sizes shown in Table 3 are available at most local retailers.

Filters designed to remove smaller particles such as pollen, may require additional maintenance.

Blower Compartment

Dirt and lint can create excessive loads on the motor resulting in higher than normal operating temperatures and shortened service life. It is recommended that the blower compartment be cleaned of dirt or lint that may have accumulated in the compartment or on the blower and motor as part of the annual inspection.

Blower Fan Wheel

Inspect the blower wheel blades for accumulations of dirt and clean if necessary. Inspect mounting nut for tightness when done.

Blower Motor & Assembly

Inspect the blower assembly and motor mounting brackets for tightness and corrosion. Correct deficiencies if necessary. The blower motor contains sealed bearings and under normal operating conditions, no maintenance is necessary for the life of the equipment.

RED LED	DIAGNOSTIC
OFF	Control Fault (No Power)
Flash	Blower Fault
ON	Normal Operation

Table 6. Air handler Control Board Fault Conditions

TROUBLESHOOTING

If the air handler fails to operate, check the following:

- Is the electric turned on?
- Is the thermostat operating properly?
- Are the blower compartment door(s) in place?
- Is the air handler disconnect closed?
- Has the circuit breaker tripped or the control board fuse burned open?
- Are any manual reset switches open?
- Is the filter dirty or plugged?
- Is the red LED on the air handler control board constantly ON? If not, use Table 6 to determine fault condition.
- Is the green and red LED on the motor control board constantly ON? If not, use Table 7 to determine fault condition.

	DIAGNOSTIC	GREEN LED	RED LED
Fixed Speed Furnaces	Control Fault (No Power)	Off	Off
	Normal Operation	On	On
	Motor Fault	On	Flash
	Twin Fault (no motor fault)	Flash	On
	Communications Fault	Flash	Flash

Table 7. Motor Control Board Fault Conditions




Figure 8. B6BV Series Air Handler Components

FIGURES & TABLES




Figure 9. B6BV Series Air Handler Physical Dimensions

AIRFLOW DATA

Cabinet	Nominal Electric Heat KW						
	5	8	10	15	20	25	30
C	1000	1100	1200	1400	1600	1800	2000

Table 6. Minimum Heating Airflow Settings (in CFM) for B6BV (FSHE) Air Handlers

Model	Nominal Blower Size	Nominal Motor Size	Number of Speeds	Ext. Static Pressure (in W.C.)	Low	Medium Low	Medium High	High
B6BV B - Cabinet	10 x 8	1/3 hp	4-sp	0.1	800	1090	1265	1405
				0.2	780	1080	1255	1395
				0.3	760	1060	1240	1375
				0.4	740	1095	1215	1350
				0.5	715	1020	1190	1310

NOTES:

- 1) Airflow is shown in cfm, +/- 5%.
- 2) All airflows are measured without filter and with dry coil. For filter velocity of 300 ft./min. subtract .08" external static pressure. For wet coil, subtract .1" external static pressure.
- 3) See unit nameplate or installation instructions for maximum recommended external static pressure.

Table 7a. Airflow Data for B-Size Cabinets

	Switch Setting				Cooling or Heating Airflow (CFM)							
					Dry Coil ESP							
	1/5	2/6	3/7	4/8	0.1	0.2	0.3	0.4	0.5	0.6	0.7	0.8
B6BV C - cabinet	0	0	0	0	710	580	395					
	1	0	0	0	830	690	675	530	505			
	0	1	0	0	930	875	710	665	560	530		
	1	1	0	0	1065	1015	900	840	800	705	665	635
	0	0	1	0	1185	1115	1010	960	925	875	830	745
	1	0	1	0	1275	1220	1175	1120	1060	970	930	890
	0	1	1	0	1365	1350	1255	1200	1150	1105	1060	1025
	1	1	1	0	1480	1430	1370	1325	1265	1225	1185	1140
	0	0	0	1	1560	1535	1485	1430	1375	1335	1285	1240
	1	0	0	1	1650	1600	1545	1500	1450	1405	1360	1305
	0	1	0	1	1730	1685	1660	1610	1570	1520	1470	1420
	1	1	0	1	1785	1740	1695	1645	1615	1545	1510	1470
	0	0	1	1	1865	1820	1785	1750	1695	1655	1605	1560
	1	0	1	1	1920	1890	1850	1805	1765	1715	1675	1640
	0	1	1	1	2010	1965	1960	1900	1850	1810	1775	1730
1	1	1	1	2065	2020	1985	1955	1915	1880	1840	1810	

NOTE: 0 = OFF, 1 = ON

Table 7b. Airflow Data for C-Size Cabinets

ELECTRICAL DIAGRAMS & DATA

B6BV																		
CABINET	CAPACITY	HEAT KIT MODEL NUMBER H6HK-	240 VAC, 50 & 60 HZ, SINGLE PHASE								208 VAC, 50 & 60 HZ, SINGLE PHASE							
			MCA				MOP				MCA				MOP			
			CIRCUIT A	CIRCUIT B	CIRCUIT C	SINGLE CIRCUIT	CIRCUIT A	CIRCUIT B	CIRCUIT C	SINGLE CIRCUIT	CIRCUIT A	CIRCUIT B	CIRCUIT C	SINGLE CIRCUIT	CIRCUIT A	CIRCUIT B	CIRCUIT C	SINGLE CIRCUIT
B	-	10 KW	53.6	-	-	53.6	60	-	-	60	47.0	-	-	47.0	50	-	-	50
	-	15 KW	56.6	25.0	-	78.6	60	30	-	80	47.0	21.7	-	68.6	50	25	-	70
C	-	10 KW	56.3	-	-	56.3	60	-	-	60	50.1	-	-	50.1	60	-	-	60
	-	20 KW	56.3	50.0	-	106.3	60	60	-	110	50.1	43.3	-	93.4	60	45	-	100

Table 8. B6BV Minimum Circuit Ampacity & Maximum Overcurrent Protection





Figure 10. Typical Thermostat Connections




Figure 11. Single Stage Control Board




Figure 12. Two - Stage Control Board




Figure 13. Two-Stage Fixed Speed Motor Control Board

CONTROL SIGNAL & MODE	OPERATION	TOTAL KW	BOARD ACTION
W1 only EHEAT	ON	5 KW	Stage 1 Heat on instantly
			Heat blower on after 3 second delay
		10 KW	Stage 1 Heat on instantly
			Heat blower on after 3 second delay
		15 KW	Stage 1 Heat on instantly
			Heat blower on after 3 second delay
			Stage 2 Heat on after 5 second delay
		20 KW	Stage 1 Heat on instantly
			Heat blower on after 3 second delay
			Stage 2 Heat on after 5 second delay
			Stage 3 Heat on after 10 second delay
		25 KW	Stage 1 Heat on instantly
	Heat blower on after 3 second delay		
	Stage 2 Heat on after 5 second delay		
	Stage 3 Heat on after 10 second delay		
30 KW	Stage 1 Heat on instantly		
	Heat blower on after 3 second delay		
	Stage 2 Heat on after 5 second delay		
	Stage 3 Heat on after 10 second delay		
OFF	OFF	Stage 4 Heat on after 15 second delay	
		Heat stages off instantly	
			Blower off after 15 second delay

Table 9. Heating Element Logic for B6BV Air Handlers

CONTROL SIGNAL & MODE	OPERATION	TOTAL KW	BOARD ACTION
W1 & W2 EHEAT	ON	5 KW	Stage 1 Heat on instantly
			Heat blower on after 3 second delay
		10 KW	Stage 1 Heat on instantly
			Heat blower on after 3 second delay
			Stage 2 Heat on after 5 seconds delay
		15 KW	Stage 1 Heat on instantly
			Heat blower on after 3 second delay
			Stage 2 Heat on after 5 seconds delay
		20 KW	Stage 3 Heat on after 10 seconds delay
			Stage 1 Heat on instantly
			Heat blower on after 3 second delay
			Stage 2 Heat on after 5 seconds delay
		25 KW	Stage 3 Heat on after 10 seconds delay
			Stage 4 Heat on after 15 seconds delay
			Stage 5 Heat on after 20 seconds delay
			Stage 1 Heat on instantly
			Heat blower on after 3 second delay
		30 KW	Stage 2 Heat on after 5 seconds delay
	Stage 3 Heat on after 10 seconds delay		
	Stage 4 Heat on after 15 seconds delay		
	Stage 5 Heat on after 20 seconds delay		
	Stage 6 Heat on after 25 seconds delay		
Heat stages off instantly			
OFF		Blower off after 15 second delay	
W1 & Y/Y2 AUX HEAT	ON	5 KW	Stage 1 Heat on instantly
			Cool blower on after 3 second delay
		10 KW	Stage 1 Heat on instantly
			Cool blower on after 3 second delay
		15 KW	Stage 1 Heat on instantly
			Cool blower on after 3 second delay
		20 KW	Stage 2 Heat on after 5 seconds delay
			Stage 1 Heat on instantly
			Cool blower on after 3 second delay
		25 KW	Stage 2 Heat on after 5 seconds delay
			Stage 3 Heat on after 10 seconds delay
			Stage 1 Heat on instantly
	30 KW	Cool blower on after 3 second delay	
		Stage 2 Heat on after 5 seconds delay	
		Stage 3 Heat on after 10 seconds delay	
		Stage 4 Heat on after 15 seconds delay	
OFF		Heat stages off instantly	
		Heat blower turns off after 40 second delay	

Table 9. Heating Element Logic for B6BV Air Handlers - Continued

CONTROL SIGNAL & MODE	OPERATION	TOTAL KW	BOARD ACTION
W1, W2 & Y/Y2 AUX HEAT	ON	5 KW	Stage 1 Heat on instantly
			Cool blower on after 3 second delay
		10 KW	Stage 1 Heat on instantly
			Cool blower on after 3 second delay
			Stage 2 Heat on after 5 seconds delay
		15 KW	Stage 1 Heat on instantly
			Cool blower on after 3 second delay
			Stage 2 Heat on after 5 seconds delay
		20 KW	Stage 3 Heat on after 30 seconds delay
			Stage 1 Heat on instantly
			Cool blower on after 3 second delay
			Stage 2 Heat on after 5 seconds delay
		25 KW	Stage 3 Heat on after 10 seconds delay
			Stage 4 Heat on after 15 seconds delay
			Stage 5 Heat on after 20 seconds delay
			Stage 1 Heat on instantly
			Cool blower on after 3 second delay
		30 KW	Stage 2 Heat on after 5 seconds delay
	Stage 3 Heat on after 10 seconds delay		
	Stage 4 Heat on after 15 seconds delay		
Stage 5 Heat on after 20 seconds delay			
Stage 6 Heat on after 25 seconds delay			
Heat stages off instantly			
OFF		Heat blower turns off after 40 second delay	
G FAN	On		Fan blower on after 3 second delay
	Off		Fan blower off instantly
Y/Y2 HEAT PUMP & COOL	On		Cool blower on after 3 second delay
	Off		Cool blower off after 40 second delay
Y1 HEAT PUMP & COOL	On		Cool blower on after 3 second delay
	Off		Cool blower off after 40 second delay
Y1 & Y/Y2 HEAT PUMP & COOL	On		Cool blower on after 3 second delay
	Off		Cool blower off after 40 second delay

Table 9. Heating Element Logic for B6BV Air Handlers - Continued

WIRING DIAGRAM

Air Handler with Factory Installed Heat (10kW)

NOTES:

1. The blower motor speed tap connection may not be as shown. See the Installation Instructions.
2. Disconnect all power before servicing.
3. Transformer may have a dual voltage primary tap. Match the tap position with the supply voltage used.
4. If the internal wiring is replaced, use only 105°C copper wire of the same gauge.




Figure 14. Wiring Diagram for B6BV Series Air Handler Equipped With PSC Motor & 10 kW Heater Kit (B Size Cabinet Only)

WIRING DIAGRAM

Air Handler with Factory Installed Heat (15kW)

NOTES:

1. The blower motor speed tap connection may not be as shown. See the Installation Instructions.
2. Disconnect all power before servicing.
3. Transformer may have a dual voltage primary tap. Match the tap position with the supply voltage used.
4. If the internal wiring is replaced, use only 105°C copper wire of the same gauge.





Figure 15. Wiring Diagram for B6BV Series Air Handler Equipped With PSC Motor & 15 kw Heater Kit (B Size Cabinet Only)

WIRING DIAGRAM

Air Handler with Factory Installed Heat (10kW)



7110800
0510



NOTES:


1. The blower motor speed tap connection may not be as shown. See the Installation Instructions.
2. Disconnect all power before servicing.
3. Transformer may have a dual voltage primary tap. Match the tap position with the supply voltage used.
4. If the internal wiring is replaced, use only 105°C copper wire of the same gauge.

Legend	
	Field Wiring
	Factory Wiring
	Low Voltage
	High Voltage

Figure 16. Wiring Diagram for B6BV Series Air Handler Equipped With FSHE Motor & 10 kw Heater Kit (C Size Cabinet Only)

WIRING DIAGRAM

Air Handler with Factory Installed Heat (20kW)



7110810
0510



Figure 17. Wiring Diagram for B6BV Series Air Handler Equipped With FSHE Motor & 20 kW Heater Kit (C Size Cabinet Only)

INSTALLATION / PERFORMANCE CHECK LIST

INSTALLER NAME:		
CITY:	STATE:	
INSTALLATION ADDRESS:		
CITY:	STATE:	
UNIT MODEL #		
UNIT SERIAL #		
Minimum clearances per page 4?	YES	NO
Is the unit properly installed and leveled?	YES	NO
Does condensate drain properly in both drain tubes?	YES	NO
Has the owner's information been reviewed with the home-owner?	YES	NO
Has the literature package been left near the appliance?	YES	NO

ELECTRICAL SYSTEM:		
Electrical connections tight?	YES	NO
Line voltage polarity correct?	YES	NO
Supply Voltage: _____ (V)		
Has the thermostat been calibrated?	YES	NO
Is the thermostat level?	YES	NO
Is the heat anticipator setting correct?	YES	NO

VENTING SYSTEM:		
Filter properly installed?	YES	NO
Filter clean?	YES	NO
Return Air Temp: _____ (° F)		
Supply Air Temp: _____ (° F)		
Temperature Rise: _____ (° F)		

⚠ WARNING:
PROPOSITION 65 WARNING: This product contains chemicals known to the state of California to cause cancer, birth defects or other reproductive harm.



NORDYNE
COMPLETE COMFORT. GENUINE VALUE.



Specifications & illustrations subject to change without notice or incurring obligations.
O' Fallon, MO | Printed in U.S.A. (12/11)

7091740 (NEW)