

MB7BM, MB7EM, & MB7VM SERIES

INSTALLATION INSTRUCTIONS

MODULAR AIR HANDLER



IMPORTANT

ATTENTION INSTALLERS:

It is your responsibility to know this product better than your customer. This includes being able to install the product according to strict safety guidelines and instructing the customer on how to operate and maintain the equipment for the life of the product. Safety should always be the deciding factor when installing this product and using common sense plays an important role as well. Pay attention to all safety warnings and any other special notes highlighted in the manual. Improper installation of the furnace or failure to follow safety warnings could result in serious injury, death, or property damage.

Please read all instructions carefully before starting the installation. These instructions are primarily intended to assist qualified individuals experienced in the proper installation of this appliance. Some local codes require licensed installation / service personnel for this type of equipment. If a problem occurs, check the instructions and follow recommendations given. If these suggestions don't eliminate your problem, call your servicing contractor. Return this manual to the customer's package for future reference.

DO NOT DESTROY. PLEASE READ CAREFULLY & KEEP IN A SAFE PLACE FOR FUTURE REFERENCE.

TABLE OF CONTENTS

IMPORTANT SAFETY INFORMATION	3	STARTUP & ADJUSTMENTS	11
GENERAL INFORMATION	3	Before You Start the Air Handler.....	11
Requirements & Codes	3	Air Circulation Check.....	11
About the Air Handler.....	3	Running the Blower Continuously	11
Before You Install this Equipment	4	System Cooling.....	11
Minimum Clearances.....	4	System Heating.....	11
Locating the Air Handler.....	4	Turning the Blower Off.....	11
Operation of an Air Handler During Construction.....	4	Blower Configurations	11
Plenums & Air Ducts	5	Selecting minimum Electric Heat Airflow.....	11
Supply Air Connections.....	5	Determining Nominal System Capacity	11
Return Air Connections.....	5	3-speed Units.....	11
Acoustical Duct Work.....	5	High Efficiency Units	12
Air Filters	6	Selecting Basic Heating Airflow	12
Unconditioned Spaces	6	Selecting Basic Cooling/Heat Pump Airflow.....	12
Condensate Drainage	6	Dehumidification Options	12
AIR HANDLER INSTALLATION	6	UNIT MAINTENANCE.....	13
Upflow Installation	6	TROUBLESHOOTING	13
Downflow Installation.....	7	FIGURES & TABLES	14
Horizontal Installation.....	8	Figure 7. MB7 Series Dimensions.....	14
Horizontal Left Installations.....	8	Figure 8. MB7 Series Components	15
Horizontal Right Installations	8	Blower Performance Data	16
ELECTRICAL CONNECTIONS	9	Table 4. MB7BM Airflow Data.....	16
Pre-Electrical Checklist	9	Table 5. MB7EM Airflow Data.....	17
Line Voltage.....	9	Table 6. MB7EM Airflow Settings (Heat Only)	18
Thermostat Connections	9	Table 7. MB7VM Airflow Settings (Cool Only)	18
Control Board	10	Table 8. MB7VM Airflow Data.....	19
Twinning	10	Electrical Data & Diagrams	20
Heater Kits.....	10	Table 9. MCA & MOP Data.....	20
Electronic Air Cleaner.....	10	Figure 9. Typical T-Stat Connections	21
Humidifier	10	Figure 10. Single Stg. C.B. (MB7BM)	22
Optional Humidistat.....	10	Figure 11. Single Stg. C.B. MB7(EM & VM).....	22
Grounding.....	10	Figure 12. Two Stg. Fixed Sp. M.C.B. (EM).....	23
		Figure 13. Two Stg. Var. Sp. M.C.B. (VM).....	23
		Figure 14. Wiring Diagram (BM Models)	24
		Figure 15. Wiring Diagram (EM Models)	25
		Figure 16. Wiring Diagram (VM Models)	26
		Table 10. MB7BM Heating Element Logic.....	27
		Table 11. MB7(EM & VM) Heat Element Logic.....	28
		INSTALLATION / PERFORMANCE CHECKLIST	32

IMPORTANT SAFETY INFORMATION

Please read all information in this manual thoroughly and become familiar with the capabilities and use of this appliance before attempting to service or maintain this unit.

Safety markings are used frequently throughout this manual to designate a degree or level of seriousness and should not be ignored. **WARNING** indicates a potentially hazardous situation that if not avoided, could result in personal injury or death. **CAUTION** indicates a potentially hazardous situation that if not avoided, may result in minor or moderate injury or property damage.

WARNING:

ELECTRICAL SHOCK, FIRE OR EXPLOSION HAZARD

Failure to follow safety warnings exactly could result in serious injury or property damage.

Improper servicing could result in dangerous operation, serious injury, death or property damage.

- **Before servicing, disconnect all electrical power to the air handler.**
 - **When servicing controls, label all wires prior to disconnecting. Reconnect wires correctly.**
 - **Verify proper operation after servicing.**
-

WARNING:

The information listed below must be followed during the installation, service, and operation of this unit. Unqualified individuals should not attempt to interpret these instructions or install this equipment. If you do not possess mechanical skills or tools, call your local dealer for assistance. Failure to follow safety recommendations could result in possible damage to the equipment, serious personal injury or death.

WARNING:

PROPOSITION 65 WARNING: This product contains chemicals known to the state of California to cause cancer, birth defects or other reproductive harm.

- To minimize equipment failure or personal injury, it is essential that only qualified individuals install, service, or maintain this equipment. If you do not possess mechanical skills or tools, call your local dealer for assistance.
- Follow all precautions in the literature, on tags, and on labels provided with the equipment. Read and

thoroughly understand the instructions provided with the equipment prior to performing the installation and operational checkout of the equipment.

- Use caution when handling this appliance or removing components. Personal injury can occur from sharp metal edges present in all sheet metal constructed equipment.
- Do not store any of the following on, or in contact with, the unit: Rags, brooms, vacuum cleaners, or other cleaning tools, spray or aerosol cans, soap powders, bleaches, waxes, cleaning compounds, plastics or plastic containers, paper bags or other paper products, gasoline, kerosene, cigarette lighter fluid, dry cleaning fluids, paint thinners, or other volatile fluids.
- Installation of equipment may require brazing operations. Installer must comply with safety codes and wear appropriate safety equipment (safety glasses, work gloves, fire extinguisher, etc.) when performing brazing operations.
- Unless otherwise noted in these instructions, only factory authorized kits or accessories may be used with this product.
- The installer should become familiar with the units wiring diagram before making any electrical connections to the unit. See the unit wiring label or Figures 14 - 16 (pages 24 - 26).
- Always reinstall the doors on the air handler after servicing or cleaning/changing the filters. Do not operate the air handler without all doors and covers in place.

GENERAL INFORMATION

Requirements & Codes

- The installer must comply with all local codes and regulations which govern the installation of this type of equipment. Local codes and regulations take precedence over any recommendations contained in these instructions. Consult local building codes for special installation requirements.
- All electrical wiring must be completed in accordance with local, state and national codes and regulations and with the National Electric Code (ANSI/NFPA 70) or in Canada the Canadian Electric Code Part 1 CSA C.22.1.
- Install this unit only in a location and position as specified on page 4. This unit is designed only for Indoor installations and should be located with consideration of minimizing the length of the supply and return ducts. See Tables 4 - 8 (pages 16 - 19) and the rating plate for proper circulating airflow data.
- This air handler may be used for temporary heating of buildings or structures under construction. See the guidelines listed on page 4.

About the Air Handler

This appliance has been tested for capacity and efficiency in accordance with AHRI Standards and will provide many years of safe and dependable comfort, providing it is properly installed and maintained. Abuse, improper use, and/or improper maintenance can shorten the life of the appliance and create unsafe hazards. Please read all instructions before installing the unit.


Before You Install this Equipment

- √ This equipment is securely packaged at the time of shipment and upon arrival should be carefully inspected for damage prior to installing the equipment at the job site. Claims for damage (apparent or concealed) should be filed immediately with the carrier.
- √ it is recommended that the cooling load of the area to be conditioned should be calculated and a system of the proper capacity selected.
- √ Check the electrical supply and verify the power supply is adequate for unit operation. The system must be wired and provided with circuit protection in accordance with local building codes. If there is any question concerning the power supply, contact the local power company.
- √ Verify the duct system is appropriate for the air handler being installed. Please note that when replacing an existing system with lower air-flow, the duct system may require modification.

Minimum Clearances

- This appliance must be installed in accordance with clearances listed in Table 1. The air handler must be installed with ample clearance for easy access to the air filter, blower assembly, heater assembly, controls, and vent connections.
- Static pressure drop through louvered openings and through return air plenums should be considered in the overall duct design in the determination of the total external static pressure.

INSTALLATION CLEARANCES	
Left Side..... 0 Inches	Right Side 0 Inches
Back..... 0 Inches	Front..... †See Notes



†NOTE:
Closest or Alcove Installations:

- Allow 24 in. minimum clearance from front of unit to nearest wall or partition for servicing. Recommended clearance is 36 in.

Table 1. Minimum Unit Clearances

Locating the Air Handler

- Survey the job site to determine the best location for mounting the unit. Consideration should be given to availability of electric power, service access, and noise.
- The dimensions of the room or alcove must be able to accommodate the overall size of the unit and the installation clearances listed in Table 1. Physical dimensions for this air handler are shown in Figure 7 (page 14).
- The air handler should be set into position before routing the refrigerant tubing.

Operation of an Air Handler During Construction

! CAUTION:

Failure to follow these instructions will void the factory warranty and may significantly reduce the life or the performance of the air handler, and/or result in other unsafe conditions. It is the responsibility of the installing contractor to insure these provisions are met.

Operating an air handler in a construction environment can cause the appliance a variety of problems. Proper use of commercial portable space heating equipment during construction is recommended. This air handler may be used during construction if it is not in violation of any applicable codes and the following criteria are met:

- The installation must meet all applicable codes and be permanently installed according to the instructions supplied with the air handler including electrical supply and duct work.
- The air handler must be controlled by a properly installed thermostat that complies with the current provisions of the NEC (ANSI/NFPA 70) and all applicable codes having jurisdiction. Thermostat connections must be made in accordance with instructions supplied with the air handler and thermostat. See page 9.
- The installation must include a properly installed filter in the return air system with no by-pass air. The filter must be inspected frequently and replaced when necessary.
- Return air must be supplied unrestricted and located such that dust and gases from construction activity are not introduced into the circulating air system.
- Before occupying the structure: The filter must be replaced or cleaned, the duct work must be inspected and cleaned of any construction debris, and the air handler must be cleaned and/or repaired if found to be dirty, damaged, or malfunctioning in any way by a qualified HVAC technician. The air handler shall be inspected and approved by applicable local authority even if this requires redundant inspections.
- The serial number for the air handler used during construction must be submitted in writing (fax and email also acceptable). This information will be used to track the long-term affects of air handler usage during construction. Proof of this submittal shall be available for the final inspection of the air handler prior to occupancy.

Plenums & Air Ducts

- Plenums and air ducts should be installed in accordance with the standards of the National Fire Protection Association Standard for Installation of Air Conditioning Systems (NFPA 90A), Standard for Installation of Residence Type Warm Air Heating and Air Conditioning Systems (NFPA 90B), and all applicable local codes. NFPA publications are available by writing to: National Fire Protection Association, Batterymarch Park, Quincy, ME 02269 or visit www.NFPA.org online.

WARNING:

All return ducts must be secured to the air handler using appropriate methods. All return ducts must be adequately sealed. When return air is provided through the bottom of the unit, the joint between the air handler and the return air plenum must be air tight.

Return air and circulating air ducts must not be connected to any other heat producing device such as a fireplace insert, stove, etc. This may result in fire, explosion, carbon monoxide poisoning, personal injury, or property damage.

- Design the duct work according to methods described by the Air Conditioning Contractors of America (ACCA).
- This unit is designed only for use with a return and supply duct. The return air duct must have the same free area as the opening provided on the air handler. The ducts should be appropriately sized to the capacity of the air handler to ensure its proper airflow rating.
- This unit should be located with consideration of minimizing the length of the supply and return ducts. See Tables 4 - 8 (pages 16 - 19) and the rating plate for proper circulating airflow data.
- Whenever the supply or return air ducts pass through the floor, a 1/4" thick noncombustible resilient gasket must be used between the duct, unit and floor
- Use transition fittings if the supply and/or return air openings of the unit do not match the duct openings. These transitions should be dimensioned in accordance with standard practice as specified in the ASHRAE recommendations for duct transitions.
- The supply air ductwork must be of noncombustible material for the first 24 inches from the unit. Some installations with a short, straight run from the unit to the first branch takeoff may require acoustical lining inside the supply air ductwork. Consult with local codes for requirements specific to your area.
- Flexible connectors may be used between the unit and the ductwork to prevent transmission of vibration from the unit to the structure. If electric heater kits are installed, heat resistant material must be used for the flexible connector at the supply air end of the unit.

- It is good practice to seal all connections and joints with industrial grade sealing tape or liquid sealant. Requirements for sealing ducts vary from region to region. Consult with local codes for requirements specific to your area.

Supply Air Connections

The supply air must be delivered to the heated space by duct(s) secured to the blower's casing, running full size and without interruption. Tape or seal all seams if required by local code.

Upflow & Horizontal Applications: To attach the supply air duct, bend the flanges (on top of the unit) outward 90° with a pair of wide duct pliers. Position the duct on top of the blower and secure together with sheet metal screws.

Downflow Applications: Position the blower over the duct and secure together with sheet metal screws.

Return Air Connections

The return air must be delivered to the blower by duct(s) secured to the casing, running full size and without interruption. Tape or seal all seams if required by local code.

Upflow & Horizontal Applications: Position the blower over the duct and secure together with sheet metal screws.

Downflow Applications: To attach the supply air duct, bend the furnace flanges outward 90° with a pair of wide duct pliers. Position the duct on top of the cased coil and secure together with sheet metal screws.

Acoustical Duct Work

- Certain installations may require the use of acoustical lining inside the supply duct work. Acoustical insulation must be in accordance with the current revision of the Sheet Metal and Air Conditioning Contractors National Association (SMACNA) application standard for duct liners. Duct lining must be UL classified batts or blankets with a fire hazard classification of FHC-25/50 or less.
- Fiber duct work may be used in place of internal duct liners if the fiber duct work is in accordance with the current revision of the SMACNA construction standard on fibrous glass ducts. Fibrous duct work and internal acoustical lining must be NFPA Class 1 air ducts when tested per UL Standard 181 for Class 1 ducts.
- Damping ducts, flexible vibration isolators, or pleated media-style filters on the return air inlet of the air handler may be used to reduce the transmission of equipment noise emanating from the air handler. These treatments can produce a quieter installation, particularly in the heated space. However, they can increase the pressure drop in the duct system. Care must be taken to maintain the proper maximum pressure rise across the air handler, temperature rise and flow rate. This may mean increasing the duct size and/or reducing the blower speed. These treatments must be constructed and installed in accordance with NFPA and SMACNA construction standards. Consult with local codes for special requirements. For best sound performance, be sure to install all the needed gaskets and grommets

around penetrations into the air handler, such as for electrical wiring.

Air Filters

WARNING:

Never operate the air handler without a filter or with doors removed. Dust and lint can build up on internal components, resulting in loss of efficiency, equipment damage, and possible fire.

MB7 Series air handlers are not equipped with filter racking; however, NORDYNE strongly recommends that a filter be located in the return air duct system. Installing the filter and replacing it every 3 months will increase air quality throughout the home.

Unconditioned Spaces

All duct work passing through unconditioned space must be properly insulated to minimize duct losses and prevent condensation. Use insulation with an outer vapor barrier. Consult your Distributor for the recommended type and thickness of insulation for your area as required by local codes.

Condensate Drainage

CAUTION:

The air handler must be level to ensure proper condensate drainage. An unlevel installation may result in structural damage, premature equipment failure, or possible personal injury.

- Modular air handlers are intended to be mated with specific NORDYNE C6 cased coils. To ensure proper condensate drainage, the unit must be installed in a level position within 1/4 inch over the height, width, and depth of the unit. The best system performance will be obtained if the unit is located in a centralized position with respect to the air distribution system. Refer to the Installation Instructions supplied with the Cased Coil for proper condensate drain connections.
- If the air handler is located in or above a living space where damage may result from condensate overflow, an auxiliary drain pan should be installed under the unit. A separate drain line should extend from the pan to a conspicuous point and serve as an alarm indicating that the primary drain is restricted. As an alternative to a separate drain line, an approved water level indicator or float switch device should be used to shut down the unit in the event water is detected in the auxiliary pan.
- During system checkout, inspect the drain line and connections to verify proper condensate drainage.
- Methods for disposing of condensate vary according to local codes. Refer to local codes or authority having jurisdiction for restrictions and proper condensate disposal requirements.

AIR HANDLER INSTALLATION

The MB7 Series air handler is shipped ready for vertical upflow installation and is approved for attic, basement, alcove/closet or crawlspace installation with zero clearance to combustibles. They may also be applied in downflow or horizontal left and right discharge applications. See Table 1 (page 4) for required installation clearances. **This appliance is approved only for indoor use.**

NOTE: For shipping purposes, the front and rear joining brackets are located in the unit's heater box. Remove these two items from the heater box before beginning.

- The unit must be leveled at installation and attached to a properly installed duct system.
- The surface that the air handler is mounted on must provide sound physical support of the unit.
- The air handler must be installed so that all electrical components are protected from water.
- If a louvered door is installed across the front of this unit, the appliance must be mounted flush or behind front edge of finished wall.
- Modular air handlers are intended to be mated with specific NORDYNE C6 cased coils. Reference the Technical Specifications for coil mating combinations.

Upflow Installation

The MB7 Series air handler is shipped from the factory ready for upflow configuration as shown in Figure 1 (page 7). Return air must enter from the bottom of the unit.

1. Remove the bracket above the door of the cased coil. Retain the screws for later use. **NOTE:** Before mating the modular unit with the cased coil, clean the mating surfaces on both units and apply the black neoprene gasket tape to the top of the coil case (except the rear surface). Make sure there are no gaps on the front and side flanges.
2. Carefully place the modular air handler on top of the cased coil making sure not to damage the cased coil flanges. The units will be flush in front with an overhang in the back as shown in Figure 2 (page 7).
3. Remove the lower front bracket (Figure 3, page 7) from the modular unit. Retain the screws for later use.
4. Attach the front joining bracket to the front of the modular unit. Align the screw holes in the bracket with the holes from the lower front bracket and the top panel of the coil case. See Figure 3.
5. Secure the bracket with the screws removed earlier in steps 1 & 2.
6. Attach the rear joining bracket to the backside of the modular unit and cased coil. Position the bracket so that it is flush with the sides and back of the units with the 1/2" insulation facing the rear gap between the units.
7. Secure the rear bracket with self tapping screws.




Figure 1. Upflow & Downflow Installation




Figure 2. Rear Bracket Installation - (Upflow Only)




Figure 3. Front Bracket Installation - (Upflow Only)

Downflow Installation

The MB7 Series Modular air handler may be installed in a downflow configuration as shown in Figure 1. Return air must enter through the top of the unit.

1. Remove the lower front bracket (Figure 3) from the modular unit. Retain the screws for later use.
2. Remove the door from the cased coil and the screws (on the side of the cased coil) securing the lower tie bar in place. Retain the screws for later use. **NOTE:** Before mating the modular unit with the cased coil, clean the mating surfaces on both units.
3. Flip the modular unit upside down and apply the black neoprene gasket tape to the top of the air handler. **NOTE:** The blowers flanged surface is now beneath the air handler and will connect with the supply air duct.
4. Carefully place the cased coil on top of the modular air handler. **NOTE:** Make sure the units are flush in the front and on the sides with a "step" fit in the back and that there are no gaps on the sides. See Figure 4.
5. Attach the front joining bracket to the cased coil and the air handler. Align the screw holes in the bracket with the holes where the lower front bracket and lower tie bar were attached.
6. Secure the bracket to the modular unit and the cased coil with the screws removed earlier in steps 1 & 2.
7. Attach the rear joining bracket to the backside of the modular unit. Position the bracket so that it is flush with the sides and back of the units with the 1/2" insulation facing the rear gap between the units.
8. Secure the rear bracket to the modular unit and cased coil with self-tapping screws.




Figure 4. Downflow Brackets

Horizontal Installation

MB7 air handlers are shipped from the factory ready for horizontal left applications and horizontal right applications. The blowers can be installed horizontally in an attic, basement, crawl space or alcove. They can also be suspended from a ceiling in a basement or utility room in either a right to left airflow or left to right airflow. A typical installation of the unit in a suspended horizontal application is shown in Figure 5.

When mating the blower and coil for horizontal left or right applications, reference the upflow instructions on page 6. Make sure to account for the coil orientation by configuring the coil drain pan assembly properly. Multi-position procedures are also available in the cased coil Installation Instructions supplied with the unit.

NOTES:

- In many applications when joined with a C6 cased coil, the shorter horizontal drain pan extension which is included with the MB7 must be used. This is to avoid any interference with the extension included with the C6 and the blower.
- The air handler may or may not be shipped from the factory with all the parts required for horizontal left applications and horizontal right applications. If your unit does not have parts for a horizontal application, a kit may be available.

If suspending the air handler from the ceiling, assemble a support frame (Figure 5) using slotted iron channel and full threaded rod. Fasten the frame together with nuts, washers, and lockwashers. Secure the support frame to the rafters with lag bolts. The air handler can also be suspended using steel straps around each end of the unit. The straps should be attached to the air handler with sheet metal screws and to the rafters with bolts.

Horizontal Left Installations

1. Remove the coil access door.
2. Remove the plug from one of the threaded holes in the horizontal drain pan. Completely remove the webbing

in the threaded holes of the horizontal drain pan. **If the webbing is not removed, the condensate will not drain properly and ceiling damage may occur.**

3. Insert the plug (from horizontal drain pan) into the open and unused drain hole in the drain pan at the bottom of the unit to block bypass air.
4. Remove the corresponding drain line knockout from the coil access door to allow access to the horizontal drain.
5. Replace the door and attach the drain line.

Horizontal Right Installations

1. Remove the coil access door. Unscrew the line-set tube close-off plate from the front left cabinet rail.
2. Slide the coil and drain pan assembly out of the unit.
3. Remove the sheet metal hairpin covers (if supplied) from the back of the coil and discard.
4. Place the horizontal drain pan on the opposite side of the coil. On units with 2 sets of knockouts, remove the other set of knockouts in the coil spacing plates and insert support rod.
5. Slide the coil and the horizontal drain pan assembly back into the unit. Re-attach the tube close off plate.
6. Remove the plug from one of the threaded holes in the horizontal drain pan. Completely remove the webbing located in the threaded holes of the drain pan. **IMPORTANT:** If the webbing is not removed, the condensate will not drain properly and ceiling damage may occur.
7. Insert the plug (from horizontal drain pan) into the open and unused drain hole in the drain pan at the bottom of the unit to block bypass air.
8. Remove the corresponding drain line knockout from the coil access door to allow access to the horizontal drain.
9. Replace the door and attach the drain line.




Figure 5. Unit Horizontally Suspended

ELECTRICAL CONNECTIONS

WARNING:

ELECTRICAL SHOCK, FIRE OR EXPLOSION HAZARD

Failure to follow safety warnings exactly could result in serious injury or property damage.

Improper servicing could result in dangerous operation, serious injury, death or property damage.

- **Before servicing, disconnect all electrical power to the air handler.**
- **When servicing controls, label all wires prior to disconnecting. Reconnect wires correctly.**
- **Verify proper operation after servicing.**

- Electrical connections must be in compliance with all applicable local codes and ordinances, and with the current revision of the National Electric Code (ANSI/NFPA 70).
- For Canadian installations, the electrical connections and grounding shall comply with the current Canadian Electrical Code (CSA C22.1 and/or local codes).

Pre-Electrical Checklist

- ✓ Verify the voltage, frequency, and phase of the supply source match the specifications on the unit rating plate.
- ✓ Verify that the service provided by the utility is sufficient to handle the additional load imposed by this equipment. See the unit wiring label or Table 9 (page 20) for proper high and low voltage wiring.
- ✓ Verify factory wiring is in accordance with the unit wiring diagram (Figures 14 - 16, pages 24 - 26). Verify none of the connections loosened during shipping or installation.

Line Voltage

- **An electrical disconnect must be located within sight of and readily accessible to the unit.** This switch shall be capable of electrically de-energizing the outdoor unit. See unit data label for proper incoming field wiring. Any other wiring methods must be acceptable to authority having jurisdiction.
- It is recommended that the line voltage to the unit be supplied from a dedicated branch circuit containing the correct fuse or circuit breaker for the unit.
- Overcurrent protection must be provided at the branch circuit distribution panel and sized as shown on the unit rating label and according to applicable local codes. See the unit rating plate and Table 9 (page 20) for maximum circuit ampacity and maximum overcurrent protection limits.
- The installer should become familiar with the wiring diagram/schematic before making any electrical connections to the unit. See the unit wiring label or Figures 14 - 16.
- Use only copper wire for the line voltage power supply to this unit. Use proper code agency listed conduit and

a conduit connector for connecting the supply wires to the unit. Aluminum supply wire may be used if a heater kit is installed.

- If replacing any of the original wires supplied with the unit, the replacement wire must be copper wire consisting of the same gauge and temperature rating.
- Provide power supply for the unit in accordance with the unit wiring diagram, and the unit rating plate. Use UL listed conduit and conduit connectors for connecting the supply wires to the unit and for proper grounding. Field supplied bushings for the power supply cables must be added to support and protect the power supply cables.
- All 208/230 Volt units are shipped from the factory wired for 240 volt operation. For 208V operation, remove the lead from the transformer terminal marked 240V and connect it to the terminal marked 208V.

Thermostat Connections

- Thermostat connections shall be in accordance with the instructions supplied with the thermostat. The thermostat used with this equipment must operate in conjunction with any installed accessories. Typical AC and air handler hookups are shown in Figure 9 (page 21).

CAUTION:

Isolation must be maintained from the external Class 2 output of any transformer in a cooling circuit. Use a thermostat with isolating contacts to prevent inter-connection of Class 2 outputs.

- Where local codes require that the thermostat wiring must be routed through a conduit or raceway, splices can be made inside the unit; however, all wiring must be NEC Class 1 and must be separated from incoming power leads.
- The thermostat should be mounted about 5 feet above the floor on an inside wall. **DO NOT** install the thermostat on an outside wall or any other location where its operation may be adversely affected by radiant heat from fireplaces, sunlight, or lighting fixtures, and convective heat from warm air registers or electrical appliances. Refer to the thermostat manufacturer's instruction sheet for detailed mounting and installation information.
- Install the grommet, which is packed with the unit, in the hole for low-voltage wires. Properly connect the low-voltage wiring between the thermostat, outdoor unit, and control board. **NOTE:** When the low voltage wires are positioned in this grommet, the grommet will prevent chafing and/or shorting of the low voltage leads

Important! On variable speed models when the unit is used in an air conditioning system, connect the **O** terminal to the **Y** terminal. See Figure 9 (page 20).

Control Board

The control board in the air handler controls the timing sequence of the elements. Depending on the thermostat connection, there are multiple timing sequence variations that can be chosen. The board also is equipped with a 3 second blower on delay and a 15 second blower off delay. See Figures 10 - 13 (pages 22 & 23) for control board layout and Tables 10 & 11 (pages 27-29) for element sequences.

Twining

MB7 air handlers are not supplied with a built in twinning capability. To connect two air handlers to a common single stage AC condensing unit or heat pump, a twinning kit is available for field installation. **IMPORTANT: Variable speed air handlers cannot be twinned. Please follow the instructions supplied with the kit.**

Heater Kits

Field-installed electric heater kits are available. Instructions for installing the electric heaters are included with the heaters. Additional heater kit information can be found in the units Technical Specifications.

Air handlers set up with 15 kw or more of electric heat will normally be configured for multiple-circuit power supply. They may, however, be connected to a single-circuit power supply with the addition of a single circuit accessory kit. Select the wire size and over-current protection in accordance with the minimum circuit ampacity and maximum over-current protection shown in Table 9. See also the units Technical Specifications.

When electric heat packages with circuit breakers are field-installed, the circuit breaker may be used as a disconnecting means in most applications. Reference the NEC and local codes for disconnect requirements.

If a heater kit is installed:

The MB7 air handler is shipped from the factory without an electric heater kit installed. If Electric heat is desired, the H6HK heater kit may be purchased separately and field installed. Determine the correct size heater kit for your unit by referring to the list below or the units rating label.

- A Size Cabinet..... 15Kw max
- B Size Cabinet..... 20Kw max
- C Size Cabinet..... 20Kw max

1. Connect the 2 wire plug of the air handler to the mating 2 wire plug of the heater kit.
2. Connect the line voltage leads to the circuit breaker or terminal block provided.
3. Connect the heater kit plug with the mating receptacle on the air handler control board.

If a heater kit is not installed:

1. Remove the 2 wire plug of the air handler by cutting the wires and discarding the plug.
2. Strip the ends of the 2 air handler wires and connect to the line-voltage leads with the 2 wire nuts provided.

Electronic Air Cleaner (EAC)

The unit has an output to power an electronic air cleaner when the blower is running. This output is rated to 1.0 amp at 208/240V.

Humidifier

The unit has an output to power a humidifier when the blower is running. This output is rated to 1.0 amp at 208/240V.

Optional Humidistat

(MB7EM or MB7VM Models Only)

The optional humidistat may be installed in the return air duct to provide excellent humidity control when needed and maximum system capacity and energy efficiency when humidity levels are normal. The humidistat senses when humidity in the return air stream is above a preset level (field adjustable) and sends a signal to the motor to reduce the airflow so that more moisture may be removed until the humidity level drops. The air handler is pre-programmed for humidistat operation.

Install the humidistat in the return air duct as directed in the installation instructions included with the kit. Wire the humidistat through the low-voltage wire entrance in the air handler to the control board terminal marked **DEHUM**. Wire the humidistat to open on rise in humidity.

Grounding

WARNING:

The unit cabinet must have an uninterrupted or unbroken electrical ground to minimize personal injury if an electrical fault should occur. Do not use gas piping as an electrical ground!

This unit must be electrically grounded in accordance with local codes or, in the absence of local codes, with the National Electrical Code (ANSI/NFPA 70) or the CSA C22.1 Electrical Code. Use the grounding lug provided in the control box for grounding the unit.

STARTUP & ADJUSTMENTS

Before You Start the Air Handler

Prior to start-up, complete the following inspections:

- √ Verify the unit is level and properly located with adequate clearances for servicing the unit. See Table 1 (page 4).
- √ Check condensate drain line(s) for proper drainage.
- √ Verify the surrounding area and top of the unit is free from obstructions and debris.
- √ Check all duct connections. Make sure the duct work is adequately sealed to prevent air leakage.
- √ Check all coil connections for leaks.
- √ Verify that the line voltage power leads are securely connected and the unit is properly grounded. Make sure all doors are installed before restoring power to the unit
- √ Verify the thermostat is wired correctly. Make sure all low voltage wires are securely connected.
- √ Verify the power supply branch circuit overcurrent protection is sized properly.
- √ Verify filter is properly and securely installed.

Air Circulation Check

Running the Blower Continuously

Set the thermostat's system mode to **OFF** and the thermostat's fan mode to **ON**. The blower motor should run continuously. Check for air delivery at the register(s). Make sure that there are no obstructions at the registers or in the ducts.

System Cooling

1. Set the thermostat's system mode to **COOL** and fan mode to **AUTO**. Lower the thermostat's temperature mode below room temperature and observe that the blower energizes. Check the air being discharged at the register is cooler than room temperature. Verify unit refrigerant pressures are in order. Blower should be turning in direction indicated by arrow.

NOTE: DO NOT alter unit wiring. Listen for any unusual noises. Locate the source and correct as needed.

2. Allow the unit to run for several minutes and then set the thermostat's temperature above room temperature. Verify the blower cycles off with the thermostat.

System Heating

1. Set the thermostat's system mode to **HEAT** and the fan mode to **AUTO**. Increase the thermostat's temperature above room temperature and observe that the blower energizes. Check the air being discharged at the register is warmer than room temperature.

2. Allow the unit to run for several minutes and then set the thermostat's temperature below room temperature. Verify the blower cycles off with the thermostat.

Turning the Blower Off

Set thermostat's fan mode to **AUTO**, the blower will shut down immediately.

Blower Configurations

Selecting Minimum Electric Heat Airflow

The minimum electric heat airflow setting controls the minimum air flow that will be produced whenever electric heater kits are used. When the electric heater kit is energized along with a heat pump, the airflow may be higher depending on the basic cooling/heat-pump airflow setting. The minimum electric heat airflow is selected by the red blower wire on 3-speed models or setting switches 1,2,3 & 4 on B7EM models. B7VM models automatically set the heating speed based on the amount of installed heat. Switch settings are listed in Tables 5, 6 & 8 (pages 17, 18, & 19). **NOTE:** The minimum electric heat airflow setting may be set higher, but must never be set lower than the setting shown in Table 6 (page 18).

Determining Nominal System Capacity

To select the appropriate airflows for the air handler, the nominal system capacity must be known. The nominal system capacity is always the nominal capacity of the outdoor unit. However, in some situations the nominal system capacity may not be the same as the nominal capacity of the air handler. Always refer to the nominal capacity of the outdoor unit to determine the nominal system capacity.

NOTE: The CFM values listed in Table 8 (page 19) are not dependent on duct static pressure. The VSHE motor automatically compensates for changes in duct static pressure (within the limits of the motor).

3-Speed Units

The blower speed is preset at the factory for operation at the same speed for heating and cooling, by using the jumping terminal on the blower motor and connecting it to the desired speed with both the red and black wires connected to the jumping terminal. **NOTE:** The control board is programmed with a 40 second off delay in the cooling mode for optimum system performance and efficiency.

CAUTION:

To avoid personal injury or property damage, make sure the motor leads do not come into contact with any uninsulated metal components of the unit.

For optimum system performance and comfort, it may be necessary to change the factory set speed. See Table 4 (page 16) for airflow data. To change the blower speed:

1. Disconnect all electrical power to the unit and remove the upper door.
2. Remove the black and red wires from the blower motor jumping terminal. Discard the blower motor jumping terminal.
3. Connect the heating speed wire (red) and the cooling speed wire (black) to the desired blower speed marked on the terminal block of the blower motor.

- Terminal 4 = Hi speed
- Terminal 5 = Med speed
- Terminal 6 = Low speed

4. Replace the upper door and secure it to the unit.
5. Restore power to the unit.

High Efficiency Units (Variable & Fixed Speed)

IMPORTANT! This air handler has been designed to give the installer maximum flexibility to optimize system performance, efficiency, and comfort. Because there are so many different ways to set up the air handler it is important to read and follow these directions carefully.

B7EM & B7VM air handlers use high efficiency circulating air motors that come in two variations and both are controlled differently. The fixed speed motor control board (Figure 12, page 23) controls the torque and the variable speed motor control board (Figure 13) controls the airflow at a constant CFM. Both boards use the same control board.

Before operation, the air handler must be configured to match the unit with the system, system options, and climatic conditions. When configured, the air handler responds directly to the thermostat inputs, as well as the optional humidistat (see page 12). During normal operation, the motor will gradually change speeds during start-up, shut down, when thermostat inputs change, and when the duct static pressure changes (vents closed or opened, filter clogging, etc.). The air handler is configured by setting the selector switches and removing jumper connectors.

Selecting Basic Heating Airflow

Fixed & variable speed motor control boards (Figures 12 & 13) contain a set of dip switches for setting the blower speed. Use pins 1 to 4 to set the blower speed for heating and pins 5 to 8 to set the speed for cooling. To determine the appropriate switch settings for your installation, see Tables 5 - 8 (pages 17-19).

Selecting Basic Cooling / Heat Pump Airflow

The basic cooling/heat-pump airflow is controlled by setting switches 5 - 8 on the thermostat input board (mounted on the blower). All airflows for other modes of operation (except electric heat) are determined by this basic setting. FAN ONLY would deliver 50% of the selected cooling airflow. Table 5 lists the basic airflow values versus the airflow selector switch settings and ranges of basic air flow settings recommended for each nominal system capacity.

- When operating in the heat pump mode, a higher basic airflow setting will increase the energy efficiency and capacity but will also decrease the supply air temperature.
- For maximum capacity and energy efficiency, select an airflow at or near the top of the range for that nominal capacity. See Table 7 (page 18).
- For maximum dehumidification, select an airflow near the middle or bottom of the range for that nominal capacity. Additional information on humidity control can be found in the Humidistat and Delay Setting sections.
- For thermostats with a dehumidifier output, use a field supplied wire to connect the thermostat's dehumidifier

output to the terminal marked **DHUM**. The thermostat should be set so that the **DHUM** output should be high (positive) when dehumidification is needed. See also Dehumidification Options section.

IMPORTANT! If coil icing is observed, the basic cooling/heat-pump airflow selected may be too low. Verify the setting selected is within the range shown in Table 7 and that the the system is properly charged. Please refer to the instructions supplied with the outdoor unit. If icing continues to occur, raise the selected airflow one or two steps.

NOTE: Variable speed air handlers with SEER ratings higher than 15 are matched with a 2-stage cooling outdoor unit. They are programmed to operate at 75% of the selected airflow while the system is in the lo-cool mode and 100% of the selected airflow while in hi-cool mode.

Dehumidification Options

(B7EM or B7VM Models Only)

Both motor control boards (Figures 12 & 13, page 23) have a **DHUM** connection that allows the system to increase the amount of humidity that is removed from the circulating air. This is accomplished by reducing the CFM and allowing the cooling coil to become colder. This will only occur when there is a call for cooling. There are many ways that this can be electrically wired.

1. If the room thermostat incorporates a humidity sensor and **DHUM** output, connect the **DHUM** on the thermostat to the **DHUM** terminal on the motor control board. See Figure 6.
2. If using a separate humidistat, connect the **DHUM** & **R** terminals on the humidistat to the **DHUM** & **R** terminals on the motor control board of the air handler. In this option, the **DHUM** output of the humidistat must be set to be normally open and closed when there is a call for humidification.
3. If a humidistat is not available, it is an acceptable option to connect the **R** & **DHUM** terminals on the motor control board together with a field supplied wire. This option causes the blower to run at a reduced CFM for 10 minutes after a call for cooling. **NOTE:** If outdoor unit is a heat pump, connect the **O** terminal to **DHUM**.




Figure 6. DHUM Wiring Configuration

UNIT MAINTENANCE

Proper maintenance is most important to achieve the best performance from an air handler. Some of the components and their locations are shown in Figure 8 (page 15). If any component of the air handler must be replaced, use only factory authorized replacement parts specified in the Replacement Parts List provided online.

WARNING:

ELECTRICAL SHOCK, FIRE OR EXPLOSION HAZARD

Failure to follow safety warnings exactly could result in serious injury or property damage.

Improper servicing could result in dangerous operation, serious injury, death or property damage.

- **Before servicing, disconnect all electrical power to the air handler.**
 - **When servicing controls, label all wires prior to disconnecting. Reconnect wires correctly.**
 - **Verify proper operation after servicing.**
-
- These maintenance instructions are primarily intended to assist qualified technicians experienced in the proper maintenance and operation of this appliance.
 - Always reinstall the doors on the air handler after servicing or cleaning/changing the filters. Do not operate the air handler without all doors and covers in place.
 - To achieve the best performance and minimize equipment failure, it is recommended that a yearly maintenance checkup be performed. At a minimum, this check should include the following items:

Air Filter(s)

WARNING:

Never operate the air handler without a filter in place. Dust and lint in the return air can build up on internal components, resulting in loss of efficiency, equipment damage, and possible fire.

Inspect and replace the air filter at the beginning of heating and cooling season. It is recommended that the filter be cleaned or replaced monthly. Newly built or recently renovated homes may require more frequent changing until the construction dust has minimized. Filters designed to remove smaller particles such as pollen, may require additional maintenance.

Blower Compartment

Dirt and lint can create excessive loads on the motor resulting in higher than normal operating temperatures and shortened service life. It is recommended that the blower compartment be cleaned of dirt or lint that may have accumulated in the compartment or on the blower and motor as part of the annual inspection.

Blower Fan Wheel

Inspect the blower wheel blades for accumulations of dirt and clean if necessary. Inspect mounting nut for tightness.

Blower Motor & Assembly

Inspect the blower assembly and motor mounting brackets for tightness and corrosion. Correct deficiencies if necessary. The blower motor contains sealed bearings and under normal operating conditions, no maintenance is necessary for the life of the equipment.

Cooling Coil

Inspect the cooling coil, drain pan, and condensate drain at the beginning of each cooling season for cleanliness. Clean these components as necessary using a mild detergent and water. After cleaning, flush the coil, drain pan, and condensate drain to remove all detergent.

IMPORTANT: Use caution when cleaning these components so that the insulation does not get wet.

TROUBLESHOOTING

If the air handler fails to operate, check the following:

- Is the electric turned on?
- Is the thermostat operating properly?
- Are the blower compartment door(s) in place?
- Is the air handler disconnect closed?
- Has the circuit breaker tripped or the control board fuse burned open?
- Are any manual reset switches open?
- Is the filter dirty or plugged?
- Is the LED on both control boards constantly ON? If not, refer to Tables 2 or 3 to determine fault condition.

RED LED (AN2)	DIAGNOSTIC
OFF	Control Fault (No Power)
Flash	Blower Fault
ON	Normal Operation

Table 2. Air handler Control Board Fault Conditions

	DIAGNOSTIC	GREEN LED	RED LED
Fixed Speed Furnaces	Control Fault (No Power)	Off	Off
	Normal Operation	On	On
	Motor Fault	On	Flash
	Twin Fault (no motor fault)	Flash	On
	Communications Fault	Flash	Flash
Variable Speed Furnaces	Control Fault (No Power)	Off	Off
	Normal Operation	On	On
	Motor Fault	On	Flash
	Communications Fault	Flash	Flash

Table 3. Motor Control Board Fault Conditions

FIGURES & TABLES




Figure 7. MB7 Series Physical Dimensions




Figure 8. MB7 Series Component Locations

BLOWER PERFORMANCE DATA

MB7BM Airflow Data

Dry Coil ESP		0.10	0.20	0.30	0.40	0.50	0.60	0.70	0.80
0800 A-Cabinet	Low	685	645	605	565	515	465	405	345
	<i>Corrected ESP¹</i>		<i>0.07</i>	<i>0.19</i>	<i>0.30</i>	<i>0.42</i>	<i>0.53</i>	<i>0.65</i>	<i>0.76</i>
	Med	860	825	780	735	680	625	565	500
	<i>Corrected ESP¹</i>			<i>0.11</i>	<i>0.23</i>	<i>0.36</i>	<i>0.48</i>	<i>0.60</i>	<i>0.72</i>
	High	1070	1025	975	920	860	800	730	660
<i>Corrected ESP¹</i>				<i>0.14</i>	<i>0.27</i>	<i>0.40</i>	<i>0.53</i>	<i>0.67</i>	
1200 A-Cabinet	Low	850	825	795	755	705	645	580	510
	<i>Corrected ESP¹</i>		<i>0.04</i>	<i>0.15</i>	<i>0.27</i>	<i>0.38</i>	<i>0.50</i>	<i>0.62</i>	<i>0.74</i>
	Med	1120	1085	1045	995	940	875	800	715
	<i>Corrected ESP¹</i>			<i>0.04</i>	<i>0.17</i>	<i>0.29</i>	<i>0.42</i>	<i>0.55</i>	<i>0.68</i>
	High	1275	1235	1185	1130	1070	1005	935	860
<i>Corrected ESP¹</i>				<i>0.10</i>	<i>0.23</i>	<i>0.36</i>	<i>0.49</i>	<i>0.63</i>	
1200 B-Cabinet	Low	995	955	910	845	780	705	610	530
	<i>Corrected ESP¹</i>		<i>0.08</i>	<i>0.19</i>	<i>0.31</i>	<i>0.42</i>	<i>0.54</i>	<i>0.65</i>	<i>0.76</i>
	Med	1335	1290	1235	1175	1100	1015	925	805
	<i>Corrected ESP¹</i>			<i>0.10</i>	<i>0.22</i>	<i>0.34</i>	<i>0.46</i>	<i>0.59</i>	<i>0.71</i>
	High	1470	1425	1360	1300	1225	1135	1050	920
<i>Corrected ESP¹</i>				<i>0.08</i>	<i>0.22</i>	<i>0.37</i>	<i>0.51</i>	<i>0.65</i>	
1600 C-Cabinet	Low	1035	1005	970	925	875	825	770	710
	<i>Corrected ESP¹</i>		<i>0.11</i>	<i>0.22</i>	<i>0.33</i>	<i>0.44</i>	<i>0.54</i>	<i>0.65</i>	<i>0.76</i>
	Med	1635	1595	1525	1475	1405	1305	1210	1060
	<i>Corrected ESP¹</i>			<i>0.08</i>	<i>0.20</i>	<i>0.32</i>	<i>0.44</i>	<i>0.57</i>	<i>0.69</i>
	High	1910	1840	1760	1685	1595	1495	1395	1250
<i>Corrected ESP¹</i>				<i>0.14</i>	<i>0.26</i>	<i>0.39</i>	<i>0.52</i>	<i>0.65</i>	
2000 C-Cabinet	Low	1520	1510	1500	1485	1465	1440	1415	1385
	<i>Corrected ESP¹</i>		<i>0.11</i>	<i>0.21</i>	<i>0.31</i>	<i>0.42</i>	<i>0.52</i>	<i>0.62</i>	<i>0.72</i>
	Med	1900	1885	1860	1830	1790	1740	1680	1620
	<i>Corrected ESP¹</i>		<i>0.06</i>	<i>0.16</i>	<i>0.27</i>	<i>0.37</i>	<i>0.48</i>	<i>0.59</i>	<i>0.70</i>
	High	2245	2195	2135	2080	2015	1950	1885	1800
<i>Corrected ESP¹</i>			<i>0.12</i>	<i>0.23</i>	<i>0.34</i>	<i>0.45</i>	<i>0.56</i>	<i>0.67</i>	

¹ ESP estimate with wet coil and filter

Table 4. Airflow Data for MB7BM Air Handlers

	Switch Settings				Cooling or Heating Airflow (CFM)							
					Dry Coil ESP							
	1/5	2/6	3/7	4/8	0.1	0.2	0.3	0.4	0.5	0.6	0.7	0.8
B7EM A-cabinet	0	0	0	0	585	550	520	460	420	405		
	1	0	0	0	710	670	650	610	560	530	475	440
	0	1	0	0	845	790	765	715	680	655	625	580
	1	1	0	0	890	865	840	785	760	710	680	655
	0	0	1	0	955	925	900	850	825	790	770	720
	1	0	1	0	1030	995	975	940	910	870	840	815
	0	1	1	0	1115	1085	1060	1020	995	965	925	905
	1	1	1	0	1155	1130	1095	1070	1040	1010	985	950
	0	0	0	1	1200	1175	1145	1110	1085	1060	1025	1000
	1	0	0	1	1240	1215	1195	1170	1140	1110	1080	1060
	0	1	0	1	1320	1290	1265	1240	1215	1185	1160	1130
	1	1	0	1	1355	1330	1305	1280	1255	1220	1200	1175
	0	0	1	1	1405	1375	1345	1325	1295	1275	1250	1210
	1	0	1	1	1440	1415	1385	1355	1325	1290	1255	1215
	0	1	1	1	1465	1425	1390	1355	1320	1290	1260	1215
1	1	1	1	1465	1425	1390	1355	1320	1290	1260	1215	
B7EM B-cabinet	Switch Setting				Cooling or Heating Airflow (CFM)							
					Dry Coil ESP							
	1/5	2/6	3/7	4/8	0.1	0.2	0.3	0.4	0.5	0.6	0.7	0.8
	0	0	0	0	600	550	430	390				
	1	0	0	0	660	610	540	460	425			
	0	1	0	0	830	750	695	640	580	520		
	1	1	0	0	860	825	765	690	630	600	525	485
	0	0	1	0	935	895	835	790	710	655	620	585
	1	0	1	0	1045	975	920	875	830	795	720	685
	0	1	1	0	1095	1040	995	950	900	850	805	750
	1	1	1	0	1155	1105	1060	1010	965	920	870	825
	0	0	0	1	1230	1185	1140	1090	1045	1010	965	920
	1	0	0	1	1285	1260	1210	1165	1125	1080	1040	1010
	0	1	0	1	1330	1290	1245	1205	1170	1125	1085	1045
	1	1	0	1	1395	1365	1315	1275	1235	1205	1160	1130
0	0	1	1	1450	1405	1375	1335	1295	1260	1220	1180	
1	0	1	1	1490	1450	1410	1385	1340	1300	1270	1230	
0	1	1	1	1530	1485	1460	1425	1380	1350	1310	1280	
1	1	1	1	1530	1490	1465	1425	1390	1350	1310	1285	
B7EM C-cabinet	Switch Setting				Cooling or Heating Airflow (CFM)							
					Dry Coil ESP							
	1/5	2/6	3/7	4/8	0.1	0.2	0.3	0.4	0.5	0.6	0.7	0.8
	0	0	0	0	710	580	395					
	1	0	0	0	830	690	675	530	505			
	0	1	0	0	930	875	710	665	560	530		
	1	1	0	0	1065	1015	900	840	800	705	665	635
	0	0	1	0	1185	1115	1010	960	925	875	830	745
	1	0	1	0	1275	1220	1175	1120	1060	970	930	890
	0	1	1	0	1365	1350	1255	1200	1150	1105	1060	1025
	1	1	1	0	1480	1430	1370	1325	1265	1225	1185	1140
	0	0	0	1	1560	1535	1485	1430	1375	1335	1285	1240
	1	0	0	1	1650	1600	1545	1500	1450	1405	1360	1305
	0	1	0	1	1730	1685	1660	1610	1570	1520	1470	1420
	1	1	0	1	1785	1740	1695	1645	1615	1545	1510	1470
0	0	1	1	1865	1820	1785	1750	1695	1655	1605	1560	
1	0	1	1	1920	1890	1850	1805	1765	1715	1675	1640	
0	1	1	1	2010	1965	1960	1900	1850	1810	1775	1730	
1	1	1	1	2065	2020	1985	1955	1915	1880	1840	1810	

NOTE: 0 = OFF, 1 = ON

Table 5. Airflow Data for MB7EM Air Handlers

Cabinet	Nominal Electric Heat KW				
	5	8	10	15	20
A	800	900	1000	1300	N/A
B	900	1000	1100	1300	1500
C	1000	1100	1200	1400	1600

Table 6. Minimum Heating Airflow Settings (in CFM) for MB7EM (FSHE) Air Handlers

A-CABINET						
CFM	SWITCH SETTINGS (1 = ON, 0 = OFF)				NOMINAL CAPACITY	
	1	2	3	4		
525	0	0	0	0	1.5 TON	
560	0	0	0	1		
600	0	0	1	0		
625	0	0	1	1		
700	0	1	0	0		2 TON
750	0	1	0	1		
800	0	1	1	0		2.5 TON
850	0	1	1	1		
875	1	0	0	0		
890	1	0	0	1		
930	1	0	1	0		
950	1	0	1	1		
1000	1	1	0	0		3 TON
1050	1	1	0	1		
1125	1	1	1	0		
1200	1	1	1	1		

B-CABINET						
CFM	SWITCH SETTINGS (1 = ON, 0 = OFF)				NOMINAL CAPACITY	
	1	2	3	4		
525	0	0	0	0	1.5 TON	
560	0	0	0	1		
600	0	0	1	0		
650	0	0	1	1		
700	0	1	0	0		2 TON
750	0	1	0	1		
800	0	1	1	0		2.5 TON
850	0	1	1	1		
875	1	0	0	0		
950	1	0	0	1		
1050	1	0	1	0		
1150	1	0	1	1		
1250	1	1	0	0		3.5 TON
1350	1	1	0	1		
1400	1	1	1	0		
1600	1	1	1	1		

C-CABINET						
CFM	SWITCH SETTINGS (1 = ON, 0 = OFF)				NOMINAL CAPACITY	
	1	2	3	4		
1100	0	0	0	0	3 TON	
1200	0	0	0	1		
1250	0	0	1	0		
1300	0	0	1	1		
1350	0	1	0	0		3.5 TON
1400	0	1	0	1		
1450	0	1	1	0		4 TON
1500	0	1	1	1		
1550	1	0	0	0		
1600	1	0	0	1		
1650	1	0	1	0		
1700	1	0	1	1		
1750	1	1	0	0		
1800	1	1	0	1		
1900	1	1	1	0		
2000	1	1	1	1		

Table 7. Recommended Cooling Airflow Settings for MB7VM Air Handlers

	Cooling Airflow					Airflow (CFM)
	HEAT Switch Setting A/B	COOL Switch Setting				
		1	2	3	4	
B7VM A-cabinet	0	0	0	0	0	525
	0	0	0	0	1	560
	0	0	0	1	0	600
	0	0	0	1	1	625
	0	0	1	0	0	700
	0	0	1	0	1	750
	0	0	1	1	0	800
	0	0	1	1	1	850
	0	1	0	0	0	875
	0	1	0	0	1	890
	0	1	0	1	0	930
	0	1	0	1	1	950
	0	1	1	0	0	1000
	0	1	1	0	1	1050
	0	1	1	1	0	1125
	0	1	1	1	1	1200

Heating Airflow		
HEAT Switch Setting A/B	Heater Kit Installed (KW)	Airflow (CFM)
0	0	600
0	5	800
0	8	900
0	10	1000
0	15	1300
0	20	N/A
0	25	N/A
0	30	N/A

	Cooling Airflow					Airflow (CFM)
	HEAT Switch Setting A/B	COOL Switch Setting				
		1	2	3	4	
B7VM B-cabinet	1	0	0	0	0	525
	1	0	0	0	1	560
	1	0	0	1	0	600
	1	0	0	1	1	650
	1	0	1	0	0	700
	1	0	1	0	1	750
	1	0	1	1	0	800
	1	0	1	1	1	850
	1	1	0	0	0	875
	1	1	0	0	1	950
	1	1	0	1	0	1050
	1	1	0	1	1	1150
	1	1	1	0	0	1250
	1	1	1	0	1	1350
	1	1	1	1	0	1400
	1	1	1	1	1	1600

Heating Airflow		
HEAT Switch Setting A/B	Heater Kit Installed (KW)	Airflow (CFM)
1	0	700
1	5	900
1	8	1000
1	10	1100
1	15	1300
1	20	1500
1	25	N/A
1	30	N/A

	Cooling Airflow					Airflow (CFM)
	HEAT Switch Setting A/B	COOL Switch Setting				
		1	2	3	4	
B7VM C-cabinet	*	0	0	0	0	1100
	*	0	0	0	1	1200
	*	0	0	1	0	1250
	*	0	0	1	1	1300
	*	0	1	0	0	1350
	*	0	1	0	1	1400
	*	0	1	1	0	1450
	*	0	1	1	1	1500
	*	1	0	0	0	1550
	*	1	0	0	1	1600
	*	1	0	1	0	1650
	*	1	0	1	1	1700
	*	1	1	0	0	1750
	*	1	1	0	1	1800
	*	1	1	1	0	1900
	*	1	1	1	1	2000

Heating Airflow		
HEAT Switch Setting A/B	Heater Kit Installed (KW)	Airflow (CFM)
*	0	800
*	5	1000
*	8	1100
*	10	1200
*	15	1400
*	20	1600
*	25	N/A
*	30	N/A

NOTES:

Airflow values listed are for 240V operation. For 208V operation, multiply A & B cabinet values by .95; for C-cabinet values multiply by .90

* = either 0 or 1
0 = OFF, 1 = ON

Table 8. Airflow Data for MB7VM (VSHE) Air Handlers

ELECTRICAL DATA & DIAGRAMS


MB7BM																		
CABINET	CAPACITY	HEAT KI MODEL NUMBER 6HK-	240 VAC, 50 & 60 HZ, SINGLE PHASE								208 VAC, 50 & 60 HZ, SINGLE PHASE							
			MCA				MOP				MCA				MOP			
			CIRCUIT A	CIRCUIT B	CIRCUIT C	SINGLE CIRCUIT	CIRCUIT A	CIRCUIT B	CIRCUIT C	SINGLE CIRCUIT	CIRCUIT A	CIRCUIT B	CIRCUIT C	SINGLE CIRCUIT	CIRCUIT A	CIRCUIT B	CIRCUIT C	SINGLE CIRCUIT
A	800CFM	None	1.6	-	-	1.6	15	-	-	15	1.6	-	-	1.6	15	-	-	15
		005H-XX	26.6	-	-	26.6	30	-	-	30	23.3	-	-	23.3	25	-	-	25
		008H-XX	41.2	-	-	41.2	45	-	-	45	35.9	-	-	35.9	40	-	-	40
		010H-XX	51.6	-	-	51.6	60	-	-	60	45.0	-	-	45.0	45	-	-	45
		015H-XX	51.6	25	-	76.6	60	30	-	80	45.0	21.7	-	66.6	45	25	-	70
B	1200CFM	None	2.6	-	-	2.6	15	-	-	15	2.6	-	-	2.6	15	-	-	15
		005H-XX	27.6	-	-	27.6	30	-	-	30	24.3	-	-	24.3	25	-	-	25
		008H-XX	42.2	-	-	42.2	45	-	-	45	36.9	-	-	36.9	40	-	-	40
		010H-XX	52.6	-	-	52.6	60	-	-	60	46.0	-	-	46.0	50	-	-	50
		015H-XX	52.6	25.0	-	64.7	60	30	-	80	46.0	21.7	-	67.6	50	25	-	70
		020H-XX	52.6	50.0	-	102.6	60	60	-	110	46.0	43.3	-	89.3	50	45	-	90
C	1600CFM	None	3.1	-	-	3.1	15	-	-	15	3.1	-	-	3.1	15	-	-	15
		005H-XX	28.1	-	-	28.1	30	-	-	30	24.8	-	-	24.8	25	-	-	25
		008H-XX	42.7	-	-	42.7	45	-	-	45	37.4	-	-	37.4	40	-	-	40
		010H-XX	53.1	-	-	53.1	60	-	-	60	46.5	-	-	46.5	50	-	-	50
		015H-XX	53.1	-	-	65.6	60	-	-	80	46.5	21.7	-	68.1	50	25	-	70
		020H-XX	53.1	-	-	103.1	60	-	-	110	46.5	43.3	-	89.8	50	45	-	90
C	2000CFM	None	5	-	-	5	15	-	-	15	5	-	-	5	15	-	-	15
		005H-XX	30	-	-	30	35	-	-	35	26.7	-	-	26.7	30	-	-	30
		008H-XX	44.6	-	-	44.6	45	-	-	45	39.3	-	-	39.3	40	-	-	40
		010H-XX	55	-	-	55	60	-	-	60	48.3	-	-	48.3	50	-	-	50
		015H-XX	55	25	-	80	60	30	-	80	48.3	21.7	-	70.0	50	25	-	70
		020H-XX	55	50	-	105	60	60	-	110	48.3	43.3	-	91.7	50	45	-	100
MB7(E,V)M																		
A	1200CFM	None	4.5	-	-	4.5	15	-	-	15	4.8	-	-	4.8	15	-	-	15
		005H-XX	29.5	-	-	29.5	30	-	-	30	26.4	-	-	26.4	30	-	-	30
		008H-XX	44.1	-	-	44.1	45	-	-	45	39.1	-	-	39.1	40	-	-	40
		010H-XX	54.5	-	-	54.5	60	-	-	60	48.1	-	-	48.1	50	-	-	50
		015H-XX	54.5	25.0	-	68.1	60	30	-	80	48.1	21.7	-	69.8	50	25	-	70
B	1600CFM	None	4.5	-	-	4.5	15	-	-	15	4.8	-	-	4.8	15	-	-	15
		005H-XX	29.5	-	-	29.5	30	-	-	30	26.4	-	-	26.4	30	-	-	30
		008H-XX	44.1	-	-	44.1	45	-	-	45	39.1	-	-	39.1	40	-	-	40
		010H-XX	54.5	-	-	54.5	60	-	-	60	48.1	-	-	48.1	50	-	-	50
		015H-XX	54.5	-	-	68.1	60	-	-	80	48.1	-	-	69.8	50	-	-	70
		020H-XX	54.5	50.0	-	104.5	60	60	-	110	48.1	43.3	-	91.4	50	45	-	100
C	2000CFM	None	6.3	-	-	6.3	15	-	-	15	6.8	-	-	6.8	15	-	-	15
		005H-XX	31.3	-	-	31.3	35	-	-	35	28.4	-	-	28.4	30	-	-	30
		008H-XX	45.8	-	-	45.8	50	-	-	50	41.1	-	-	41.1	45	-	-	45
		010H-XX	56.3	-	-	56.3	60	-	-	60	50.1	-	-	50.1	60	-	-	60
		015H-XX	56.3	-	-	81.3	60	-	-	90	50.1	-	-	71.8	60	-	-	80
		020H-XX	56.3	-	-	106.3	60	-	-	110	50.1	-	-	93.4	60	-	-	100

*All wire sizes for copper conductors only, based on NEC Table 310-16.


**Required for C-cabinet variable speed.

***Circuit ampacity slightly higher for variable speed. See label on blower.


Table 9. Minimum Circuit Ampacity & Maximum Overcurrent Protection




Typical Air Conditioner with Standard Air Handler




Typical Air Conditioner with Variable Speed Air Handler




Typical 2-Stage Air Conditioner with Variable Speed Air Handler



Typical Heat Pump with Standard Air Handler



Typical Heat Pump with Variable Speed Air Handler



Typical 2-Stage Heat Pump with Variable Speed Air Handler

Figure 9. Typical Thermostat Connections




Figure 10. Single Stage Control Board (MB7BM Models)




Figure 11. Two - Stage Control Board (MB7EM / VM Models)




Figure 12. Two-Stage Fixed Speed Motor Control Board (MB7EM Models)





Figure 13. Two-Stage Variable Speed Motor Control Board (MB7VM Models)

WIRING DIAGRAM

Air Handler



NOTES:

1. The blower motor speed tap connection may not be as shown. See the installation Instructions.
2. Disconnect all power before servicing.
3. Transformer may have a dual voltage primary tap. Match the tap position with the supply voltage used.
4. If the internal wiring is replaced, use only 105°C copper wire of the same gauge.



7110750
0510


Figure 14. Wiring Diagram for MB7BM Series Air Handler

WIRING DIAGRAM

Air Handler with Fixed Speed High Efficiency Motor

NOTES:

1. The blower motor speed tap connection may not be as shown. See the Installation Instructions.
2. Disconnect all power before servicing.
3. Transformer may have a dual voltage primary tap. Match the tap position with the supply voltage used.
4. If the internal wiring is replaced, use only 105°C copper wire of the same gauge.



7110760
0510

Figure 15. Wiring Diagram for MB7EM Series Air Handler

WIRING DIAGRAM

Air Handler with Variable Speed High Efficiency Motor




Figure 16. Wiring Diagram for MB7VM Series Air Handler

CONTROL SIGNAL & MODE	OPERATION	TOTAL KW	BOARD ACTION
W EHEAT	On	5 KW	Stage 1 Heat on instantly
			Heat blower on after 3 second delay
		10 KW	Stage 1 Heat on instantly
			Heat blower on after 3 second delay
			Stage 2 Heat on after 5 seconds delay
		15 KW	Stage 1 Heat on instantly
			Heat blower on after 3 second delay
			Stage 2 Heat on after 5 seconds delay
	20 KW	Stage 1 Heat on instantly	
		Heat blower on after 3 second delay	
		Stage 2 Heat on after 5 seconds delay	
		Stage 3 Heat on after 10 seconds delay	
	Off		Heat stages off instantly
			Blower off after 15 second delay
W & Y AUX HEAT	On	5 KW	Stage 1 Heat on instantly
			Cool blower on after 3 second delay
		10 KW	Stage 1 Heat on instantly
			Cool blower on after 3 second delay
			Stage 2 Heat on after 5 seconds delay
		15 KW	Stage 1 Heat on instantly
			Cool blower on after 3 second delay
			Stage 2 Heat on after 5 seconds delay
	20 KW	Stage 1 Heat on instantly	
		Cool blower on after 3 second delay	
		Stage 2 Heat on after 5 seconds delay	
		Stage 3 Heat on after 10 seconds delay	
	Off		Heat stages off instantly
			Heat blower turns off after 40 second delay
G FAN	On		Cool blower on after 3 second delay
	Off		Cool blower off instantly
Y HEAT PUMP & COOL	On		Cool Blower on after 3 second delay
	Off		Cool Blower off after 40 second delay

Table 10. Heating Element Logic for MB7BM Air Handlers

CONTROL SIGNAL & MODE	OPERATION	TOTAL KW	BOARD ACTION
W1 only EHEAT	ON	5 KW	Stage 1 Heat on instantly
			Heat blower on after 3 second delay
		10 KW	Stage 1 Heat on instantly
			Heat blower on after 3 second delay
		15 KW	Stage 1 Heat on instantly
			Heat blower on after 3 second delay
			Stage 2 Heat on after 5 second delay
		20 KW	Stage 1 Heat on instantly
	Heat blower on after 3 second delay		
	Stage 2 Heat on after 5 second delay		
OFF		Stage 3 Heat on after 10 second delay	
		Heat stages off instantly Blower off after 15 second delay	
W1 & W2 EHEAT	ON	5 KW	Stage 1 Heat on instantly
			Heat blower on after 3 second delay
		10 KW	Stage 1 Heat on instantly
			Heat blower on after 3 second delay
			Stage 2 Heat on after 5 seconds delay
		15 KW	Stage 1 Heat on instantly
			Heat blower on after 3 second delay
			Stage 2 Heat on after 5 seconds delay
			Stage 3 Heat on after 10 seconds delay
		20 KW	Stage 1 Heat on instantly
	Heat blower on after 3 second delay		
	Stage 2 Heat on after 5 seconds delay		
	Stage 3 Heat on after 10 seconds delay		
OFF		Stage 4 Heat on after 15 seconds delay	
		Heat stages off instantly	
		Blower off after 15 second delay	

Table 11. Heating Element Logic for MB7EM / MB7VM Series Air Handler

CONTROL SIGNAL & MODE	OPERATION	TOTAL KW	BOARD ACTION
W1 & Y/Y2 AUX HEAT	ON	5 KW	Stage 1 Heat on instantly
			Cool blower on after 3 second delay
		10 KW	Stage 1 Heat on instantly
			Cool blower on after 3 second delay
		15 KW	Stage 1 Heat on instantly
			Cool blower on after 3 second delay
			Stage 2 Heat on after 5 seconds delay
			Stage 3 Heat on after 10 seconds delay
	20 KW	Stage 1 Heat on instantly	
		Cool blower on after 3 second delay	
OFF	Heat stages off instantly		
	Heat blower turns off after 40 second delay		
W1, W2 & Y/Y2 AUX HEAT	ON	5 KW	Stage 1 Heat on instantly
			Cool blower on after 3 second delay
		10 KW	Stage 1 Heat on instantly
			Cool blower on after 3 second delay
			Stage 2 Heat on after 5 seconds delay
		15 KW	Stage 1 Heat on instantly
			Cool blower on after 3 second delay
			Stage 2 Heat on after 5 seconds delay
			Stage 3 Heat on after 30 seconds delay
		20 KW	Stage 1 Heat on instantly
			Cool blower on after 3 second delay
			Stage 2 Heat on after 5 seconds delay
	Stage 3 Heat on after 10 seconds delay		
	Stage 4 Heat on after 15 seconds delay		
OFF	Heat stages off instantly		
	Heat blower turns off after 40 second delay		

Table 11. Continued

INSTALLATION / PERFORMANCE CHECK LIST

INSTALLER NAME:		
CITY:	STATE:	
INSTALLATION ADDRESS:		
CITY:	STATE:	
UNIT MODEL #		
UNIT SERIAL #		
Minimum clearances per page 4?	YES	NO
Is the unit properly installed and leveled?	YES	NO
Does condensate drain properly in both drain tubes? (If applicable)	YES	NO
Has the owner's information been reviewed with the home-owner?	YES	NO
Has the literature package been left near the appliance?	YES	NO

ELECTRICAL SYSTEM:		
Electrical connections tight?	YES	NO
Line voltage polarity correct?	YES	NO
Supply Voltage: _____(V)		
Has the thermostat been calibrated?	YES	NO
Is the thermostat level?	YES	NO
Is the heat anticipator setting correct?	YES	NO

VENTING SYSTEM:		
Filter properly installed?	YES	NO
Filter clean?	YES	NO
Return Air Temp: _____(° F)		
Supply Air Temp: _____(° F)		
Temperature Rise: _____(° F)		



NORDYNE
COMPLETE COMFORT. GENUINE VALUE.



Specifications & illustrations subject to change without notice or incurring obligations.
O' Fallon, MO | Printed in U.S.A. (12/11)

7091750 (NEW)