

# WIRING DIAGRAM

## Wall Mount Air Handler ECM (8KW/10KW)

### NOTES:

1. The blower motor speed tap connection may not be as shown. Refer to installation instructions provided with unit to set DIP switches for the appropriate heating and cooling speed setting for your application.
2. Disconnect all power before servicing.
3. The transformer may have a dual voltage primary tap. Match the tap position with the supply voltage used.
4. If the internal wiring is replaced, use only 105°C copper wire of the same gauge.
5. Connect 24VAC/40VA Class 2 circuit to thermostat. See air handler installation instructions for control circuit.

### Remarques

1. Le connecteur de vitesse du moteur du ventilateur peut différer de l'illustration. Consultez les Instructions d'installation.
2. Débranchez toutes les sources d'alimentation avant l'entretien.
3. Le transformateur peut avoir un robinet principal à double tension. Agencez la position du robinet au type de tension de l'installation.
4. Si le câblage interne est remplacé, utilisez seulement un fil de cuivre 105° C du même gabarit.
5. Branchez le circuit de 24 VAC/40 VA de Classe 2 au thermostat. Voyez les Directives d'installation de l'appareil de traitement de l'air pour le circuit de commande.

