

WIRING DIAGRAM

Wall Mount Air Handler (8KW/10KW)

NOTES:

- The blower motor speed tap connection may not be as shown.
See the Installation Instructions.
- Disconnect all power before servicing.
- The transformer may have a dual voltage primary tap.
Match the tap position with the supply voltage used.
- If the internal wiring is replaced, use only 105°C copper wire of the same gauge.

Remarques

- Le connecteur de vitesse du moteur du ventilateur peut différer de l'illustration. Consultez les Instructions d'installation.
- Débranchez toutes les sources d'alimentation avant l'entretien.
- Le transformateur peut avoir un robinet principal à double tension.
Agencez la position du robinet au type de tension de l'installation.
- Si le câblage interne est remplacé, utilisez seulement un fil de cuivre 105° C du même gabarit.

