## Wall Mount Air Handler

## **Installation Instructions**

## Louvered Panel Accessory, Vertical Wall Mount Air Handler (903892, 919583)

This louvered panel accessory is designed to be used to cover the wall-mount Air Handler in installations where the Air Handler is mounted flush with the wall surface.

- 1. Remove the (2) lower screws on the upper access panel.
- 2. Attach the door mounting bracket to the Air Handler with the (2) screws removed in step 1.
- 3. Slide the louvered panel on the front of the Air Handler until the mounting brackets interlock. The panel should be flush with the wall surface.





Specifications & illustrations subject to change without notice or incurring obligations (06/15). O'Fallon, MO, @ Nortek Global HVAC LLC 2015. All Rights Reserved.