


REPLACEMENT PARTS LIST

Light Commercial Air Handler - B5SM Series

For use with 7.5 & 10 Ton Split System AC and Heat Pumps



B5SM AIR HANDLER REPLACEMENT PARTS LIST

ITEM	DESCRIPTION	208-230/460-3-60	208-230-1-60	208-230/460-3-60	208-230-1-60
		090J	090K	120J	120K
1	Pan, Top	294071R	294071R	294071R	294071R
2	Bracket, Vertical, DP, Right	293651R	293651R	293651R	293651R
3	Panel, Front, Return	294081R	294081R	294081R	294081R
4	Bracket, Vertical, DP, Left	293661R	293661R	293661R	293661R
5	Cover, Return Air	292651R	292651R	292651R	292651R
6	Panel, Coil Access, LF	294121R	294121R	294121R	294121R
7	Pan, Drain, Vert, LF	293681R	293681R	293681R	293681R
8	Panel, Filter Access, LF	292711R	292711R	292711R	292711R
9	Complete Blower Assembly, 15" x 15"	667285	667285	667285	667285
10	Adapter, Filter Offset	295361R	295361R	295361R	295361R
11	Slider, Filter	295351R	295351R	295351R	295351R
12	Panel, Filter Rack, 2 Inch	293621R	293621R	293621R	293621R
13	Latch, Offset, Blk Handle	618080	618080	618080	618080
14	Panel, Filter Access, RT	292761R	292761R	292761R	292761R
15	Pan, Bottom	294151R	294151R	294151R	294151R
16	Panel, Back	294111R	294111R	294111R	294111R
17	Pan, Drain, Vert, RT	293671R	293671R	293671R	293671R
18	Panel, Close-Off	294141R	294141R	---	---
	Panel, Close-Off	---	---	294142R	294142R
19	Mount, Adjustable Motor, 143 Frame	667391	667391	667391	667391
20	Panel, Coil Access, RT	294131R	294131R	294131R	294131R
21	Panel, Top, LF & RT	294161R	294161R	294161R	294161R
22	Block, Terminal, 7 Pin (Not Shown)	632483	632483	632483	632483
23	Contactor, 2 Pole 20A	---	621668	---	621668
	Contactor, 3 Pole 30A	621667	---	621667	---
24	Box, Electrical, Top/Back	294171R	294171R	294171R	294171R
25	Support, Mtr, Slotted, H Bracket	293161R	293161R	293161R	293161R
26	Blower Motor	---	622295R	---	622295R
	Blower Motor	622142R	---	622142R	---
27	Sheave, 1VP40	667314	667314	667314	667314

B5SM AIR HANDLER REPLACEMENT PARTS LIST

ITEM	DESCRIPTION	208-230/460-3-60	208-230-1-60	208-230/460-3-60	208-230-1-60
		090J	090K	120J	120K
28	Pulley, Blower, Drive, BK100	667366	667366	---	---
	Pulley, Blower, Drive, BK80	---	---	667368	667368
29	Belt, Blower Drive, A36	669370	669370	---	---
	Belt, Blower Drive, A32	---	---	669676	669676
30	Complete Coil Assy, 090 (TXV/Distributor included)	297193R	297193R	---	---
	Complete Coil Assy, 120 (Distributors included, TXV not included)	---	---	297192R	297192R
31	Key, Blower Shaft (Not Shown)	618057	618057	618057	618057
32	Blower Power Cord (Not Shown)	634696		634696	
	Blower Power Cord (Not Shown)		634695	---	634695
33	Grommet, Flexible, 3/8" (Not Shown)	---	---	689086	689086
	Grommet, Flexible, 7/8" (Not Shown)	689089	689089	---	---
	Grommet, Flexible, 1" (Not Shown)	689977	689977	689977	689977
	Grommet, Flexible, 1.06" (Not Shown)	632415	632415	632415	632415
34	TXV, with internal check valve (Not Shown)	---	---	664576	664576
	TXV/Distributor with external check valve assy. (Not Shown)	664556	664556	---	---
35	PVC, Drain Tube, 3/4" (Not Shown)	656355	656355	656355	656355
36	PVC, Drain Plug, 3/4" (Not Shown)	656356	656356	656356	656356
37	Nut, Plastic-Knurl 3/4 FGH (Not Shown)	663656	663656	663656	663656
38	Filter,Permanent (Not Shown)	669654	669654	669654	669654
39	Drain Pan	669665	669665	669665	669665
40	Cap, Charging Port (Not Shown)	---	---	662102	662102
41	Core, Charging Port (Not Shown)	662103	662103	662103	662103
42	Distributor, 8 CIR, Part of Coil Assembly Item 30 - 297192R (Not Shown)	---	---	663586	663586
43	Fitting, Access (Not Shown)	663812	663812	---	---
44	Cap, Service Port, Brass (Not Shown)	663818	663818	---	---
45	Box, Electrical, Bottom/Sides	295881R	295881R	295881R	295881R
46	Cover, Electrical Box	295411R	295411R	295411R	295411R
47	Switch, Limit-Freezestat	M0062206	M0062206	M0062206	M0062206

