


REPLACEMENT PARTS LIST

INDOOR AIR HANDLER B6BV SERIES



B6BV AIR HANDLER

ITEM	DESCRIPTION	B6BV-000K-B-10	B6BV-000K-B-15	B6BV-000K-C-10	B6BV-000K-C-20
		921176	921177	921178	921179
1	PLATE, CLOSE-OFF, ELEC HT (NOT SHOWN)	226420R	226420R	226420R	226420R
2	ELEMENT ASSEMBLY	921913	921914	921913	921915
3	SET OF WIRES, (NOT SHOWN)	921881	921881	921883	921883
4	BLOWER HOUSING	297212R	297212R	297219R	297219R
5	PANEL, TOP,	921878	921878	921879	921879
6	DOOR, FILTER	921875	921875	921876	921876
7	PLATE, TUBE CLOSE-OFF, B6 (NOT SHOWN)	921880	921880	921880	921880
8	HARNESS, FSHE/VSHE, UPPER, AH (NOT SHOWN)	—	—	2C0251R	2C0251R
9	HARNESS, FSHE, LOWER, AH (NOT SHOWN)	—	—	2C0252R	2C0252R
10	MOTOR, BLOWER	622088R	622088R	622501R	622501R
11	RELAY (NOT SHOWN)	622210R	622210R	622210R	622210R
12	TRANSFORMER	621709R	621709R	621709R	621709R
13	CAPAC, RUN	622535R	622535R	—	—
14	PCB, CONTROL	624735R	624735R	624736R	624736R
15	CONTROL, BLOWER, CONSTANT TORQUE	—	—	624756R	624756R
16	LIM, 3/4D, 2S (NOT SHOWN)	626458R	626458R	626458R	626458R
17	LIM, 3/4D, 1S (NOT SHOWN)	—	626487R	—	—
18	DUAL GROUNDING LUG (NOT SHOWN)	632235R	632235R	632235R	632235R
19	CIRCUIT BREAKER, 2 POLE-FE	632249R	632249R	632249R	632249R
20	WHEEL, BLOWER	667037R	667037R	667280R	667280R
21	ROD, ELEMENT SUPPORT (NOT SHOWN)	669325R	669325R	669325R	669325R
22	PAINT, SPRAY, GRAY (NOT SHOWN)	903598	903598	903598	903598
23	BELLY-BAND	—	—	903489	903489
24	BLOWER, ASSY	921856	921856	921862	921862
25	ELECTRICAL ASSEMBLY (NOT SHOWN)	M0063801R	M0063801R	M0063802R	M0063802R
26	DOORS	921869	921869	921870	921870
27	FUSE, 3 AMP (NOT SHOWN)	632261R	632261R	632261R	632261R
43	FILTER DOOR FASTENERS UNITS PRODUCED BEFORE 2/28/2014 (NOT SHOWN)	921402	921402	921402	921402
	FILTER DOOR FASTENERS UNITS PRODUCED ON OR AFTER 3/1/2014 (NOT SHOWN)	922458	922458	922458	922458

Please specify the correct Model No., Serial No., and Part No.(s) when ordering parts from the nearest authorized dealer or service center.

