


WIRING DIAGRAM

H3HK008H-01B (Without Circuit Breaker)
H3HK010H-01B (Without Circuit Breaker)
H4HK008H-01B (Without Circuit Breaker)
H4HK008H-11B (With Circuit Breaker)
H4HK010H-11B (With Circuit Breaker)
H4HK010H-01B (Without Circuit Breaker)

8 kW ,10kW,
1-Stage,240 VAC,
1-Phase Electric Heater Kit



NOTES:

- 1) Circuit breakers (if supplied) are not wired to heater kit by the factory, see Installation Instructions for wiring procedure.
- 2) If any of the original wire supplied with this unit must be replaced, it must be replaced with wiring material of the same gauge size and temperature rating.
- 3) The installation of this heater kit may require a change in the blower speed tap connection. See Installation Instructions for details.
- 4) Use copper conductors with a minimum temperature rating of 60°C for supply connections.

LEGEND:

FIELD WIRING	----
LOW VOLTAGE	———
HIGH VOLTAGE	————



710395B
(Replaces 710395A)