

REPLACEMENT PARTS LIST

SINGLE PACKAGE GAS HEATING / ELECTRIC COOLING

R8GE SERIES

ULTRA LOW NOX, 14 SEER, SINGLE PHASE MODELS



IMPORTANT

- This document is primarily intended to assist qualified individuals experienced in the proper repair or servicing of this appliance. Only factory authorized parts or accessory kits may be used with this product. Improper installation, service, adjustment, or maintenance may cause explosion, fire, electrical shock or other hazardous conditions which may result in personal injury or property damage.
- Some local codes require licensed installation / service personnel to service this type of equipment. Under no circumstances should the equipment owner attempt to install parts or service this equipment. Failure to comply with this warning could result in property damage, personal injury, or death.

R8GE Ultra Low NOx Single Package Gas Heating / Electric Cooling Units

14 SEER, Single Phase Models

DESCRIPTION	R8GE-024K055U1	R8GE-030K070U1	R8GE-036K070U1	R8GE-042K100U1	R8GE-048K100U1	R8GE-X060K100U1
	1036135	1036136	1036137	1036138	1036139	1036140
AUTOTRANSFORMER (200VA, 230 TO 115V)	1036083R	1036083R	1036083R	1036083R	1036083R	1036083R
BLOWER HOUSING (11X10)	297219R	297219R	297219R	297219R	297219R	297219R
BLOWER MOTOR	1040092R	1040093R	1040094R	1040095R	1040096R	1040097R
BLOWER WHEEL	667260	667260	667260	667260	667260	667260
CAPACITOR	01-0084	01-0269	01-0271	01-0271	01-0278	01-0278
COIL GUARD (FORMED)	2A8452R	2A8452R	2A8452R	2A8453R	2A8453R	2C5161R
COLLECTOR GASKET	689506R	689506R	689506R	103610501R	103610501R	103610501R
COLLECTOR PAN/GASKET	1040152	1040152	1040152	1040153	1040153	1040153
COMBUSTION AIR ORIFICE PLATE	1040148	1040146	1040146	1040147	1040147	1040147
COMPRESSOR	1033625R	918869	921427	921465	921466	921467
CONTACTOR	1014863R	1014863R	1014864R	1014865R	1014865R	1014865R
CONTROL BOARD	1039191R	1039191R	1039191R	1039191R	1039191R	1039191R
CORNER PANEL	103612022R	103612022R	103612022R	103612059R	103612059R	103612011R
CORNER POST	D09994R	D09994R	D09994R	D09996R	D09996R	2B1941R
DISTRIBUTOR ASSEMBLY	664518R	664595R	664689R	664691R	664778R	—
DRAIN PAN	669190R	669190R	669190R	669190R	669190R	669190R
DUCT COVER	283101R	283101R	283101R	283101R	283101R	283101R
EXTERNAL SERVICE BRACKET	298552R	298552R	298552R	298552R	298552R	298552R
FAN BLADE	667356R	667278R	667278R	667356R	667278R	667351R
FAN GRILLE (BLACK)	669404R	669404R	669404R	669404R	669404R	669335R
FAN MOTOR	622080R	621990R	621990R	621990R	621990R	621990R
FAN ORIFICE	263210R	263210R	263210R	263210R	263210R	295481R
FILTER DRIER (8 IN^3)	669764R	669764R	669764R	669764R	669764R	669764R
FILTER	1039259R	1039259R	1039259R	1039259R	1039259R	1039259R
FLEXIBLE GAS CONNECTOR (5/8"D X 16"L)	1039233R	1039233R	1039233R	1039233R	1039233R	1039233R
FUSE (AUTOTRANSFORMER)	RZ261956	RZ261956	RZ261956	RZ261956	RZ261956	RZ261956
FUSE HOLDER (NOT SHOWN)	RZ060241	RZ060241	RZ060241	RZ060241	RZ060241	RZ060241
GAS/AIR VENTURI	1018739R	1018739R	1018739R	1018739R	1018739R	1018739R
GAS ORIFICE	661030R	661026R	661026R	661016R	661016R	661016R
GAS VALVE	624775R	624775R	624775R	624775R	624775R	624775R
HAIL GUARD KIT (NOT SHOWN)	917206	917206	917206	917206	917206	917206
HEAT EXCHANGER ASSEMBLY	103612031R	103612031R	103612031R	103612008R	103612008R	103612008R
HIGH PRESSURE SWITCH (NOT SHOWN)	632473R	632473R	632473R	632473R	632473R	632473R
IGNITOR / FLAME SENSOR ASSEMBLY	1021611R	1021611R	1021611R	1021611R	1021611R	1021611R
INDOOR COIL	1017857R	1017857R	1017857R	1017853R	1017853R	1017854R
INDUCER GASKET	689518R	689518R	689518R	689518R	689518R	689518R
INDUCER MOTOR & GASKET	1040149	1040150	1040150	1040151	1040151	1040151
LOUVERED SERVICE PANEL	103612024R	103612024R	103612024R	103948602R	103948602R	103612012R
LOW PRESSURE SWITCH (NOT SHOWN)	1023984R	1023984R	1023984R	1023984R	1023984R	1023984R
MAIN AIR LIMIT SWITCH	626434R	626424R	626424R	626445R	626445R	626445R
MOLDED PLUG (NOT SHOWN)	634715R	634715R	634715R	634715R	634715R	634715R
OUTDOOR COIL	1010327R	1010327R	1010327R	1010325R	1010325R	1010328R
PANEL (FRONT)	298891R	298891R	298891R	298892R	298892R	298894R
PANEL (RETURN)	D05567R	D05567R	D05567R	D05565R	D05565R	M0068603R
PANEL (SUPPLY)	D05558R	D05558R	D05558R	D05552R	D05552R	D05569R
PANEL (TOP)	M0034721R	M0034721R	M0034721R	M0034721R	M0034721R	M0034707R
PRESSURE SWITCH (0.20)	1018505R	1018505R	1018505R	1018505R	1018505R	1018505R
RELAY	1022845R	1022845R	1022845R	1022845R	1022845R	1022845R
SERVICE DOOR	D05548R	D05548R	D05548R	D05542R	D05542R	M0060705R
SET OF WIRES (NOT SHOWN)	103612080R	103612080R	103612080R	103612080R	103612080R	103612080R
TEMPERATURE LIMIT SWITCH	1027311R	1027064R	1027064R	1027311R	1027311R	1027311R
TRANSFORMER (40 VA)	621709R	621709R	621709R	621709R	621709R	621709R
TXV (NOT SHOWN)	—	—	—	—	—	664275R
VENT COVER	265040R	265040R	265040R	265040R	265040R	265040R

Please specify the correct Model No., Serial No, and part number(s) when ordering parts from the nearest authorized dealer or service center.

