

REPLACEMENT PARTS LIST

SINGLE PACKAGE GAS HEATING / ELECTRIC COOLING

VR104GD SERIES

13.4 SEER2, SINGLE PHASE MODELS



IMPORTANT

- This document is primarily intended to assist qualified individuals experienced in the proper repair or servicing of this appliance. Only factory authorized parts or accessory kits may be used with this product. Improper installation, service, adjustment, or maintenance may cause explosion, fire, electrical shock or other hazardous conditions which may result in personal injury or property damage.
- Some local codes require licensed installation / service personnel to service this type of equipment. Under no circumstances should the equipment owner attempt to install parts or service this equipment. Failure to comply with this warning could result in property damage, personal injury, or death.

VR104GD Single Package Gas Heating / Electric Cooling Units 13.4 SEER2, Single Phase 2, 2.5 & 3 Ton Models

DESCRIPTION	2 TON		2.5 TON		3 TON	
	VR104GD-024K045C	V104GD-024K072*	VR104GD-030K045*	VR104GD-030K072*	VR104GD-036K072*	VR104GD-036K096*
	1036038V	1036039V	1036040V	1036041V	1036042V	1036043V
ACCESS FITTING	663812R	663812R	663812R	663812R	663812R	663812R
BLOWER HOUSING	D07484R	D07484R	D07484R	D07484R	D07484R	D07484R
BLOWER MOTOR	104117901R	104117902R	104117903R	104117904R	104117905R	104117906R
BLOWER MOTOR MOUNT KIT	903489	903489	903489	903489	903489	903489
BLOWER SERVICE PANEL ASSY,30",J	D05548VR	D05548VR	D05548VR	D05548VR	D05548VR	D05548VR
BLOWER WHEEL (11 X 10)	667277R	667277R	667277R	667277R	667277R	667277R
CAPACITOR (40/5/370)	01-0084	01-0084	—	—	—	—
CAPACITOR (40/7.5/370)	—	—	01-0269	01-0269	—	—
CAPACITOR (45/7.5/370)	—	—	—	—	01-0271	01-0271
COIL GUARD (FORMED)	2A8452R	2A8452R	2A8452R	2A8452R	2A8452R	2A8452R
COLLECTOR PAN (W/O RETAINER)	M0074322R	100677913R	M0074322R	100677913R	100677913R	100653203R
COLLECTOR PAN GASKET	689506	689506	689506	689506	689506	689506
COMPRESSOR (ZP21K5E)	921423	921423	—	—	—	—
COMPRESSOR (ZP25K5E)	—	—	921425	921425	—	—
COMPRESSOR (ZP31K5E)	—	—	—	—	921427	921427
CONTACTOR (1 POLE 35A)	1014863R	1014863R	1014863R	1014863R	—	—
CONTACTOR (1 POLE 40A)	—	—	—	—	1014864R	1014864R
CONTROL BOARD	919943	919943	919943	919943	919943	919943
CORNER PANEL	D05630VR	D05630VR	D05630VR	D05630VR	D05630VR	D05630VR
CORNER POST	D09994VR	D09994VR	D09994VR	D09994VR	D09994VR	D09994VR
DISTRIBUTOR ASSY, (.057 RESTRICTOR)	664518R	664518R	—	—	—	—
DISTRIBUTOR ASSY, (.062 RESTRICTOR)	—	—	664595R	664595R	—	—
DISTRIBUTOR ASSY, (.068 RESTRICTOR)	—	—	—	—	664689R	664689R
DRAIN PAN ASSEMBLY (INCLUDES DRAIN TUBE)	D05700R	D05700R	D05700R	D05700R	D05700R	D05700R
DRAIN TUBE	663833R	663833R	663833R	663833R	663833R	663833R
EXHAUST DUCT	263420R	263420R	263420R	263420R	263420R	263420R
FAN BLADE	667356R	667356R	667278R	667278R	667278R	667278R
FAN GRILLE (BLACK)	669404R	669404R	669404R	669404R	669404R	669404R
FAN ORIFICE	263210VR	263210VR	263210VR	263210VR	263210VR	263210VR
FILTER DRIER (8 IN^3)	669764R	669764R	669764R	669764R	669764R	669764R
FLAME ROLLOUT LIMIT SWITCH (320° F)	626547R	626547R	626547R	626547R	626547R	626547R
FLAME SENSOR	903600	903600	903600	903600	903600	903600

Please specify the correct Model No., Serial No, and part number(s) when ordering parts from the nearest authorized dealer or service center.

Continued on page 3

VR104GD Single Package Gas Heating / Electric Cooling Units 13.4 SEER2, Single Phase 2, 2.5 & 3 Ton Models continued

DESCRIPTION	2 TON		2.5 TON		3 TON	
	VR104GD-024K045C	V104GD-024K072*	VR104GD-030K045*	VR104GD-030K072*	VR104GD-036K072*	VR104GD-036K096*
	1036038V	1036039V	1036040V	1036041V	1036042V	1036043V
FRONT PANEL	298891VR	298891VR	298891VR	298891VR	298891VR	298891VR
FUSE, 3-AMP (NOT SHOWN)	632261R	632261R	632261R	632261R	632261R	632261R
GAS VALVE	904081	904081	904081	904081	904081	904081
GAS MANIFOLD	664302R	664303R	664302R	664303R	664303R	664304R
HEAT EXCHANGER	100677905R	293335R	100677905R	293335R	293335R	D10303R
HIGH PRESSURE SWITCH AUTO RESET (NOT SHOWN)	632473R	632473R	632473R	632473R	632473R	632473R
HORIZONTAL DUCT COVER	283101VR	283101VR	283101VR	283101VR	283101VR	283101VR
IGNITOR (208/230V)	1046528	1046528	1046528	1046528	1046528	1046528
INDOOR COIL (EVAP COIL)	1017857R	1017857R	1017857R	1017857R	1017857R	1017857R
INDUCER GASKET	689518R	689518R	689518R	689518R	689518R	689518R
INDUCER MOTOR	903162	903162	903162	903162	903162	903162
INSHOT BURNER	660812R (2)	660812R (3)	660812R (2)	660812R (3)	660812R (3)	660812R (4)
MAIN AIR LIMIT SWITCH (165/145)	626432R	—	626432R	—	—	626432R
MAIN AIR LIMIT SWITCH (170/150)	—	626423R	—	626423R	626423R	—
MAIN BURNER ORIFICE (#43 DRILL) (NOT SHOWN)	661043R (2)	661043R (3)	661043R (2)	661043R (3)	661043R (3)	661043R (4)
MOLDED PLUG HV / COMPRESSOR PLUG (NOT SHOWN)	634715R	634715R	634715R	634715R	634715R	634715R
OUTDOOR COIL (CONDENSER COIL)	1010327R	1010327R	1010327R	1010327R	1010327R	1010327R
OUTDOOR FAN MOTOR	622080	622080	622757R	622757R	622757R	622757R
PRESSURE SWITCH (0.50)	1043932R	1043932R	1043932R	1043932R	1043932R	1043932R
RETURN AIR PANEL	D05567VR	D05567VR	D05567VR	D05567VR	D05567VR	D05567VR
SERVICE BRACKET	298552VR	298552VR	298552VR	298552VR	298552VR	298552VR
SERVICE PANEL	D05548VR	D05548VR	D05548VR	D05548VR	D05548VR	D05548VR
SET OF WIRES (NOT SHOWN)	104136601R	104136601R	104136601R	104136601R	104136601R	104136601R
SUPPLY AIR PANEL	D05558VR	D05558VR	D05558VR	D05558VR	D05558VR	D05558VR
TERMINAL BLOCK	632695R	632695R	632695R	632695R	632695R	632695R
TOP CAP (NOT SHOWN)	275291VR	275291VR	275291VR	275291VR	275291VR	275291VR
TOP PAN ASSEMBLY	292441VR	292441VR	292441VR	292441VR	292441VR	292441VR
TOUCH-UP PAINT BRONZE HIGH GLOSS (NOT SHOWN)	1035209R	1035209R	1035209R	1035209R	1035209R	1035209R
TRANSFORMER (40 VA)	621709R	621709R	621709R	621709R	621709R	621709R
VENT COVER	265040R	265040R	265040R	265040R	265040R	265040R

Please specify the correct Model No., Serial No, and part number(s) when ordering parts from the nearest authorized dealer or service center.

VR104GD Single Package Gas Heating / Electric Cooling Units 13.4 SEER2, Single Phase 3.5, 4 & 5 Ton Models

DESCRIPTION	3.5 TON		4 TON		5 TON	
	VR104GD-042K072*	VR104GD-042K096*	VR104GD-048K096*	VR104GD-048K120*	VR104GD-X60K096*	VR104GD-X60K120*
	1036044V	1036045V	1036046V	1036047V	1036048V	1036049V
ACCESS FITTING	663812R	663812R	663812R	663812R	663812R	663812R
BLOWER HOUSING	D07484R	D07484R	D07484R	D07484R	D07484R	D07484R
BLOWER MOTOR	104117907R	104117908R	104117909R	104117910R	104117911R	104117912R
BLOWER MOTOR MOUNT KIT	903489	903489	903489	903489	903489	903489
BLOWER SERVICE PANEL ASSY,J	D05542VR	D05542VR	D05543VR	D05543VR	D05543VR	D05543VR
BLOWER WHEEL (11 X 10)	667277R	667277R	667277R	667277R	667277R	667277R
CAPACITOR, RUN 45/7.5/370	01-0271	01-0271	—	—	—	—
CAPACITOR, RUN 70/7.5/370	—	—	01-0278	01-0278	—	—
CAPACITOR, RUN 80/7.5/370	—	—	—	—	01-0279	01-0279
COIL GUARD (FORMED)	2A8453R	2A8453R	2A8454R	2A8454R	2A8454R	2A8454R
COLLECTOR PAN (W/O RETAINER)	D10322R	100653203R	D10328R	100677916R	D10328R	100677916R
COLLECTOR PAN GASKET	689506	689506	689506	689506	689506	689506
COMPRESSOR (ZP40K6E)	922459	922459	—	—	—	—
COMPRESSOR (ZP42K5E)	—	—	921466	921466	—	—
COMPRESSOR (ZP54K5E)	—	—	—	—	921468	921468
CONTACTOR (1 POLE 50A)	1014865R	1014865R	1014865R	1014865R	1014865R	1014865R
CONTROL BOARD	919943	919943	919943	919943	919943	919943
CORNER PANEL	D05628VR	D05628VR	D05629VR	D05629VR	D05629VR	D05629VR
CORNER POST	D09996VR	D09996VR	D09997VR	D09997VR	D09997VR	D09997VR
DISTRIBUTOR ASSY, (.074 RESTRICTOR)	—	—	664599R	664599R	—	—
DISTRIBUTOR ASSY, (.076 RESTRICTOR)	664691R	664691R	—	—	—	—
DRAIN PAN ASSEMBLY (INCLUDES DRAIN TUBE)	D05700R	D05700R	D05700R	D05700R	D05700R	D05700R
DRAIN TUBE	663833R	663833R	663833R	663833R	663833R	663833R
EXHAUST DUCT	263420R	263420R	263420R	263420R	263420R	263420R
FAN BLADE	667356R	667356R	1024013R	1024013R	667319R	667319R
FAN GRILLE (BLACK)	669404R	669404R	1034994R	1034994R	1034994R	1034994R
FAN ORIFICE	263210VR	263210VR	295481VR	295481VR	295481VR	295481VR
FILTER DRIER (8 IN^3)	669764R	669764R	669764R	669764R	669764R	669764R
FLAME ROLLOUT LIMIT SWITCH (320° F)	626547R	626547R	626547R	626547R	626547R	626547R
FLAME SENSOR	903600	903600	903600	903600	903600	903600
FRONT PANEL	298892VR	298892VR	298893VR	298893VR	298893VR	298893VR
FUSE, 3-AMP (NOT SHOWN)	632261R	632261R	632261R	632261R	632261R	632261R

Please specify the correct Model No., Serial No, and part number(s) when ordering parts from the nearest authorized dealer or service center.

Continued on page 5

VR104GD Single Package Gas Heating / Electric Cooling Units 13.4 SEER2, Single Phase 3.5, 4 & 5 Ton Models continued

DESCRIPTION	3.5 TON		4 TON		5 TON	
	VR104GD-042K072*	VR104GD-042K096*	VR104GD-048K096*	VR104GD-048K120*	VR104GD-X60K096*	VR104GD-X60K120*
	1036044V	1036045V	1036046V	1036047V	1036048V	1036049V
GAS VALVE	904081	904081	904081	904081	904081	904081
GAS MANIFOLD	664303R	664304R	66304R	664305R	664304R	664305R
HEAT EXCHANGER	100677908R	903478	100677911R	100677912R	100677911R	100677912R
HIGH PRESSURE SWITCH AUTO RESET (NOT SHOWN)	632473R	632473R	632473R	632473R	632473R	632473R
HORIZONTAL DUCT COVER	283101VR	283101VR	283101VR	283101VR	283101VR	283101VR
IGNITOR (208/230V)	1046528	1046528	1046528	1046528	1046528	1046528
INDOOR COIL (EVAP COIL)	1017853R	1017853R	1017858R	1017858R	1017858R	1017858R
INDUCER GASKET	689518R	689518R	689518R	689518R	689518R	689518R
INDUCER MOTOR	903162	903162	903162	903162	903162	903162
INSHOT BURNER	660812R (3)	660812R (4)	660812R (4)	660812R (5)	660812R (4)	660812R (5)
MAIN AIR LIMIT SWITCH (165/145)	—	626432R		—	—	—
MAIN AIR LIMIT SWITCH (175/155)	—	—	—	626424R	—	626424R
MAIN AIR LIMIT SWITCH (185/165)	—	—	626445R	—	626445R	—
MAIN AIR LIMIT SWITCH (210/190)	626624R	—	—	—	—	—
MAIN BURNER ORIFICE (#43 DRILL) (NOT SHOWN)	661043R (3)	661043R (4)	661043R (4)	661043R (5)	661043R (4)	661043R (5)
MOLDED PLUG HV / COMPRESSOR PLUG (NOT SHOWN)	634715R	634715R	634715R	634715R	634715R	634715R
OUTDOOR COIL (CONDENSER COIL)	1010325R	1010325R	1010326R	1010326R	1010326R	1010326R
OUTDOOR FAN MOTOR	622757R	622757R	622757R	622757R	622757R	622757R
PRESSURE SWITCH (0.50)	1043932R	1043932R	1043932R	1043932R	1043932R	1043932R
RETURN AIR PANEL	D05565VR	D05565VR	D05566VR	D05566VR	D05566VR	D05566VR
SERVICE BRACKET	298552VR	298552VR	298552VR	298552VR	298552VR	298552VR
SERVICE PANEL	D05542VR	D05542VR	D05543VR	D05543VR	D05543VR	D05543VR
SET OF WIRES (NOT SHOWN)	104136602R	104136602R	104136602R	104136602R	104136602R	104136602R
SUPPLY AIR PANEL	D05552VR	D05552VR	D05557VR	D05557VR	D05557VR	D05557VR
TERMINAL BLOCK	632695R	632695R	632695R	632695R	632695R	632695R
TOP CAP (NOT SHOWN)	275291VR	275291VR	275291VR	275291VR	275291VR	275291VR
TOP PAN ASSEMBLY	292441VR	292441VR	M0034707VR	M0034707VR	M0034707VR	M0034707VR
TOUCH-UP PAINT BRONZE HIGH GLOSS (NOT SHOWN)	1035209R	1035209R	1035209R	1035209R	1035209R	1035209R
TRANSFORMER (40 VA)	621709R	621709R	621709R	621709R	621709R	621709R
VALVE, TXV, EQ, CK, R410A, 5.0T, ID	—	—	—	—	664275R	664275R
VENT COVER	265040R	265040R	265040R	265040R	265040R	265040R

Please specify the correct Model No., Serial No, and part number(s) when ordering parts from the nearest authorized dealer or service center.

