

REPLACEMENT PARTS LIST

SINGLE PACKAGE GAS HEATING / ELECTRIC COOLING


VR8GE SERIES

ULTRA LOW NOX, 14 SEER, SINGLE PHASE MODELS



IMPORTANT

- This document is primarily intended to assist qualified individuals experienced in the proper repair or servicing of this appliance. Only factory authorized parts or accessory kits may be used with this product. Improper installation, service, adjustment, or maintenance may cause explosion, fire, electrical shock or other hazardous conditions which may result in personal injury or property damage.
- Some local codes require licensed installation / service personnel to service this type of equipment. Under no circumstances should the equipment owner attempt to install parts or service this equipment. Failure to comply with this warning could result in property damage, personal injury, or death.



VR8GE Ultra Low Nox Single Package Gas Heating / Electric Cooling Units

14 SEER, Single Phase Models

DESCRIPTION	VR8GE-024K055U1	VR8GE-030K070U1	VR8GE-036K070U1	VR8GE-042K100U1	VR8GE-048K100U1	VR8GE-X60K100U1
	1036135V	1036136V	1036137V	1036138V	1036139V	1036140V
AUTOTRANSFORMER (200VA, 230 TO 115V)	1036083R	1036083R	1036083R	1036083R	1036083R	1036083R
BLOWER HOUSING (11X10)	297219R	297219R	297219R	297219R	297219R	297219R
BLOWER MOTOR	1040092R	1040093R	1040094R	1040095R	1040096R	1040097R
BLOWER MOTOR MOUNT KIT	903489	903489	903489	903489	903489	903489
BLOWER WHEEL	667260	667260	667260	667260	667260	667260
CAPACITOR	01-0084	01-0269	01-0271	01-0271	01-0278	01-0278
COIL GUARD (FORMED)	2A8452R	2A8452R	2A8452R	2A8453R	2A8453R	2C5161R
COLLECTOR GASKET	689506R	689506R	689506R	103610501R	103610501R	103610501R
COLLECTOR PAN/GASKET	1040152	1040152	1040152	1040153	1040153	1040153
COMBUSTION AIR ORIFICE PLATE	1043390	1043388	1043388	1043389	1043389	1043389
COMPRESSOR	921423	921425	921427	921465	921466	921467
CONTACTOR	1014863R	1014863R	1014864R	1014865R	1014865R	1014865R
CONTROL BOARD	1039191R	1039191R	1039191R	1039191R	1039191R	1039191R
CORNER PANEL	1039462R	1039462R	1039462R	1039472R	1039472R	1039480R
CORNER POST	D09994BR	D09994BR	D09994BR	D09996BR	D09996BR	2B1941BR
DISTRIBUTOR ASSEMBLY (ORIFICE SIZE SHOWN UNDER SKU)	664518R (.057)	664595R (.062)	664689R (.068)	664691R (.076)	664778R (.078)	—
DRAIN PAN	669190R	669190R	669190R	669190R	669190R	669190R
DUCT COVER	283101BR	283101BR	283101BR	283101BR	283101BR	283101BR
EXTERNAL SERVICE BRACKET	298552BR	298552BR	298552BR	298552BR	298552BR	298552BR
FAN BLADE	667356R	667278R	667278R	667356R	667278R	667319R
FAN GRILLE (BLACK)	669404R	669404R	669404R	669404R	669404R	1034994R
FAN MOTOR	622080R	622757R	622757R	622757R	622757R	622757R
FAN ORIFICE	263210BR	263210BR	263210BR	263210BR	263210BR	295481BR
FILTER DRIER (8 IN^3)	669764R	669764R	669764R	669764R	669764R	669764R
FILTER	1039259R	1039259R	1039259R	1039259R	1039259R	1039259R
FLEXIBLE GAS CONNECTOR (5/8"D X 16"L)	1039233R	1039233R	1039233R	1039233R	1039233R	1039233R
FUSE (AUTOTRANSFORMER)	RZ261956	RZ261956	RZ261956	RZ261956	RZ261956	RZ261956
FUSE HOLDER (NOT SHOWN)	RZ060241	RZ060241	RZ060241	RZ060241	RZ060241	RZ060241
GAS/AIR VENTURI	1018739R	1018739R	1018739R	1018739R	1018739R	1018739R
GAS ORIFICE	661030R	661026R	661026R	661016R	661016R	661016R
HAIL GUARD KIT (NOT SHOWN)	917206	917206	917206	917206	917206	917206
HEAT EXCHANGER ASSEMBLY	103612031R	103612031R	103612031R	103612008R	103612008R	103612008R
HIGH PRESSURE SWITCH (NOT SHOWN)	632473R	632473R	632473R	632473R	632473R	632473R
IGNITOR / FLAME SENSOR ASSEMBLY	1021611R	1021611R	1021611R	1021611R	1021611R	1021611R
INDOOR COIL	1017857R	1017857R	1017857R	1017853R	1017853R	1017854R
INDUCER GASKET	689988R	689988R	689988R	689988R	689988R	689988R
INDUCER MOTOR & GASKET	1040149	1040150	1040150	1040151	1040151	1040151
LOUVERED SERVICE PANEL	1039463R	1039463R	1039463R	1039473R	1039473R	1039479R
LOW PRESSURE SWITCH (NOT SHOWN)	1023984R	1023984R	1023984R	1023984R	1023984R	1023984R
MAIN AIR LIMIT SWITCH	626434R	626424R	626424R	626445R	626445R	626445R
MOLDED PLUG (NOT SHOWN)	634715R	634715R	634715R	634715R	634715R	634830R
OUTDOOR COIL	1010327R	1010327R	1010327R	1010325R	1010325R	1010328R
PANEL (FRONT)	298891BR	298891BR	298891BR	298892BR	298892BR	298894BR
PANEL (RETURN)	D05568BR	D05568BR	D05568BR	D05565BR	D05565BR	M0068605R
PANEL (SUPPLY)	D05559R	D05559R	D05559R	D05552BR	D05552BR	D05569BR
PANEL (TOP)	100677903R	100677903R	100677903R	100677903R	100677903R	M0034710BR
PRESSURE SWITCH (0.20)	1018505R	1018505R	1018505R	1018505R	1018505R	1018505R
RELAY	622180R	622180R	622180R	622180R	622180R	622180R
SERVICE DOOR	D05549R	D05549R	D05549R	D05542BR	D05542BR	M0060714R
SET OF WIRES (NOT SHOWN)	103612080R	103612080R	103612080R	103612080R	103612080R	103612080R
SPRAY PAINT	898329R	898329R	898329R	898329R	898329R	898329R
TEMPERATURE LIMIT SWITCH	1027311R	1027064R	1027064R	1027311R	1027311R	1027311R
TRANSFORMER (40 VA)	621709R	621709R	621709R	621709R	621709R	621709R
TXV (NOT SHOWN)	—	—	—	—	—	664275R
VENT COVER	265040R	265040R	265040R	265040R	265040R	265040R

Please specify the correct Model No., Serial No, and part number(s) when ordering parts from the nearest authorized dealer or service center.

