


REPLACEMENT PARTS LIST

FLEX MATCH SYSTEM
CASSETTE TYPE INDOOR UNIT
GKH12(3.5)FMK4DH1

ITEM #	COMPONENT
1	REAR GRILL
2	BRUSHLESS DC MOTOR (FAN MOTOR)
3	WATER TRAY ASSY
4	WATER PUMP
5	LIQUID LEVEL SWITCH
6	PUMP DRAINPIPE
7	WATER PUMP ASSY
8	RIGHT SIDE PLATE SUB-ASSY
9	BOTTOM FOAM ASSY
10	BASE PLATE ASSY
11	BODY INSTALLING SUPPORT
12	LEFT SIDE PLATE SUB-ASSY
13	CONNECTING PLATE(FRONT PANEL)
14	COVER PLATE SUB-ASSY
15	ELECTRIC BOX ASSY
16	TERMINAL BOARD
17	WIRE CLAMP
18	MAIN BOARD
19	ELECTRIC BOX COVER
20	FRONT SIDE PLATE SUB-ASSY
21	DRAIN HOSE SUB-ASSY
22	ROOM SENSOR
23	TEMPERATURE SENSOR (TUBE SENSOR)
24	REMOTE CONTROLLER
25	EVAPORATOR ASSY
26	SUPPORTER
27	CENTRIFUGAL FAN (BLOWER WHEEL)
28	DIVERSION CIRCLE



GKH12(3.5)FMK4DH1

	PART DESCRIPTION	PART CODE	NORTEK PART NUMBER
1	Rear Grill	26909400007	1032714
2	Brushless DC Motor (Fan Motor)	1570940000401	1028702
3	Water Tray Assy	01289400004	1028687
4	Water Pump	4313800005801	1046526
5	Liquid Level Switch	450102013	1044321
6	Pump Drainpipe	26909400069	1046525
7	Water Pump Assy	15409400008	1046524
8	Right Side Plate Sub-Assy	01319400013	1044324
9	Bottom Foam Assy	12509400004	1046523
10	Base Plate Assy	02229400007	1044323
11	Body Installing Support	01332705	1044327
12	Left Side Plate Sub-Assy	01319400012	1044328
13	Connecting Plate(Front Panel)	01349400006	1046522
14	Cover Plate Sub-Assy	01269400006	1046521
15	Electric Box Assy	100002066221	1046520
16	Terminal Board	420001000002	1041734
17	Wire Clamp	0220410000501	1046519
18	Main Board	300002060012	1046518
19	Electric Box Cover	0142940000301	1046517
20	Front Side Plate Sub-Assy	01319400014	1044326
21	Drain Hose Sub-Assy	0070080000001	1044210
22	Room Sensor	39000191	1008271
23	Temperature Sensor (Tube Sensor)	3900012128	1008270
24	Remote Controller	30510599	1028705
25	Evaporator Assy	01029400058	1046515
26	Supporter	01809400007	1044330
27	Centrifugal Fan (Blower Wheel)	10429400001	1003125
28	Diversion Circle	10479400001	1044319

