

REPLACEMENT PARTS LIST

WALL MOUNT AIR HANDLER
RF1PY




RF1PY WALL MOUNT AIR HANDLER

DESCRIPTION	RF1PY1821STANSJB05	RF1PY1821STANSJB08	RF1PY2421STANSJB05	RF1PY2421STANSJB08	RF1PY2421STANSJB10
	1.5 TON, 5KW	1.5 TON, 8KW	2 TON, 5 KW	2 TON, 8KW	2 TON, 10KW
AIR FILTER	54-17531-04	54-17531-04	54-17531-04	54-17531-04	54-17531-04
BLOWER DOOR	AE-103093-11	AE-103093-11	AE-103093-11	AE-103093-11	AE-103093-11
BLOWER HOUSING & WHEEL	70-104803-02	70-104803-02	70-104803-02	70-104803-02	70-104803-02
BLOWER MOTOR	51-102500-07	51-102500-07	51-102500-08	51-102500-08	51-102500-08
BLOWER ASSEMBLY	AS-103222-11	AS-103222-11	AS-103222-12	AS-103222-12	AS-103222-12
CAPACITOR	01-0024	01-0024	01-0025	01-0025	01-0025
CIRCUIT BREAKER	QOU230	PD455183	QOU230	PD455183	PD455681
CIRCUIT BREAKER COVER	68-103316-01	68-103316-01	68-103316-01	68-103316-01	68-103316-01
COIL BRACKET (LEFT)	10-103106-11	10-103106-11	10-103106-11	10-103106-11	10-103106-11
COIL BRACKET (RIGHT)	10-103106-12	10-103106-12	10-103106-12	10-103106-12	10-103106-12
CONTROL BOARD KIT	47-100436-08K	47-100436-08K	47-100436-08K	47-100436-08K	47-100436-08K
DRAIN PAN	68-103104-01	68-103104-01	68-103104-01	68-103104-01	68-103104-01
DRAIN PLUG	68-100070-02	68-100070-02	68-100070-02	68-100070-02	68-100070-02
EXPANSION VALVE (TXV) VALVE ONLY	61-109959-01V	61-109959-01V	61-109959-01V	61-109959-01V	61-109959-01V
FILTER RETAINER	10-103218-01	10-103218-01	10-103218-01	10-103218-01	10-103218-01
GROUND LUG	45-19000-01	45-19000-01	45-19000-01	45-19000-01	45-19000-01
HEATER KIT	RXHJ-21B05J-1	RXHJ-21B08J-1	RXHJ-21B05J-1	RXHJ-21B08J-1	RXHJ-21B10J-1
LIMIT SWITCH (AUTO RESET)	PD425123	PD425123	PD425123	PD425123	PD425123
LIMIT SWITCH (NON-RESETTABLE)	PD476642	PD476642	PD476642	PD476642	PD476642
MOTOR MOUNT ARM W/GROMMET	70-19929-10	70-19929-10	70-19929-10	70-19929-10	70-19929-10
MOTOR MOUNT BAND	70-19927-04	70-19927-04	70-19927-04	70-19927-04	70-19927-04
MOUNTING BRACKET (CABINET)	AE-103105-01	AE-103105-01	AE-103105-01	AE-103105-01	AE-103105-01
MOUNTING BRACKET (WALL)	AE-103105-02	AE-103105-02	AE-103105-02	AE-103105-02	AE-103105-02
RELAY - DPST-NO (24 VAC COIL)	42-101208-05	42-101208-05	42-101208-05	42-101208-05	42-101208-05
REPLACEMENT COIL	RCHY2421STASVU	RCHY2421STASVU	RCHY2421STASVU	RCHY2421STASVU	RCHY2421STASVU
SENSOR A2L	47-109642-01	47-109642-01	47-109642-01	47-109642-01	47-109642-01
SEQUENCING RELAY (HEATER KIT)	PD425166	PD425166	PD425166	PD425166	PD425166
TERMINAL BLOCK	45-23222-02	45-23222-02	45-23222-02	45-23222-02	45-23222-02
TRANSFORMER	46-101905-01	46-101905-01	46-101905-01	46-101905-01	46-101905-01
TXV BULB STRAP MOUNTING KIT	64-21106-02	64-21106-02	64-21106-02	64-21106-02	64-21106-02
WIRING HARNESS	45-24371-57	45-24371-57	45-24371-57	45-24371-57	45-24371-57
WIRING HARNESS	45-102645-03	45-102645-03	45-102645-03	45-102645-03	45-102645-03
PLUG HOUSING ASSEMBLY A2L T-STAT (PSC)	45-109519-02	45-109519-02	45-109519-02	45-109519-02	45-109519-02
PLUG HOUSING ASSEMBLY T-STAT	45-109872-04	45-109872-04	45-109872-04	45-109872-04	45-109872-04


RF1PY WALL MOUNT AIR HANDLER

DESCRIPTION	RF1PY3024STANSJB05	RF1PY3024STANSJB08	RF1PY3024STANSJB10
	2.5 TON, 5KW	2.5 TON, 8KW	2.5 TON, 10KW
AIR FILTER	54-17531-06	54-17531-06	54-17531-06
BLOWER DOOR	AE-103093-14	AE-103093-14	AE-103093-14
BLOWER HOUSING & WHEEL	70-104803-01	70-104803-01	70-104803-01
BLOWER MOTOR	51-101728-04	51-101728-04	51-101728-04
BLOWER ASSEMBLY	AS-103222-04	AS-103222-04	AS-103222-04
CAPACITOR	01-0066	01-0066	01-0066
CIRCUIT BREAKER	QOU230	PD455183	PD455681
CIRCUIT BREAKER COVER	68-103316-01	68-103316-01	68-103316-01
COIL BRACKET (LEFT)	10-103106-08	10-103106-08	10-103106-08
COIL BRACKET (RIGHT)	10-103106-09	10-103106-09	10-103106-09
CONTROL BOARD KIT	47-100436-08K	47-100436-08K	47-100436-08K
DRAIN PAN	68-103104-02	68-103104-02	68-103104-02
DRAIN PLUG	68-100070-02	68-100070-02	68-100070-02
EXPANSION VALVE (TXV) VALVE ONLY	61-109959-02V	61-109959-02V	61-109959-02V
FILTER RAIL	10-103218-05	10-103218-05	10-103218-05
GROUND LUG	45-19000-01	45-19000-01	45-19000-01
HEATER KIT	RXHJ-21B05J-1	RXHJ-21B08J-1	RXHJ-21B10J-1
LIMIT SWITCH (AUTO RESET)	PD425123	PD425123	PD425123
LIMIT SWITCH (NON-RESETTABLE)	PD476642	PD476642	PD476642
MOTOR MOUNT ARM W/GROMMET	70-19929-11	70-19929-11	70-19929-11
MOTOR MOUNT BAND	70-19927-04	70-19927-04	70-19927-04
MOUNTING BRACKET (CABINET)	AE-103105-01	AE-103105-01	AE-103105-01
MOUNTING BRACKET (WALL)	AE-103105-02	AE-103105-02	AE-103105-02
RELAY - DPST-NO (24 VAC COIL)	42-101208-05	42-101208-05	42-101208-05
REPLACEMENT COIL	RCHY3624STASVU	RCHY3624STASVU	RCHY3624STASVU
SENSOR A2L	47-109642-01	47-109642-01	47-109642-01
SEQUENCING RELAY (HEATER KIT)	PD425166	PD425166	PD425166
TERMINAL BLOCK	45-23222-02	45-23222-02	45-23222-02
TRANSFORMER	46-101905-01	46-101905-01	46-101905-01
TXV BULB STRAP MOUNTING KIT	64-21106-02	64-21106-02	64-21106-02
WIRING HARNESS	45-24371-57	45-24371-57	45-24371-57
WIRING HARNESS	45-102645-03	45-102645-03	45-102645-03
PLUG HOUSING ASSEMBLY A2L T-STAT (PSC)	45-109519-02	45-109519-02	45-109519-02
PLUG HOUSING ASSEMBLY T-STAT	45-109872-04	45-109872-04	45-109872-04

Please specify the correct Model No., Serial No., and part number(s) when ordering parts from the nearest authorized dealer or service center.



**EXPLODED VIEW
1.5 - 2 TON MODELS**



BLOWER ASSEMBLY

