



Universal HVAC Parts & Accessories


REPLACEMENT PARTS LIST

R32 ULTRA SIDE DISCHARGE

2 TON AIR HANDLER

UMD24MSK3IH

ITEM #	COMPONENT
1	Transformer
2	Main Board
3	Centrifugal Fan Housing (Blower Housing)
4	Brushless DC Motor (Blower Motor)
5	Water Tray (Horizontal Drain Pan)
6	Strainer
7	Evaporator Assy
8	Choke Plug
9	Water Tray (Vertical Drain Pan)
10	Gas Sensor
11	Filter Sub-Assy
12	Temperature Sensor*
13	Electric Expansion Valve Sub-Assy (Not Shown)
14	Terminal Board (Not Shown)
15	Terminal Board (Not Shown)
16	Jumper (Not Shown)
17	Sensor Sub-Assy (Not Shown)**



UMD24MSK3IH

	PART DESCRIPTION	PART CODE	NORDYNE PART NUMBER
1	Transformer	43110286	1032640
2	Main Board	300002064036	1050311
3	Centrifugal Fan Housing (Blower Housing)	1570220101	1050310
4	Brushless DC Motor (Blower Motor)	15010400001401	1032757
5	Water Tray (Horizontal Drain Pan)	2690220000202	1050309
6	Strainer	035021060019	1050308
7	Evaporator Assy	011001063444P	1050307
8	Choke Plug	76718209	1032661
9	Water Tray (Vertical Drain Pan)	2690220000102	1050306
10	Gas Sensor	34002406001501	1050305
11	Filter Sub-Assy	111001060269	1050304
12	Temperature Sensor*	390001060085	1050303
13	Electric Expansion Valve Sub-Assy (Not Shown)	030026061767	1050302
14	Terminal Board (Not Shown)	422000060207	1050300
15	Terminal Board (Not Shown)	42200006005601	1050299
16	Jumper (Not Shown)	4202021909	1028868
17	Sensor Sub-Assy (Not Shown)**	390002060708	1050301

* = Air outlet temperature sensor

** = 1)Evaporator inlet pipe temp. sensor; 2) Evaporator outlet pipe temp. sensor;
3) Evaporator medium pipe temp. sensor; 4) Air return temp.sensor

