


REPLACEMENT PARTS LIST

R32 ULTRA SIDE DISCHARGE

3 TON AIR HANDLER

UMD36MSK3IH

ITEM #	COMPONENT
1	Main Board
2	Terminal Board
3	Terminal Board
4	Transformer
5	Centrifugal Fan Housing (Blower Housing)
6	Brushless DC Motor (Blower Motor)
7	Water Tray (Horizontal Drain Pan)
8	Evaporator Assy
9	Choke Plug
10	Water Tray (Vertical Drain Pan)
11	Strainer
12	Electric Expansion Valve Sub-Assy
13	Gas Sensor
14	Filter Sub-Assy
15	Temperature Sensor*
16	Jumper (Not Shown)
17	Sensor Sub-Assy (Not Shown)**



UMD36MSK3IH

	PART DESCRIPTION	PART CODE	NORDYNE PART NUMBER
1	Main Board	300002064036	1050311
2	Terminal Board	422000060207	1050300
3	Terminal Board	42200006005601	1050299
4	Transformer	43110286	1032640
5	Centrifugal Fan Housing (Blower Housing)	1570220201	1032756
6	Brushless DC Motor (Blower Motor)	15010400001401	1032757
7	Water Tray (Horizontal Drain Pan)	2690220502	1050298
8	Evaporator Assy	011001063481P	1050297
9	Choke Plug	76718209	1032661
10	Water Tray (Vertical Drain Pan)	2690220402	1050296
11	Strainer	0721200102	1032658
12	Electric Expansion Valve Sub-Assy	030026061768	1050295
13	Gas Sensor	34002406001501	1050305
14	Filter Sub-Assy	111001060160	1032703
15	Temperature Sensor*	390001060085	1050303
16	Jumper (Not Shown)	4202021911	1028695
17	Sensor Sub-Assy (Not Shown)**	390002060708	1050301

* = Air outlet temperature sensor

** = 1)Evaporator inlet pipe temp. sensor; 2) Evaporator outlet pipe temp. sensor;
3) Evaporator medium pipe temp. sensor; 4) Air return temp.sensor

