


REPLACEMENT PARTS LIST

R32 ULTRA SIDE DISCHARGE

4 TON AIR HANDLER

UMD48MSK3IH

ITEM #	COMPONENT
1	Terminal Board
2	Transformer
3	Main Board
4	Terminal Board
5	Centrifugal Fan Housing (Blower Housing)
6	Brushless DC Motor (Blower Motor)
7	Water Tray (Horizontal Drain Pan)
8	Evaporator Assy
9	Electric Expansion Valve Sub-Assy
10	Strainer
11	Choke Plug
12	Water Tray (Vertical Drain Pan)
13	Gas Sensor
14	Filter Sub-Assy
15	Temperature Sensor*
16	Sensor Sub-Assy (Not Shown)**
17	Jumper (Not Shown)



UMD48MSK3IH

	PART DESCRIPTION	PART CODE	NORDYNE PART NUMBER
1	Terminal Board	422000060207	1050300
2	Transformer	43110286	1032640
3	Main Board	300002064036	1050311
4	Terminal Board	42200006005601	1050299
5	Centrifugal Fan Housing (Blower Housing)	1570220301	1032636
6	Brushless DC Motor (Blower Motor)	15010400001301	1032771
7	Water Tray (Horizontal Drain Pan)	2690220502	1050298
8	Evaporator Assy	011001063446P	1050294
9	Electric Expansion Valve Sub-Assy	030026061769	1050293
10	Strainer	0721200102	1032658
11	Choke Plug	76718209	1032661
12	Water Tray (Vertical Drain Pan)	2690220602	1050292
13	Gas Sensor	34002406001501	1050305
14	Filter Sub-Assy	111001060188	1045209
15	Temperature Sensor*	390001060085	1050303
16	Sensor Sub-Assy (Not Shown)**	390002060708	1050301
17	Jumper (Not Shown)	4202021912	1050291

* = Air outlet temperature sensor

** = 1)Evaporator inlet pipe temp. sensor; 2) Evaporator outlet pipe temp. sensor;

3) Evaporator medium pipe temp. sensor; 4) Air return temp.sensor

